WALKER

Illustrated Parts Manual

R22



Beginning S/N: 196175
P/N 1000-15

KEY TO ABBREVIATIONS USED IN THIS MANUAL

Abbreviation	*What it Represents*
º (Dimension)	Degrees (Angle)
" (Dimension)	inches
(-)	Negative (Polarity)
(+)	Positive (Polarity)
-1 (as deck style designation)	Standard (Aluminum) Gear Drive Deck
-2 (as deck style designation)	Heavy Duty (Cast Iron) Gear Drive Deck
-3 (as deck style designation)	Belt Drive Deck
AT	All-Terrain
CCW	Counter-clockwise
CW	Clockwise
D	Diameter
DC	Deck, Collection (number refers to size in inches)
DM	Deck, Mulching (number refers to size in inches)
DR	Deck, Rear Discharge (number refers to size in inches)
DS	Deck, Side Discharge (number refers to size in inches)
DU	Garlock (Bearing)
ESNA (Fastener)	Nylon Insert Locknut
FSC	Forward Speed Control
GA	Gauge
gal.	gallon
GHS	Grass Handling System
GR (Fastener)	Grade
HD	Heavy Duty
HP	Horse Power
ID	Identification or Inside Diameter
L	Length
LH	Left Hand (orientated with operator on seat)
LP	Low Profile
mm (Dimension)	millimeters
MS (Fastener)	Machine Screw
NS (as part number)	Item is not sold by Walker Manufacturing
OD	Outside Diameter
oz.	ounce
PFH (Fastener)	Phillips Flat Head
P/N	Part Number
PPH (Fastener)	Phillips Pan Head
PTH (Fastener)	Phillips Truss Head
PTO	Power Take-Off
QKS	Quick Slide
qt	quart
RH	Right Hand (orientated with operator on seat)
SAE (Fastener)	Society of Automotive Engineers
SBH (Fastener)	Socket Button Head (Bolt)
SD	Side Discharge
SFH (Fastener)	Slotted Flat Head
SHC (Fastener)	Socket Head Cap
SHL (Fastener)	Shoulder (Bolt)
SM (Fastener)	Sheet Metal (Screw)
S/N	Serial Number
SQH (Fastener)	Square Head
SS (Fastener)	Stainless Steel
ST (Fastener)	Self-Tapping (Screw)
V	Volts

NOTE: In some instances, combinations of abbreviations may be used (e.g. PPHMS - Phillips Pan Head Machine Screw).

ILLUSTRATED PARTS LIST


Section of Tractor Covered	*Page*
Decals	
Tractor Decals	2
Body / Chassis Assemblies	
Body / Chassis Assembly	4
Tractor Components	
Main Component Power Transmission	6
Engine Group	8
Hydrostatic and Brake Assemblies	10
Steering Control Assemblies	12
Electrical Components	
Electrical Assembly	14
Maintenance	
Lubrication Points	16
Wiring Schematic	18
Maintenance And Service Record Sheet	19
Warranty	
Limited Warranty	21

TRACTOR DECALS

ITEM NO.	PART NO.	DESCRIPTION	LOCATION	NO. REQ'D
Walker Product and Operation Decals				
1	8600-52	RH Fender	Chassis, RH Side Near Seat	1
2	5800-9	Decal, Walker Round (4-3/4")	Chassis, LH Side	1
3	8600-53	LH Fender	Chassis, LH Side Near Seat	1
4	8821-34	Decal, R22	Chassis, Front	1
Danger Decals Warning Decals Caution Decals				
5	8600-5	Caution, Engine Exhaust	Muffler Guard	1
6	8600-12	Caution, Engine Exhaust	Engine, LH Side	1
7	1600-6	Decal, Belt Routing	Seat Pan, Underside	1
8	8600-66	Decal, Pinch Point	Tensioner Mount Assembly	1
Maintenance Decals				
9	8600-54	Decal, Ignition Switch	Chassis, Front	1
10	5855	Important, Engine Cooling	Engine	1
11	6895-103	Rehlko/Kohler 300 Hour Oil	Solenoid Guard	1
12	1600-2	Decal, Steering Lever	Chassis, Front	1

NOTE: All parts requiring decals are shipped with decals applied.

TRACTOR DECALS



Refer to Decks Parts Manual for Deck Decals


BODY / CHASSIS ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Seat Assembly			
1	5103-3	Seat W/Switch	1
2	7440-5	Shock Mount (1-1/4 x 3/4)	4
3	5103-11	Seat Pan	1
4	4504-1	Hinge (13-1/2")	1
Body Assembly			
5	7845-1	Rubber Bumper (1.375 x .750)	2
6	1300-10	Solenoid Guard	1
7	1300-5	Hydro Fan Cover, LH	1
8	1910-3	Battery Mount Plate	1
9	1406-1	Parking Brake Bracket	1
10	5180	Edge Molding, Lever Opening	2
11	1300-1	Chassis Frame	1
12	1300-2	Hydro Fan Cover, RH	1
13	1046	Gas Tank Mount	1
14	7222	Extension Spring (1/4 x 3)	1
15	1383-1	Seat Latch	1
16	5847	Plastic Tip	1
17	5145-4	Gas Spring Assembly	1
Rear Chassis Assembly			
18	1013-4	Muffler Guard	1
19	5267-1	Retainer Collar (1") (Includes Item # F413)	1
20	5270-1	Ball Bearing	2
21	1300-45	Rear Chassis	1
22	5420-3	Tail Wheel Fork	1
23	8769-12	Bearing Cup (1/2 ID)	2
24	5037-1	Bearing, Tail Wheel	2
25	5035-5	Tail Wheel & Tire Assembly (13 x 6.50-6) Black	1
	5035-1	Tail Wheel Tire (13 x 6.50-6)	*
	5036-1	Tail Wheel & Hub (6 x 4.5) Black	*
26	5038-1	Axle Spacer Tube (6-5/8)	1

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Deck Support Arm & Hitch Assemblies			
27	1431-1	Deck Support Arm, LH	1
28	5840-3	Bushing	2
29	7364-5	Torsion Spring, LH	1
30	1431-3	Deck Arm Latch, LH	1
31	1431-6	Deck Support Arm, RH	1
32	1431-4	Deck Arm Latch, RH	1
33	7364-4	Torsion Spring, RH	1
Fasteners			
	F002	10-24 Keps Nut	7
	F004	1/4-20 Keps Nut	17
	F009	5/16-18 Whiz Locknut	16
	F016	1/2-13 Self-Locking Nut	1
	F025	10-24 x 3/8 PPHMS	7
	F029	1/4-20 x 1/2 Hex Bolt	10
	F049	5/16 SAE Washer	6
	F108	3/8-16 x 2 Hex Bolt	2
	F179	1/4-20 x 1 Hex Bolt	1
	F182	1/4 x 5/8 x 1/8 Washer	2
	F194	7/16 x 1-1/4 x 1/8 Washer	2
	F226	5/16-18 x 7/8 Hex Bolt	6
	F292	1/2-13 x 8-1/2 Hex Bolt, Grade 5	1
	F333	1/4-20 x 3/4 PTHMS	6
	F350	1/4-20 LP Nylock	2
	F413	5/16-24 x 5/16 Set Screw	2
	F477	1/4-20 x 5/8 Carriage Bolt	2
	F570	3/8-16 Flange Top Lock Nut	2
	F621	7/16-20 Flange Top Lock Nut	2
	F632	7/16-20 x 1-1/2 Hex Bolt	2
	F637	Washer .835 x .505 x .125	2

* Service Part Only

BODY / CHASSIS ASSEMBLY



Model R22 Beginning S/N 196175
Use only genuine **Walker**® replacement parts.

MAIN COMPONENT POWER TRANSMISSION


PTO Drive Assembly

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
1	1300-23	Idler Mount	1
2	1410	Clutch	1
3	5245-2	Idler Pulley (2-3/4)	3
4	1410-2	Clutch Step Washer	1
5	7201-3	Fiberglide Bearing	2
6	5841	Retainer Washer (3/8 x 1-1/4)	2
7	5247-2	V-Groove Idler (4")	2
8	1300-21	Twin Idler Mount, LH	1
9	1010-3	Spacer (.750 x .375 x .5625)	2
10	7245-2	Idler Pulley	1
11	5830	Grease Fitting	1
12	1300-13	Tensioner Arm Assembly (Includes Items # 5 & 11)	1
13	7201-4	Inner Race (1-1/2)	1
14	1300-20	Twin Idler Mount, RH	1
15	1300-17	Tensioner Mount Assembly	1
16	1300-12	Tensioner Lever	1
17	5850-2	Handle Grip, Foam (5-1/2)	1
18	5221-4	Extension Spring (1 x 8)	1
19	1410-1	Clutch Stop	1

Fasteners

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
	F004	1/4-20 Keps Nut	2
	F009	5/16-18 Whiz Locknut	4
	F013	3/8-16 Whiz Locknut	6
	F031	1/4-20 x 5/8 Hex Bolt	2
	F032	1/4-20 x 3/4 Hex Bolt	4
	F034	5/16-18 x 3/4 Hex Bolt	2
	F040	3/8-16 x 1-1/2 Hex Bolt	2
	F049	5/16 SAE Washer	1
	F051	3/8 SAE Washer	10
	F091	5/16-18 x 5/8 Hex Bolt	2
	F111	1/8 x 3/4 Cotter Pin	1
	F170	5/16 x 1 x 7/64 Flat Washer (Zinc Plate)	2
	F393	3/8-16 x 3-1/4 Hex Bolt	1
	F438	5/16-18 x 2-3/4 Hex Bolt	2
	F551	5/16-18 Flange Top Lock Nut	2
	F569	1/4-20 Flange Top Lock Nut	4
	F626	7/16-20 x 2-1/2 Hex Bolt Grade 8	1
	F667	3/8-16 x 1-5/8 Hex Bolt	1

MAIN COMPONENT POWER TRANSMISSION



ENGINE GROUP


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Engine Assembly			
1	NS	22 HP Engine (Rehlko/Kohler)	1Δ
2	1013-8	Muffler	1
3	NS	Nut (Rehlko/Kohler)	4
Throttle Assembly			
4	M265	Insultherm (3/8 x 10)	1
5	1108-1	Throttle Cable (45")	1
6	5108-21	Control Bracket	1
7	5108-10	Friction Washer (.125)	2
8	5108-20	Control Lever, Throttle	1
9	5108-5	Throttle Control Knob, Red	1
Fuel Tank Assembly			
10	5879-3	Hose Clamp (1/2)	2
11	M246	Fuel Line (1/4 x 6")	1*
12	5020-3	Fuel Filter	1
13	M265	Insultherm (3/8 x 12)	1
14	M113	Fuel Line (3/16 x 31")	1*
15	5020-2	Fuel Filter, In Tank	1
16	M121	Fuel Line (1/4 x 6-1/2")	1*
17	6045-10	Fuel Tank, 3.0 Gallon (Includes Items # 15, 16 & 20-24)	1
18	5082-4	2-1/4 Rachet Fuel Cap (EPA)	1
19	5083-1	Bushing, Rubber	1
20	5083-7	Tank Tube (8-1/2")	1
21	6045-1	Fuel Tank Gauge	1
22	6045-3	Fuel Tank Gauge Grommet	1
23	5977-7	Roll Over Grommet (.900 x 1-1/2)	1
24	8043-8	Roll Over Valve	1

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Fasteners			
	F005	1/4-20 ESNA Nut	1
	F049	5/16 SAE Washer	2
	F184	1/4-20 x 1/2 Hex Bolt, SS	2
	F185	1/4 Internal Star Lock Washer, SS	2
	F278	3/8 Split Lock Washer	3
	F390	1/4-20 x 7/8 Carriage Bolt	1
	F496	M8 x 1.25 Nut	2
	F497	M8 x 1.25 x 20 Hex Bolt	2
	F596	3/8-16 x 1-1/8 Hex Bolt	3
	F631	3/8-16 x 1 Button Head Cap Screw	1
	F642	1/4 x .042 Belleville Washer	1

* **Required hose specifications:**
M113 - 3/16" ID fuel/oil/vapor hose
M121 - 1/4" ID submersible fuel hose
M246 - 1/4" ID low permeation fuel hose

Δ Replacement engines will require the use of forming 3/8-16 thread tap with F596 and F631.

ENGINE GROUP



† Apply Blue LOCTITE® # 242


HYDROSTATIC AND BRAKE ASSEMBLIES

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Ground Drive Assemblies			
1	4026-19	Fan & Pulley Kit (Includes Items 2 & 3)	2
2	1300-7	Hydro Pulley Fan	2
3	5025-19	Hydro Fan Nut	2
4	1250	Drive Belt	1
5	6240-24	Engine Pulley (3-1/2/A)	1
6	5103-2	Pivot Bushing (5/16 ID)	3
7	5025-24	Hydro-Gear EZT-2200, LH	1
8	2028-5	Lockout Arm, LH	1
9	4407-4	Bow Tie Cotter Pin	3
10	5026-24	Hydro-Gear EZT-2200, RH	1
11	2028-6	Lockout Arm, RH	1
12	5221	Extension Spring (3/4 x 4)	1
13	1300-6	Ground Drive Idler Arm	1
14	5245	Idler Pulley (3")	1
Parking Brake Assembly			
15	1406	Parking Brake Arm	1
16	5850-2	Handle Grip, Foam (5-1/2)	1
17	7410-1	Brake Control Cable, RH (36.5")	1
18	7523-3	Clevis Pin W/Hole (1/4 x 1/2)	1
19	1406-2	Parking Brake Clevis	2
20	7222	Extension Spring (1/4 x 3)	1
21	7409-1	Brake Control Cable, LH (31")	1
22	1406-3	Parking Brake Knuckle	1

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Wheel Assembly			
23	5075-8	LP Wheel & Tire Assembly (18 x 8.50-10) Black	2
	5075-2	LP Tire (18 x 8.50-10)	*
	5075-9	LP Wheel (10 x 7) Black	*
Fasteners			
	F005	1/4-20 ESNA Nut	1
	F009	5/16-18 Whiz Locknut	7
	F013	3/8-16 Whiz Locknut	5
	F015	1/2-20 Wheel Lug Nut	8
	F040	3/8-16 x 1-1/2 Hex Bolt	1
	F042	3/8-16 x 2-1/4 Hex Bolt	4
	F049	5/16 SAE Washer	7
	F051	3/8 SAE Washer	1
	F066	1/4 x 1/4 x 3/4 Key	1
	F072	1/4 "E" Retainer Ring	2
	F182	1/4 x 5/8 x 1/8 Washer	2
	F235	5/16-18 x 2-1/2 Hex Bolt	4
	F275	5/16-18 x 2 Hex Bolt	1
	F383	1/4-20 x 2 Shear Bolt, Grade 2	1
	F623	5/16-18 x 3-3/4 Hex Bolt	1
	F627	1/4-28 Nylock Jam Nut	2

* Service Part Only

HYDROSTATIC AND BRAKE ASSEMBLIES




STEERING CONTROL ASSEMBLIES

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Forward Speed Control Assemblies			
1	5850-2	Handle Grip, Foam (5-1/2)	3
2	1170-27	FSC Lever Weldment	1
3	4219-1	Extension Spring	1
4	8655-4	Clevis Pin (5/16 x 3/4)	2
5	4407-4	Bow Tie Cotter Pin	1
6	1170-1	FSC Link	2
7	4142-1	FSC Cam	1
8	5141	FSC Friction Washer (1-1/2 x 3/8 x 1/16)	2
Steering Lever Assemblies			
9	2212-3	Seal Retainer	2
10	1212-4	Transmission Control Arm	2
11	5214-4	Ball Joint (5/16-24) W/O Stud	2
12	2025-10	TWHCS 5/16-24 x 1.0 (Patch)	2
13	5213-5	Control Rod (17")	2
14	5665-1	Compression Spring (2-1/2)	2
15	5463-8	Pivot Bushing, SS (.5 x .313 x .350)	2
16	9704-4	Pivot Rod Bushing	2
17	5146	10mm Ball Stud	4
18	4199-3	Steering Lever Dampener Assembly	2
19	5463-7	Steering Lever Actuator	2
20	5463-6	Washer 5/16 x 3/4 x .250	2
21	1451-40	Steering Assembly	1
22	5222	Extension Spring (1/2 x 3-1/4)	2
23	5450	D-Clip	2
24	4452-6	Steering Pivot (1/4-20 x 1-5/8)	2
25	1452	Steering Lever Tube W/Tab	2
26	5453-14	Steering Lever Handle, Adjustable (Includes Items # 1, F050, F188 & F390)	2
27	7201-2	Fiberglide Bearing 1/2"	2
28	5463-5	Steering Arm Pivot Bushing (SS)	2
29	5830	Grease Fitting	2

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Fasteners			
	F004	1/4-20 Keps Nut	2
	F005	1/4-20 ESNA Nut	2
	F009	5/16-18 Whiz Locknut	4
	F010	5/16-24 ESNA Nut	2
	F020	5/16-18 ESNA Nut	2
	F024	5/16-24 Jam Nut	2
	F049	5/16 SAE Washer	6
	F050	1/4 SAE Washer	4
	F093	5/16-18 x 1 Hex Bolt	2
	F111	1/8 x 3/4 Cotter Pin	1
	F116	1/4-20 x 1-1/4 Hex Bolt	1
	F146	1/4-20 Jam Nut	1
	F183	.312 x .700 x .074 Washer	2
	F188	1/4-20 Self-Locking Nut	4
	F192	3/8-24 Self-Locking Nut	1
	F226	5/16-18 x 7/8 Hex Bolt	2
	F390	1/4-20 x 7/8 Carriage Bolt	4
	F392	1/4-20 x 1 Set Screw, SS Cup Point	1
	F407	Belleville Washer 3/8 x 1.187, SS	1
	F620	3/8-24 x 1-1/2 Hex Bolt	1
	F754	5/16-18 x 7/8 Button Head Cap Screw	2

STEERING CONTROL ASSEMBLIES



ELECTRICAL ASSEMBLY

Electrical Assembly


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
1	6940-18	Jumper Wire	1
2	5929	Starter Solenoid	1
3	8941	Circuit Breaker (30 Amp) Auto Reset/Sealed	1
4	6940-21	Ground Wire	1
5	6940-19	Jumper Wire	1
6	5942-8	Safety Switch (NO), Delta Side Mount	2
7	1910-1	Battery Hold Down	1
8	5910-6	Battery Spacer Pad	1
9	7910-3	Battery (12V/350A CCA)	1
10	5932	Battery Terminal Insulation Black (-)	1
11	5975-1	Cable Tie (18# x 3-3/4")	4
12	5933	Battery Terminal Insulation Red (+)	1
13	6941-9	Relay Switch 30/40 Amp	2
14	5832	Cable Clamp (1/2) .203 Hole	1
15	6833	Cable Clamp (9/16 x #10)	5
16	4950-11	PTO Switch Spacer	1
17	5942-20	Safety Switch (NO)	1
18	4950	PTO Switch	1
19	8990-1	Hourmeter (Global)	1
20	8960-15	Ignition Switch W/Keys (Includes Items # 21, 22 & F349)	1
21	7854	Plastic Tip, Red	1
22	8960-3	Key Set W/Umbrella	1
23	5103-12	Seat Switch	1*
24	1940	Wire Harness	1
25	8404-8	Plastic Cover, Red	2
26	4940-11	Jumper Wire	1

Fasteners


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
	F002	10-24 Keps Nut	11
	F004	1/4-20 Keps Nut	4
	F019	1/4-20 ESNA Wing Nut	1
	F025	10-24 x 3/8 PPHMS	4
	F026	10-24 x 1/2 PPHMS	7
	F029	1/4-20 x 1/2 Hex Bolt	2
	F031	1/4-20 x 5/8 Hex Bolt	2
	F050	1/4 SAE Washer	2
	F232	10-32 Keps Nut	2
	F349	Washer .835 ID 1.122 OD, SS	1
	F505	6-32 x 7/8 Hex Trim MS, SS	4
	F506	6-32 Nylock Nut	6
	F527	6-32 x 3/4 Hex Trim MS, SS	2
	F624	1/4-20 x 6 Carriage Bolt	1

* Replacement sensor for the integrated seat sensor.


ELECTRICAL ASSEMBLY



DETAIL A



DETAIL B



DETAIL C




DETAIL D



DETAIL E




DETAIL F




DETAIL G



DETAIL H



DETAIL I



DETAIL J



DETAIL K




LUBRICATION POINTS

ITEM NO.	PART NO.	DESCRIPTION		NO. REQ'D
Lubrication Points				
1		Steering Lever Pivot	Grease	2
2		Throttle Control Cable Ends	Oil	2
3		Engine Dipstick / Oil Fill	Oil*	1
4		Belt Tensioner Arm	Grease	1

* Refer to R22 **Operator's Manual** for procedure for checking and changing oil in Engine Crankcase.

NOTE: See Model R22 **Operator's Manual** (P/N 1000-14) for proper lubrication intervals.

LUBRICATION POINTS



WIRING SCHEMATIC

WALKER MODEL R22
Beginning S/N 2024-189149


RELAY - A	
IGNITION RELAY	
OFF	30 + 87A
START	30 + 87
RUN	30 + 87
PTO ON	30 + 87A

RELAY - B	
START RELAY	
OFF	30 + 87A
START	30 + 87
RUN	30 + 87
PTO ON	30 + 87A

PTO CLUTCH SWITCH	
OFF-PUSH	PUR + ORG BLK+BLK/WHT
ON-PULL	PUR+BRN+BRN/WHT

IGNITION SWITCH CIRCUITS	
OFF	G + M
START	B + A / S1 + S2
RUN	B + A

S1 = START CIRCUIT
S2 = START/ACCESSORY CIRCUIT
M = MAGNETO GROUND CIRCUIT
B = BATTERY CIRCUIT
A = ACCESSORY CIRCUIT
G = GROUND CIRCUIT



MAINTENANCE AND SERVICE RECORD SHEET

DATE	SERVICE ITEM	ENGINE HOURS

MAINTENANCE AND SERVICE RECORD SHEET

DATE	SERVICE ITEM	ENGINE HOURS

LIMITED WARRANTY
FOR
WALKER MODEL R22
RIDER MOWERS

1. WHAT THIS WARRANTY COVERS, AND FOR HOW LONG:

Walker Manufacturing company will, at its option, repair or replace, without charge, any part covered by this warranty which is found to be defective in material and/or workmanship within three (3) years or 300 hours whichever comes first after date of sale to the original retail purchaser. At Walker's request, customer will make the defective part available for inspection by Walker and/or return the defective part to Walker, transportation charges prepaid. All parts and components of the Walker Mower are covered by this warranty **except** the following components which are warranted separately by their respective manufacturers:

Rehlko/Kohler Engine

The available warranties covering these items are furnished with each mower. Walker does not assume any warranty obligation, liability or modification for these items, which are covered exclusively by the stated warranty of the respective manufacturers noted above.

The Fulbat battery comes with a one (1) year warranty from the date of sale to the original retail purchaser. Warranty claims for the battery are administered through Walker Manufacturing.

2. WHAT THIS WARRANTY DOES NOT COVER:

A. This warranty does not cover defects caused by depreciation or damage caused by normal wear, accidents, improper maintenance, improper use or abuse of the product, alterations, or failure to follow the instructions contained in the Owner's Manual for operation and maintenance.

B. The customer shall pay any charges for making service calls and/or for transporting the mower to and from the place where the inspection and/or warranty work is performed.

3. HOW TO OBTAIN SERVICE UNDER THIS WARRANTY:

Warranty service can be arranged by contacting the dealer where you purchased the mower or by contacting Walker Manufacturing Company, 5925 East Harmony Road, Ft. Collins, CO 80528. Proof of the date of purchase may be required to verify warranty coverage.


4. WARRANTY LIMITATION:

A. **THERE IS NO OTHER EXPRESS WARRANTY. ANY WARRANTY THAT MAY BE IMPLIED FROM THIS PURCHASE INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE IS HEREBY LIMITED TO THE DURATION OF THIS WARRANTY AND TO THE EXTENT PERMITTED BY LAW ANY AND ALL IMPLIED WARRANTIES ARE EXCLUDED.** Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

B. **WALKER WILL NOT BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES AND/OR EXPENSES IN CONNECTION WITH THE PURCHASE OR USE OF THE MOWER.** Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation(s) or exclusion(s) may not apply to you.

C. Only the warranty expressed in this limited warranty shall apply and no dealer, distributor, or individual is authorized to amend, modify, or extend this warranty in any way. Accordingly, additional statements such as dealer advertising or presentations, whether oral or written, do not constitute warranties by Walker, and should not be relied upon.

D. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.



WALKER MFG. CO. • 5925 E. HARMONY ROAD, FORT COLLINS, CO 80528 • (970) 221-5614
FORM NO. 110626 PRINTED IN USA www.walker.com
©2026 WALKER MFG. CO