




WALKER

Illustrated Parts Manual

H24d



Beginning S/N: 182266
P/N 2000-45

KEY TO ABBREVIATIONS USED IN THIS MANUAL

<i>Abbreviation</i>	<i>What it Represents</i>
° (Dimension)	Degrees (Angle)
" (Dimension)	inches
(-)	Negative (Polarity)
(+)	Positive (Polarity)
-1 (as deck style designation)	Standard (Aluminum) Gear Drive Deck
-2 (as deck style designation)	Heavy Duty (Cast Iron) Gear Drive Deck
-3 (as deck style designation)	Belt Drive Deck
AT	All-Terrain
CCW	Counter-clockwise
CW	Clockwise
D	Diameter
DC	Deck, Collection (number refers to size in inches)
DM	Deck, Mulching (number refers to size in inches)
DR	Deck, Rear Discharge (number refers to size in inches)
DS	Deck, Side Discharge (number refers to size in inches)
DU	Garlock (Bearing)
ESNA (Fastener)	Nylon Insert Locknut
FSC	Forward Speed Control
GA	Gauge
gal.	gallon
GR (Fastener)	Grade
HD	Heavy Duty
HP	Horse Power
ID	Identification or Inside Diameter
L	Length
LH	Left Hand (orientated with operator on seat)
LP	Low Profile
mm (Dimension)	millimeters
MS (Fastener)	Machine Screw
NS (as part number)	Item is not sold by Walker Manufacturing
OD	Outside Diameter
oz.	ounce
PFH (Fastener)	Phillips Flat Head
P/N	Part Number
PPH (Fastener)	Phillips Pan Head
PTH (Fastener)	Phillips Truss Head
PTO	Power Take-Off
QKS	Quick Slide
qt.	quart
RH	Right Hand (orientated with operator on seat)
ROPS	Roll-Over Protection System
SAE (Fastener)	Society of Automotive Engineers
SBH (Fastener)	Socket Button Head (Bolt)
SFH (Fastener)	Slotted Flat Head
SHC (Fastener)	Socket Head Cap
SHL (Fastener)	Shoulder (Bolt)
SM (Fastener)	Sheet Metal (Screw)
S/N	Serial Number
SQH (Fastener)	Square Head
SS (Fastener)	Stainless Steel
ST (Fastener)	Self-Tapping (Screw)
V	Volts
VLR	Very Low Restriction

NOTE: In some instances, combinations of abbreviations may be used (e.g. PPHMS - Phillips Pan Head Machine Screw).

ILLUSTRATED PARTS LIST


<i>Section of Tractor Covered</i>	<i>Page</i>	<i>Section of Tractor Covered</i>	<i>Page</i>
Decals		Electrical Components	
Tractor Decals	2	Electrical Assembly	20
Body / Chassis Assemblies		Maintenance	
Body Assembly	4	Lubrication Points	22
Chassis Assembly	6	Wiring Schematic	24
Tractor Components		Electrical Assembly (Connections)	25
Main Component Power Transmission	8	Maintenance And Service Record Sheet	26
Engine Group	10	Warranty	
Radiator Group	12	Limited Warranty	29
Hydrostatic Ground Drive Assemblies	14		
Steering Control Assemblies	16		
Roll-Over Protection System (ROPS)	18		

TRACTOR DECALS

ITEM NO.	PART NO.	DESCRIPTION	LOCATION	NO. REQ'D SD
Walker Product and Operation Decals				
1	2802-4	RH Fender	Body, RH near Seat	1
2	2010-17	Fuel Transfer	Transfer Mount, RH	1
3	5800-9	Decal, Walker Round (4-3/4")	Rear Body (one on each side)	2
4	2802-5	LH Fender	Body, LH near Seat	1
5	9804-1	Axle Lockout	Hydro Mount Plate	2
6	8821-6	Decal, H24d	Body	1
7	5856-1	Made in USA	Body	1
Danger Decals Warning Decals Caution Decals				
8	5685-3	Decal, ROPS	ROPS	1
9	8600-12	Danger, Engine Exhaust	Engine Brace	1
10	2107-5	Decal, Belt Routing	Rear Body, Underside	1
11	8600-2	Danger, Rotating Components	Coupling Guard	1
Maintenance Decals				
12	2427-9	Radiator Solution	Radiator	1
13	2807-9	Decal, Amp/Glow Plug	Body	1
14	6875	PTO Alignment Arrow	Universal Joint Tube Assembly	1

NOTE: All parts requiring decals are shipped with decals applied.


TRACTOR DECALS



BODY ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Body & Seat Assembly				Fasteners			
1	6103-14	Suspension Seat	1	F004	1/4-20 Keps Nut		13
2	M112	Edge Molding (16-3/8")	1	F005	1/4-20 ESNA Nut		2
3	8650-12	Bed Liner (23-5/16 x 25-3/8)	1	F009	5/16-18 Whiz Locknut		20
4	2650-2	Utility Bed (Includes Items # 2 & 3)	1	F020	5/16-18 ESNA Nut		3
5	7145	Gas Spring Assembly (Includes Items # 6 & 7)	1	F023	10-24 ESNA Nut		5
6	7147	Spring Clip	2	F029	1/4-20 x 1/2 Hex Bolt		4
7	7146	13mm Ball Stud	2	F035	5/16-18 x 1-1/4 Hex Bolt		2
8	7845-1	Rubber Bumper (1.375 x .750)	2	F049	5/16 SAE Washer		4
9	2105-13	Front Bed Support	1	F060	AN960516 Washer		2
10	5989-3	Dome Plug (5/16)	2	F084	5/16 Wave Spring Washer		2
11	5989-4	Dome Plug (3/8)	2	F091	5/16-18 x 5/8 Hex Bolt		4
12	6105-1	Shoulder Washer	2	F093	5/16-18 x 1 Hex Bolt		1
13	7844	Rubber Bumper (1.25 x .250)	2	F226	5/16-18 x 7/8 Hex Bolt		4
14	5146	10mm Ball Stud	2	F236	1/4-20 x 1-3/4 Hex Bolt		2
15	2145	Gas Spring	1	F246	1/4-20 x 1/2 PTHMS		4
16	5180	Edge Molding, Lever Opening	2	F341	Coil Roll Pin (7/64 x 9/16)		1
17	2504-4	Hinge (22.5)	1	F342	5/16 Conical Washer		2
18	2100-9	Front Body	1	F442	1/4-20 x 5/8 PTHMS		5
19	5989-55	Dome Plug (1/2)	1	F613	10-24 x 1/2 Truss Head Torx		5
20	7222	Extension Spring (1/4 x 3)	1	* Complete Tilt-Up Latch Assembly Kit available by ordering kit # 5744-5.			
21	2383	Body Latch Hook	1				
22	7854	Plastic Tip, Red	1				
23	6103-44	Grammer Seat Mount Channel, RH	1				
24	6103-45	Grammer Seat Mount Channel, LH	1				
25	4102-1	Body Guide, Upper	1				
Tilt-Up Latch Assembly*							
26	5847	Plastic Tip	1				
27	5744-20	Spring Arm, Tilt-Up Latch	1				
28	5744-10	Spring Pivot Bushing	1				
29	5744-15	Compression Spring (3/8 x 5/8)	1				
30	5744-13	Mount Angle, LH	1				
31	5744-12	Hook, Tilt-Up Latch	1				
32	5744-14	Mount Angle, RH	1				

BODY ASSEMBLY




Model H24d Beginning S/N 182266
Use only genuine **Walker®** replacement parts.

CHASSIS ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Chassis Assembly				Deck Support Arm & Hitch Assemblies			
1	2325-8	Belt Guide	1	24	2300-9	Deck Arm Support Mount	1
2	2046-1	Gas Tank Mount, LH	1	25	6840-1	Support Arm Bushing (2-1/16)	2
3	2301-8	Debris Guard	1	26	2775	Lynch Pin (5/16 x 1-1/4)	2
4	2301-9	Back-Up Plate	1	27	5830-1	5/16-24 4" Grease Fitting	2
5	2300-14	Chassis Frame	1	28	2431-2	Deck Support Arm, LH (Includes Item # 27)	1
6	2046	Gas Tank Mount	1	29	2430-2	Deck Support Arm, RH (Includes Item # 27)	1
7	4102-2	Body Guide, Lower	1	Fasteners			
Tail Wheel Assembly					F004	1/4-20 Keps Nut	6
8	5830	Grease Fitting	2		F009	5/16-18 Whiz Locknut	8
9	2300-10	Tail Wheel Pivot (Includes Items # 8, 11, 12 & 15)	1		F031	1/4-20 x 5/8 Hex Bolt	2
10	2201-2	Fiberglide Thrust Washer	2		F032	1/4-20 x 3/4 Hex Bolt	4
11	2201-3	Fiberglide Bearing (1-5/8)	2		F034	5/16-18 x 3/4 Hex Bolt	4
12	5830-4	Grease Fitting (90 Deg.)	1		F093	5/16-18 x 1 Hex Bolt	4
13	8769-8	Dust Cap, Deck Caster	2		F205	5/16-18 x 1/4 Set Screw (Knurl Point)	2
14	8769-6	Bearing Cone (1" ID)	4		F218	7/16 Split Lock Washer	5
15	8769-5	Bearing Cup (2 x 1-5/8)	4		F219	7/16-14 x 1-1/4 Hex Bolt	5
16	8769-7	Seal	2		F256	7/16 SAE Washer	1
17	2770	Caster Wheel Fork	2		F344	3/4-16 Slotted Hex Nut	2
18	8039	Nut, Wheel Axle	2		F348	1/8 x 1-1/2 Cotter Pin	2
19	8038-1	Spacer, Wheel Axle (.750 ID x 1.125 OD)	2		F430	7/16-20 ESNA Nut	2
20	8768-2	Seal, Reverse Lip	4		F446	7/16-20 x 3-1/2 Grd 8 Bolt	2
21	8037	Bearing Cone (3/4 ID)	4		F477	1/4-20 x 5/8 Carriage Bolt	2
22	8035-1	Wheel & Tire (13 x 4.50-6) (W/Bearing Race)	2		F639	Belleville Washer (1.5 x .755 x .072)	2
	8035-3	Tail Wheel Tire (13 x 4.5-6 Ply)	*	* Service Part Only			
23	7038	Wheel Axle (3/4 x 5-9/16)	2				

CHASSIS ASSEMBLY




MAIN COMPONENT POWER TRANSMISSION

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
PTO Drive Assembly				Fasteners			
1	4850	Handle Grip, Black	1	F004	1/4-20 Keps Nut		4
2	2358-1	Clutch Lever, MBS (Includes Items # 1 & 3)	1	F008	5/16-24 Keps Nut		1
3	5830-3	Grease Fitting (45 Deg.)	3	F009	5/16-18 Whiz Locknut		14
4	4303-7	Clutch Actuator Bolt (5/16)	1	F010	5/16-24 ESNA Nut		1
5	2306-2	Oilite Flanged Bushing	2	F012	3/8-16 Keps Nut		1
6	5830	Grease Fitting	2	F013	3/8-16 Whiz Locknut		3
7	2325-7	Clutch Arm (Includes Items # 5 & 6)	1	F019	1/4-20 ESNA Wing Nut		1
8	5221-1	Extension Spring (3/4 x 5)	1	F020	5/16-18 ESNA Nut		1
9	2358-11	Clutch Actuator	1	F029	1/4-20 x 1/2 Hex Bolt		1
10	5214-13	Ball Joint (3/8)	2	F031	1/4-20 x 5/8 Hex Bolt		5
11	2011-12	Flex Coupling Guard	1	F034	5/16-18 x 3/4 Hex Bolt		9
12	2358-9	Clutch Pivot Base	1	F035	5/16-18 x 1-1/4 Hex Bolt		2
13	2358-8	Adjustor Brace	1	F039	3/8-16 x 1-1/4 Hex Bolt		1
14	2302-16	Right Hand Shoe	1	F051	3/8 SAE Washer		2
15	2302-3	Left Hand Shoe	1	F060	AN960516 Washer		2
16	7775-6	Wire Lock Pin (2-1/2")	1	F061	1/4 Star Lock Washer		1
17	2349-17	Bearing Mount	1	F069	3/32 x 1/2 Cotter Pin		1
18	2406-5	Spacer	1	F091	5/16-18 x 5/8 Hex Bolt		1
19	2236-5	PTO Pulley (4.5/AAA)	1	F104	1/4-20 x 3/4 PFH Bolt		1
20	2359-1	Brake Band / Guard Mount	1	F120	AN960416 Washer		3
21	7775-8	Wire Lock Pin (4")	1	F146	1/4-20 Jam Nut		1
22	2302-5	PTO Shoe	1	F149	1/4 x 1/4 x 1-1/2 Key		1
23	7275-16	Universal Joint Tube Assembly / Spline	1	F168	5/16 Split Lock Washer		1
24	2274-10	PTO Drive Shaft Assembly	*	F170	5/16 x 1 x 7/64 Flat Washer (Zinc Plate)		1
25	2302-6	Shoe Mount, LH	1	F171	5/16-18 x 3/8 Set Screw		1
26	2302-17	Upper Shoe, LH	1	F178	1/4 x 1 Fender Washer		1
27	2358-7	Clutch / Pivot Stop	1	F182	1/4 x 5/8 x 1/8 Washer		3
28	7523-2	Clevis Pin W/Hole (1/4 x 5/8)	1	F183	.312 x .700 x .074 Washer		4
29	4359-2	Brake Band Link, Rear	1	F211	1/4-20 x 7/8 Hex Bolt		1
30	8304	Brake Band (14-1/2)	1	F217	7/16-14 Hex Nut		2
31	4359-1	Brake Band Link, Front	1	F218	7/16 Split Lock Washer		2
32	2410-2	Drive Shaft	1	F219	7/16-14 x 1-1/4 Hex Bolt		2
33	2265	Bearing (20mm)	4	F241	.375 x .875 x .10 Washer		1
34	2406-7	Pivot Shaft Spacer	1	F255	5/16-18 x 1-1/2 Hex Bolt		4
35	2236-1	Idler Pulley (4.5/AAA)	2	F298	3/8-24 Jam Nut		2
36	2230	Engine PTO Belt / Set (3)	1	F350	1/4-20 LP Nylock		5
37	2236-6	Pulley (Includes Items # F149 & F171)	1	F389	3/8-16 x 2-3/4 Hex Bolt		1
38	2236-4	Idler Pulley Shaft	1	F431	1/4-20 x 3-1/2 Hex Bolt		1
39	7201-3	Fiberglide Bearing	2	F435	1/4 x 1/4 x 1-1/4 Key		2
40	7201-9	Inner Race (5.324)	1	F450	Washer 5/8 x 1-3/4 x 1/4		1
41	2359-3	Clutch Idler Arm (Includes Items # 3 & 39)	1	F452	5/8-18 Nylon Locknut		1
42	2349-6	Flanged Bearing	1	F473	5/16-18 x 5 Hex Bolt		1
43	2358-12	Fiberglide Bushing	1	F476	3/8-16 x 6-1/2 Hex Bolt		1
44	7201-2	Fiberglide Bearing 1/2"	1	F477	1/4-20 x 5/8 Carriage Bolt		1
45	7377	Plastic Washer (1 x .438 x .025)	2	F484	Washer .380 ID x 1.0 OD x .120		2
46	7378	Pivot Bearing (7/16 x 9/16)	1	F551	5/16-18 Flange Top Lock Nut		4
47	5214-2	Ball Joint (5/16-24) (Nylon Lined)	1	F576	3/8-16 ESNA Wing Nut		1
48	7226	Compression Spring (3/4 x 2-1/2)	1	F581	1/4-20 x 1-1/4" Carriage Bolt		1
49	7380	Knuckle Joint	1	F642	1/4 x .042 Belleville Washer		2
				F651	5/16-18 x 5/8 Carriage Bolt Grd 2		4

* Service Part Only

MAIN COMPONENT POWER TRANSMISSION




Model H24d Beginning S/N 182266
Use only genuine **Walker®** replacement parts.

ENGINE GROUP

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Precleaner Assembly				46	NS	Fuel Line (Kohler)	1
1	4090-1	Air Cleaner Assembly (Includes Items # 2-5)	1	47	M246	Fuel Line (1/4 x 20")	1*
2	5090-2	Vacuator Valve	1	48	M246	Fuel Line (1/4 x 5")	1*
3	5088-5	Air Cleaner Draw Latch	2	49	2010-6	Fuel Valve	1
4	5090-8	Air Cleaner Cartridge	1	50	M246	Fuel Line (1/4 x 39")	1*
5	5090-7	Safety Filter Insert	1	51	M246	Fuel Line (1/4 x 39-1/2")	1*
6	5088-4	Air Cleaner Band	1	52	2010-2	Fuel Transfer Mount	1
7	5091-4	Indicator Nipple	1	53	M246	Fuel Line (1/4 x 11")	1*
8	5091-3	Air Flow Indicator	1	Throttle Assembly			
9	6029	Hose Clamp (1-13/16 to 2-3/4)	2	54	2108-6	Control Cable (73")	1
10	2012-5	Air Intake Hose	1	55	5108-1	Control Lever, Throttle / Choke	1
Engine Assembly				56	5108-5	Throttle Control Knob, Red	1
11	NS	Bolt (Kohler)	2	57	5108-11	Friction Washer (.062)	1
12	2437-3	Upper Engine Brace	1	58	2108-1	Throttle Control and Cable Assembly (Includes Items # 54-57, 59-62, F002, F005, F050, F164 & F642)	1
13	NS	Oil Filter	1**	59	5108-9	Control Bracket	1
14	2437-4	Engine Muffler Link	1	60	5108-10	Friction Washer (.125)	1
15	2013-2	Muffler	1	61	5108-7	Control Lock Tab	1
16	2013-13	Muffler Shield	1	62	5172	Bearing, Delrin (.250 ID x .375 OD x .250)	1
17	NS	Nut (Kohler)	2	Fasteners			
18	NS	Gasket (Kohler)	1	F002	10-24 Keps Nut		3
19	2437-1	Engine Mount, LH	1	F004	1/4-20 Keps Nut		2
20	7440-9	Motor Mount	4	F005	1/4-20 ESNA Nut		1
21	2437-2	Engine Mount, RH	1	F009	5/16-18 Whiz Locknut		6
22	NS	23.7 HP Engine (Kohler)	1	F012	3/8-16 Keps Nut		8
Fuel Tank Assembly				F013	3/8-16 Whiz Locknut		2
23	8055-4	Fuel Tank, 4.7 Gallon, Diesel (Black) (Includes Items # 25-30)	2	F025	10-24 x 3/8 PPHMS		2
24	7082-1	Fuel Tank Cap, Diesel	2	F031	1/4-20 x 5/8 Hex Bolt		2
25	5020-2	Fuel Filter, In Tank	2	F034	5/16-18 x 3/4 Hex Bolt		4
26	5086-7	Hose (1/4 x 6)	2	F038	3/8-16 x 1 Hex Bolt		2
27	5083-1	Bushing, Rubber	4	F050	1/4 SAE Washer		1
28	8055-2	Fuel Tank Gauge	2	F091	5/16-18 x 5/8 Hex Bolt		2
29	7046-1	Fuel Return Tube	2	F151	3/8-16 x 7/8 Hex Bolt		8
30	5083-8	Tank Tube (13")	2	F164	10-24 x 1/4 x 3/8 SHL Bolt		1
31	5879-3	Hose Clamp (1/2)	12	F184	1/4-20 x 1/2 Hex Bolt, SS		8
32	M246	Fuel Line (1/4 x 10")	1*	F185	1/4 Internal Star Lock Washer, SS		8
33	NS	Fuel Line (Kohler)	1	F198	.250 x .625 x .040 Washer, SS		4
34	NS	Fuel Line (Kohler)	1	F249	M10 Split Lock Washer		4
35	NS	Fuel Filter (Kohler)	1	F492	M12 Split Lock Washer		4
36	2437-5	Fuel Filter Mount	1	F493	M10-1.5 x 20 Hex Bolt		4
37	8043-10	1/4 x 3/16 Reducer Coupler	1	F494	M12-1.75 x 30 Hex Bolt		4
38	5879-4	Hose Clamp (7/16)	2	F642	1/4 x .042 Belleville Washer		1
39	M113	Fuel Line (3/16 x 4-1/2")	1*	* Required hose specifications:			
40	7840-4	Hose Clamp (3/4 to 1-1/2)	4	M113 - 3/16" ID fuel/oil/vapor hose (Gates 4219-0093 or equivalent)			
41	NS	Hose (Kohler)	1	M246 - 1/4" ID low permeation (<15g/m^2/day) fuel hose (Parker 38904 or equivalent)			
42	NS	Crankcase Vacuum Regulator Valve (Kohler)	1	** Refer to the Operator's Manual for recommended part number.			
43	NS	Hose (Kohler)	1				
44	5975-1	Cable Tie (18# x 3-3/4")	4				
45	NS	Fuel Line (Kohler)	1				


ENGINE GROUP



RADIATOR GROUP

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Radiator Assembly				Fasteners			
1	2427-5	Radiator	1	F002	10-24 Keps Nut		3
2	7427-21	Fan Mount Tab, LH	2	F004	1/4-20 Keps Nut		4
3	2425-3	Radiator Fan Shroud (Includes Item # F346)	1	F009	5/16-18 Whiz Locknut		12
4	7432	Shock Mount (1.0 OD x .75)	2	F025	10-24 x 3/8 PPHMS		3
5	7427-22	Fan Mount Tab, RH	2	F029	1/4-20 x 1/2 Hex Bolt		8
6	7429-6	Radiator Cooling Fan	*	F034	5/16-18 x 3/4 Hex Bolt		4
7	5841	Retainer Washer (3/8 x 1-1/4)	2	F061	1/4 Internal Star Lock Washer		8
8	7434	Washer (3/8 x 1-1/4 x 1/4)	4	F129	10-24 x 1/2 PTHMS		4
9	M204	Recovery Tank Hose (5/16 x 16-1/2")	1**	F360	1/4-20 x 3/8 Hex Bolt		4
10	2088-4	Air Cleaner Mount	1	F561	1/4 x 1-3/4 Fender Washer		2
11	2427-6	Recovery Tank Mount	1	* Service Part Only			
12	2427-2	Recovery Tank Keeper	1	** Required hose specifications: M204 - 5/16" ID 70 Durometer EPDM hose M247 - 5/16" ID low permeation (<15g/m ² /day) fuel hose (Parker 38905 or equivalent)			
13	7427-18	Coolant Recovery Tank	1				
14	7440-5	Shock Mount (1-1/4 x 3/4)	2				
15	2427	Radiator Mount	1				
16	7431-3	Radiator Channel Seal	2				
17	2425-2	Screen Channel	2				
18	7840-4	Hose Clamp (3/4 to 1-1/2)	4				
19	2012-3	Upper Radiator Hose	1				
20	7840-6	Hose Clamp (5/16 to 7/8)	2				
21	M247	Hose	1**				
22	2012-4	Lower Radiator Hose	1				
23	2425-1	Radiator Screen	1				
24	7429-7	Fan Blade Replacement	*				


RADIATOR GROUP



HYDROSTATIC GROUND DRIVE ASSEMBLIES

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Parking Brake Assembly				48	2026-41	Hydro-Gear ZT3400, RH	1
1	2358-6	5/16-18 x 1-3/4 Stud	2	Wheel Assembly			
2	2300-20	Parking Brake Hydro Mount, RH	1	49	2071	Wheel & Tire (22 x 10.50-12)	2
3	5103-2	Pivot Bushing (5/16 ID)	2		2071-4	AT Wheel & Tire (23 x 10.50-12)	**
4	2406-3	Parking Brake Actuator Tube	1	PTO Coupler			
5	5222	Extension Spring (1/2 x 3-1/4)	1	50	2351-1	Rubber Iso Coupler	6
6	2280	Clevis (3/8)	1	51	2351-45	Flex Coupler Half	1
7	2406-4	Clevis Pin (5/16 x 1-1/8)	1	52	2351-19	Inner Flex Coupler Half	1
8	8655-4	Clevis Pin (5/16 x 3/4)	1	53	2351-50	Flex Coupler Half (1" Bore)	1
9	2406-14	Brake Actuator Pull	1			(Includes Items # F171 & F435)	
10	4407-4	Bow Tie Cotter Pin	5	Fasteners			
11	5830	Grease Fitting	1		F002	10-24 Keps Nut	3
12	7406-1	Handle Grip, Red	1		F004	1/4-20 Keps Nut	2
13	2406-15	Parking Brake Lever / Idler Mount (Includes Items # 11 & 12)	1		F005	1/4-20 ESNA Nut	2
14	2406-5	Spacer	1		F009	5/16-18 Whiz Locknut	17
15	2300-1	Parking Brake Hydro Mount, LH	1		F010	5/16-24 ESNA Nut	2
16	7523-2	Clevis Pin W/Hole (1/4 x 5/8)	2		F012	3/8-16 Keps Nut	4
17	2406-10	Parking Brake Rod	2		F013	3/8-16 Whiz Locknut	7
18	5665-1	Compression Spring (2-1/2)	2		F015	1/2-20 Wheel Lug Nut	8
19	5463	Steering Lever Actuator	2		F025	10-24 x 3/8 PPHMS	3
Transaxle Reservoir Assemblies					F029	1/4-20 x 1/2 Hex Bolt	1
20	2025-17	Straight Thread Hose Fitting	2		F031	1/4-20 x 5/8 Hex Bolt	1
21	5879-4	Hose Clamp (7/16)	2		F032	1/4-20 x 3/4 Hex Bolt	2
22	M111	Hose (1/4 x 6-1/4")	2*		F034	5/16-18 x 3/4 Hex Bolt	18
23	5879-3	Hose Clamp (1/2)	4		F035	5/16-18 x 1-1/4 Hex Bolt	1
24	8043-9	1/4 x 1/4 x 1/4 Tee	1		F039	3/8-16 x 1-1/4 Hex Bolt	2
25	5832	Cable Clamp (1/2)	3		F040	3/8-16 x 1-1/2 Hex Bolt	1
26	2025-19	Hose Channel	1		F042	3/8-16 x 2-1/4 Hex Bolt	1
27	M111	Hose (1/4 x 14-1/2")	1*		F049	5/16 SAE Washer	1
28	2024-1	Oil Expansion Reservoir (1 Qt.)	1		F050	1/4 SAE Washer	2
29	2025-21	Reservoir Bottle Mount	1		F051	3/8 SAE Washer	2
Ground Drive Assemblies					F052	5/16 Ext. Star Lock Washer	12
30	2028-8	Lockout Arm, RH	1		F108	3/8-16 x 2 Hex Bolt	1
31	2248-1	Ground Drive Belt	1		F151	3/8-16 x 7/8 Hex Bolt	2
32	4245	Idler Pulley (3/A)	2		F168	5/16 Split Lock Washer	4
33	4349-12	Flange Bearing (1")	1		F171	5/16-18 x 3/8 Set Screw	3
34	2240-2	Drive Pulley (Includes Item # F171)	1		F182	1/4 x 5/8 x 1/8 Washer	4
35	5841	Retainer Washer (3/8 x 1-1/4)	1		F183	.312 x .700 x .074 Washer	4
36	5830-3	Grease Fitting (45 Deg.)	1		F231	1/4 x 3/4 Woodruff Key (#806)	1
37	2349-14	Transmission Belt Tensioner (Includes Items # 36 & 38)	1		F336	3/8-16 Jam Nut	1
38	7201-3	Fiberglide Bearing	2		F350	1/4-20 LP Nylock	2
39	7201-4	Inner Race (1-1/2)	1		F388	3/8-16 x 2-1/2 Hex Bolt	4
40	6325-3	Spacer Bushing (9/16)	1		F434	5/16-18 x 3-1/2 Hex Bolt	4
41	5146	10mm Ball Stud	2		F435	1/4 x 1/4 x 1-1/4 Key	1
42	2215-6	Pressure Dampener	1		F481	Washer 5/16 x 1 x .125	12
43	2028-7	Lockout Arm, LH	1		F497	M8 x 20 Hex Bolt	4
44	2026-6	Hydro-Gear® Oil Filter (52114)	2	* Required hose specifications:			
45	9430-1	Spacer Tube	4			M111 - 1/4" ID fuel/oil/vapor hose (Gates 4219-0103 or equivalent)	
46	2349-15	Idler Mount	1	** Service Part Only			
47	2025-41	Hydro-Gear ZT3400, LH	1				

HYDROSTATIC GROUND DRIVE ASSEMBLIES




Model H24d Beginning S/N 182266
Use only genuine **Walker®** replacement parts.

STEERING CONTROL ASSEMBLIES

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Steering Lever & FSC Assemblies				33	4142-1	FSC Cam	1
1	5850-2	Handle Grip, Foam (5-1/2)	3	34	5141	FSC Friction Washer (1-1/2 x 3/8 x 1/16)	1
2	4170-4	FSC Lever Assembly (Includes Item # 3)	*	35	4142-2	FSC Friction Washer (1-1/2 x 1-1/32 x 1/16)	1
3	5830	Grease Fitting	1	36	9704-3	Pivot Rod Bushing, Plastic	2
4	7201-11	Inner Race (1.938)	1	37	2451-4	Steering Shaft Spacer	1
5	5214-4	Ball Joint (5/16-24) W/O Stud	2	Fasteners			
6	4213-3	Control Rod (6-1/4)	1		F004	1/4-20 Keps Nut	2
7	5463-4	Steering Lever Actuator	2		F005	1/4-20 ESNA Nut	2
8	5665-1	Compression Spring (2-1/2)	2		F008	5/16-24 Keps Nut	2
9	2213	Control Rod (7")	2		F009	5/16-18 Whiz Locknut	6
10	2212-3	Seal Retainer	2		F010	5/16-24 ESNA Nut	2
11	2212	Transmission Control Arm Stop	2		F024	5/16-24 Jam Nut	4
12	2212-2	Transmission Control Arm, RH	1		F035	5/16-18 x 1-1/4 Hex Bolt	1
13	5214-2	Ball Joint (5/16-24) (Nylon Lined)	2		F044	5/16-24 x 3/4 Hex Bolt	2
14	2212-1	Transmission Control Arm, LH	1		F060	AN960516 Washer	1
15	2451-1	Steering Pivot Shaft With Stop	1		F093	5/16-18 x 1 Hex Bolt	2
16	5463-6	Washer 5/16 x 3/4 x .250	2		F121	5/16-18 x 3/8 x 1 SHL Bolt	1
17	7201-2	Fiberglide Bearing (1/2")	2		F146	1/4-20 Jam Nut	2
18	5463-5	Steering Arm Pivot Bushing (SS)	2		F167	5/16-18 Hex Nut	1
19	5830-3	Grease Fitting (45 Degree)	1		F183	.312 x .700 x .074 Washer	6
20	8201-3	Fiberglide Bearing	4		F188	1/4-20 Self-Locking Nut	4
21	2451-7	Speed Control Actuator, LH (Includes Items # 19 & 20)	1		F192	3/8-24 Self-Locking Nut	1
22	5146	10mm Ball Stud	4		F198	.250 x .625 x .040 Washer, SS	2
23	4199-4	Steering Lever Dampener Assembly	2		F211	1/4-20 x 7/8 Hex Bolt	1
24	2451-8	Speed Control Actuator, RH (Includes Items # 20 & 25)	1		F226	5/16-18 x 7/8 Hex Bolt	2
25	5830-4	Grease Fitting (90 Deg.)	1		F235	5/16-18 x 2-1/2 Hex Bolt	1
26	4451-4	FSC Friction Actuator	1		F345	1/4-20 x .770 Knurled Bolt	4
27	4219	Extension Spring (3/4 x 6-1/2)	1		F385	1/4 x 1-1/4 Roll Pin	1
28	5453-20	Steering Lever Handle (+1") Adjustable / SS (Includes Items # 1, F188, F198 & F345)	2		F391	1/4-20 x 1/2 Set Screw, SS	2
29	4452-4	Steering Lever Tube W/Tab	2		F407	Belleville Washer 3/8 x 1.187, SS	1
30	5450	D-Clip	2		F551	5/16-18 Flange Top Lock Nut	1
31	5222	Extension Spring (1/2 x 3-1/4)	2	* Service Part Only			
32	4452-6	Steering Pivot (1/4-20 x 1-5/8)	2				

STEERING CONTROL ASSEMBLIES




Model H24d Beginning S/N 182266
Use only genuine **Walker®** replacement parts.

ROLL-OVER PROTECTION SYSTEM (ROPS)


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
ROPS Assembly				Fasteners			
1	A30	ROPS	1	F151	3/8-16 x 7/8 Hex Bolt		4
2	2302-11	Stop Plate	1	F306	3/8-16 x 3/4 Hex Bolt		4
3	2302-10	Threaded Knob	2	F399	1/2-13 x 3-1/4 Hex Bolt		5
4	2302-9	Hinge Pin	2	F565	1/2-13 x 3-1/4 Hex Bolt, Grade 8		1
5	2302-8	ROPS Seat Belt, Grammer Seat	1	F566	1/2-13 Nut, HXCL Reversible Locking Nut		6
				F587	3/8-16 Top Lock Flange Nut, Grade G		8

ROLL-OVER PROTECTION SYSTEM (ROPS)



ELECTRICAL ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Electrical Assembly				29	5942-4	Safety Switch (NO)	1
1	6105-3	Harness Clip	3	30	5942-5	Safety Switch (NO)	1
2	5977-3	Grommet (9/16)	1	31	8960-15	Ignition Switch W/Keys (Includes Items # 39, 40 & F349)	1
3	2103-8	Adapter Harness	1	32	8536-2	Warning Horn Assembly	1
4	7306-11	Switch (205 Deg. 3/8-18 NPT)	1	33	8996-9	Red Indicator Light Assembly	3
5	6941-9	Relay Switch 30/40 Amp	6	34	8990-1	Hourmeter (Global)	1
6	NS	Glow Plug Controller / Timer (Kohler)	1	35	8996-13	Glow Plug Light Assembly, Green	1
7	7948-6	Time Delay Module	1	36	7941-3	Boot, Circuit Breaker	2
8	7948-2	Time Delay Harness	1	37	7941-2	Circuit Breaker (10 Amp)	1
9	5941-2	Safety Switch	1	38	7941-5	Circuit Breaker (7 Amp)	1
10	8941	Circuit Breaker (30 Amp) (Auto Reset/Sealed)	2	39	7854	Plastic Tip, Red	1
11	8440-3	Jumper Wire	2	40	8960-3	Key Set W/Umbrella	1
12	7941	Circuit Breaker (40 Amp) (Auto Reset/Sealed)	1	Fasteners			
13	7433-2	Resistor, 50 Watt .4 OHM 1%	1	F002	10-24 Keps Nut		26
14	7433-3	Resistor Mount	1	F004	1/4-20 Keps Nut		3
15	NS	Regulator/Rectifier (Kohler)	1	F009	5/16-18 Whiz Locknut		3
16	2940-9	Ground Wire (8")	1	F019	1/4-20 ESNA Wing Nut		2
17	2940-3	Battery Cable, 14" (-)	1	F025	10-24 x 3/8 PPHMS		2
18	7428-2	Fan Control Module W/P Plug	1	F026	10-24 x 1/2 PPHMS		24
19	5932	Battery Terminal Insl., Blk (-)	1	F029	1/4-20 x 1/2 Hex Bolt		1
20	5975-1	Cable Tie (18# x 3-3/4")	2	F031	1/4-20 x 5/8 Hex Bolt		2
21	4940-6	Battery Cable, 33" (+)	1	F034	5/16-18 x 3/4 Hex Bolt		3
22	5844	Battery Hold-Down Bar	1	F050	1/4 SAE Washer		2
23	5839	Hook Bolt	2	F145	4-40 Keps Nut		2
24	5933	Battery Terminal Insl., Red (+)	1	F182	1/4 x 5/8 x 1/8 Washer		2
25	NS	Battery (12V/350 CCA/Wet/SP-40)	1	F232	10-32 Keps Nut		6
26	2940-22	Wire Harness	1	F349	Washer .835 ID 1.122 OD, SS		1
27	7833	Cable Clamp (7/8 x 1/4)	2	F491	4-40 x 3/8 PPHMS		2
28	5833	Cable Clamp (1/4)	1				



NOTE: Electrical connections are identified on page 25.

LUBRICATION POINTS

ITEM NO.	LOCATION	LUBRICATION TYPE	NO. PLACES
----------	----------	------------------	------------

Lubrication Points

1	Steering Lever Pivot	Grease	2
2	Deck Support Arm Pivot	Grease	2
3	Deck-to-PTO Coupling (Grease Spline Slide Area)	Grease	1
4	Universal Joint Tube Assembly	Grease*	1
5	FSC Lever Pivot	Grease	1
6	Body Latch Pivot	Oil	2
7	PTO Clutch Lever Pivot	Grease	1
8	Clutch Arm Pivot	Grease	1
9	Hydro Idler Arm Pivot	Grease	1
10	Transaxle Oil Reservoir	Oil/20W-50	1
11	Throttle Control Cable Ends	Oil	2
12	Engine Dipstick	Oil**	1
13	Tail Wheel Caster Fork Pivot	Grease	2
14	Rear Axle Pivot	Grease	1

ITEM NO.	LOCATION	LUBRICATION TYPE	NO. PLACES
----------	----------	------------------	------------


15	Rear Wheel Bearing	Grease	2
16	Engine Oil Fill	Oil**	1
17	PTO Belt Tightener Idler Pivot	Grease	1
18	Clutch Actuator Push Rod	Grease	1
19	Brake Band Pivot Pins (Clevis)	Oil	2
20	Parking Brake Lever Pivot	Grease	1
21	Parking Brake Clevis	Oil	3
22	Throttle Control Pivot	Oil	1

* Grease every 25 hours.


** Refer to H24d **Operator's Manual** for procedure for checking and changing oil in Engine Crankcase.

NOTE: See Model H24d **Operator's Manual** (P/N 2000-34) for proper lubrication intervals.



LUBRICATION POINTS



WIRING SCHEMATIC



ELECTRICAL ASSEMBLY (CONNECTIONS)



MAINTENANCE AND SERVICE RECORD SHEET

[illegible]

MAINTENANCE AND SERVICE RECORD SHEET

[illegible]

MAINTENANCE AND SERVICE RECORD SHEET

[illegible]

LIMITED WARRANTY FOR WALKER MODEL H24d RIDER MOWER

1. WHAT THIS WARRANTY COVERS, AND FOR HOW LONG:

Walker Manufacturing company will, at its option, repair or replace, without charge, any part covered by this warranty which is found to be defective in material and/or workmanship within two (2) years* after the date of sale to the original retail purchaser unless the product is used for rental purposes, in which case this warranty is limited to ninety (90) days. At Walker's request, customer will make the defective part available for inspection by Walker and/or return the defective part to Walker, transportation charges prepaid. All parts and components of the Walker Mower are covered by this warranty **except** the following components which are warranted separately by their respective manufacturers:

Kohler Engine

Battery

The available warranties covering these items are furnished with each mower. Walker does not assume any warranty obligation, liability or modification for these items, which are covered exclusively by the stated warranty of the respective manufacturers noted above.

* Extended warranties are offered for the following powertrain components:

- A three (3) year or 3000 hour (whichever comes first) warranty is offered for Hydro-Gear ZT3400 Hydrostatic transaxle; covers full cost of replacement up to 1000 hours of use, and after 1000 hours warranty coverage is prorated against 3000 hours.

2. WHAT THIS WARRANTY DOES NOT COVER:


- A. This warranty does not cover defects caused by depreciation or damage caused by normal wear, accidents, improper maintenance, improper use or abuse of the product, alterations, or failure to follow the instructions contained in the Operator's Manual for operation and maintenance.
- B. The customer shall pay any charges for making service calls and/or for transporting the mower to and from the place where the inspection and/or warranty work is performed.

3. HOW TO OBTAIN SERVICE UNDER THIS WARRANTY:

Warranty service can be arranged by contacting the dealer where you purchased the mower or by contacting Walker Manufacturing Company, 5925 East Harmony Road, Ft. Collins, CO 80528. Proof of the date of purchase may be required to verify warranty coverage.

4. WARRANTY LIMITATION:

- A. **THERE IS NO OTHER EXPRESS WARRANTY. ANY WARRANTY THAT MAY BE IMPLIED FROM THIS PURCHASE INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE IS HEREBY LIMITED TO THE DURATION OF THIS WARRANTY AND TO THE EXTENT PERMITTED BY LAW ANY AND ALL IMPLIED WARRANTIES ARE EXCLUDED.** Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.
- B. **WALKER WILL NOT BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES AND/OR EXPENSES IN CONNECTION WITH THE PURCHASE OR USE OF THE MOWER.** Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation(s) or exclusion(s) may not apply to you.
- C. Only the warranty expressed in this limited warranty shall apply and no dealer, distributor, or individual is authorized to amend, modify, or extend this warranty in any way. Accordingly, additional statements such as dealer advertising or presentations, whether oral or written, do not constitute warranties by Walker, and should not be relied upon.
- D. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.



WALKER

WALKER MFG. CO. • 5925 E. HARMONY ROAD, FORT COLLINS, CO 80528 • (970) 221-5614
FORM NO. 082223 PRINTED IN USA www.walker.com ©2023 WALKER MFG. CO