




WALKER

Illustrated Parts Manual

S18



Beginning S/N: 153873
P/N 5000-51

KEY TO ABBREVIATIONS USED IN THIS MANUAL

<i>Abbreviation</i>	<i>What it Represents</i>
° (Dimension)	Degrees (Angle)
" (Dimension)	inches
(-)	Negative (Polarity)
(+)	Positive (Polarity)
AT	All-Terrain
CCW	Counter-clockwise
Conn.	Connector
CW	Clockwise
D	Diameter
DC	Deck, Collection (number refers to size in inches)
DM	Deck, Mulching (number refers to size in inches)
DR	Deck, Rear Discharge (number refers to size in inches)
DS	Deck, Side Discharge (number refers to size in inches)
DU	Garlock (Bearing)
ESNA (Fastener)	Nylon Insert Locknut
FSC	Forward Speed Control
GA	Gauge
gal.	gallon
GHS	Grass Handling System
GR (Fastener)	Grade
HD	Heavy Duty
HP	Horse Power
ID	Identification or Inside Diameter
L	Length
LH	Left Hand (orientated with operator on seat)
LP	Low Profile
mm (Dimension)	millimeters
MS (Fastener)	Machine Screw
NS (as part number)	Item is not sold by Walker Manufacturing
OD	Outside Diameter
oz.	ounce
PFH (Fastener)	Phillips Flat Head
P/N	Part Number
PPH (Fastener)	Phillips Pan Head
PTH (Fastener)	Phillips Truss Head
PTO	Power Take-Off
QKS	Quick Slide
qt.	quart
RH	Right Hand (orientated with operator on seat)
SAE (Fastener)	Society of Automotive Engineers
SBH (Fastener)	Socket Button Head (Bolt)
SFH (Fastener)	Slotted Flat Head
SHC (Fastener)	Socket Head Cap
SHL (Fastener)	Shoulder (Bolt)
SM (Fastener)	Sheet Metal (Screw)
S/N	Serial Number
Spg.	Spring
SQH (Fastener)	Square Head
SS (Fastener)	Stainless Steel
ST (Fastener)	Self-Tapping (Screw)
Term.	Terminal
V	Volts

NOTE: In some instances, combinations of abbreviations may be used (e.g. PPHMS - Phillips Pan Head Machine Screw).

ILLUSTRATED PARTS LIST

<i>Section of Tractor Covered</i>	<i>Page</i>
Decals	
Tractor Decals	2
Body / Chassis Assemblies	
Body / Chassis Assembly	4
Rear Body Assembly	6
Tractor Components	
Main Component Power Transmission	8
Engine Group	10
Hydrostatic Ground Drive Assemblies.....	12
Steering Control Assemblies.....	14
GHS Group	16
GHS Powerfil® Assembly (7.0)	18
GHS 7.0 Bushel Catcher Assembly.....	20


<i>Section of Tractor Covered</i>	<i>Page</i>
Electrical Components	
Electrical Assembly	22
Electrical Assemblies (GHS 7.0 Bushel Components).....	24
Electrical Connectors.....	26
Maintenance	
Lubrication Points	28
Wiring Schematic	30
Maintenance And Service Record Sheet.....	31
Warranty	
Limited Warranty	33

TRACTOR DECALS

ITEM NO.	PART NO.	DESCRIPTION	LOCATION	NO. REQ'D GHS
Walker Product Decals				
1	5800-11	Walker (8" Round)	7.0 Bushel Catcher (one on each side)	2
2	5813-2	Decal, 4" Grass-Pak Powerfil®	Powerfil® Cover Plate	1
3	9804-1	Axle Lockout	Chassis	2
4	8600-44	LH Fender	Body, LH near Seat	1
5	8821-21	Decal, S18	Body	1
6	5856-1	Made in USA	Body	1
7	8600-45	RH Fender	Body, RH near Seat	1
Danger Decals Warning Decals Caution Decals				
8	8600-10	Danger, Pinch Point	7.0 Bushel Catcher Mounting Frame Assembly (one on each side)	2
9	8600-12	Danger, Engine Exhaust	Engine	1
10	8600-4	Danger, Rotating Blower Blades	Body, Near Body Chute	1
Maintenance Decals				
11	5869	Removable Screen	7.0 Bushel Catcher Removable Screen	1
12	6875	PTO Alignment Arrow	Universal Joint Tube Assembly	1

NOTE: All parts requiring decals are shipped with decals applied.


TRACTOR DECALS



BODY / CHASSIS ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Seat Assembly				Deck Support Arm & Hitch Assemblies			
1	5103	Seat	1	41	5830	Grease Fitting	2
2	7223-4	Compression Spring	2	42	6840-1	Support Arm Bushing (2-1/16)	2
3	5841-1	Retainer Washer	4	43	6431-5	Deck Arm Mount	2
4	7434	Washer (3/8 x 1-1/4 x 1/4)	2	44	6431-9	Deck Arm Support, LH (Includes Item # 41)	1
5	7845-1	Rubber Bumper (1.375 x .750)	2	45	5775-2	Hitch Pin (#6)	2
6	7440-5	Shock Mount (1-1/4 x 3/4)	2	46	5303-5	Deck Arm Hydro Mount, LH	1
Rear Bumper Assembly				47	5303-6	Deck Arm Hydro Mount, RH	1
7	7516-5	Catcher Pivot Bushing	2	48	6431-8	Deck Arm Support, RH (Includes Item # 41)	1
8	5517-6	Rear Bumper	1	Fasteners			
9	7517-3	Catcher Pivot Plate	2	F002	10-24 Keps Nut		2
10	5162	Roller Wheel (5" Rubber)	2	F004	1/4-20 Keps Nut		14
Body Assembly				F005	1/4-20 ESNA Nut		1
11	2505	Leaf Spring	1	F009	5/16-18 Whiz Locknut		26
12	5100-17	Welded Body	1	F013	3/8-16 Whiz Locknut		2
13	4102-1	Body Guide, Upper	1	F014	3/8-16 ESNA Nut		2
14	7844	Rubber Bumper (1.25 x .250)	2	F016	1/2-13 Self-Locking Nut		1
15	NS	Body ID Plate	1	F020	5/16-18 ESNA Nut		1
16	5180	Edge Molding, Lever Opening	2	F025	10-24 x 3/8 PPHMS		2
17	4504-3	Hinge (19")	1	F029	1/4-20 x 1/2 Hex Bolt		4
Tilt-Up Latch Assembly**				F034	5/16-18 x 3/4 Hex Bolt		14
18	5847	Plastic Tip	1	F038	3/8-16 x 1 Hex Bolt		2
19	5744-20	Spring Arm, Tilt-Up Latch	1	F041	3/8-16 x 1-3/4 Hex Bolt		2
20	5744-10	Spring Pivot Bushing	1	F042	3/8-16 x 2-1/4 Hex Bolt		2
21	5744-15	Compression Spring (3/8 x 5/8)	1	F049	5/16 SAE Washer		8
22	5744-13	Mount Angle, LH	1	F053	7/16 Int. Star Lock Washer		2
23	5744-12	Hook, Tilt-Up Latch	1	F059	3/8 Wave Spring Washer		2
24	5744-14	Mount Angle, RH	1	F093	5/16-18 x 1 Hex Bolt		1
Chassis Assembly				F116	1/4-20 x 1-1/4 Hex Bolt		1
25	9046	Gas Tank Mount	1	F151	3/8-16 x 7/8 Hex Bolt		2
26	5300-17	Chassis Frame	1	F183	.312 x .700 x .074 Washer		2
27	5267-1	Retainer Collar (1") (Includes Item # F413)	1	F200	7/16-20 x 3 Grade 8 Bolt		2
28	5270-1	Ball Bearing	2	F206	#2 x 3/16 Drive Pin		2
29	5420-2	Tail Wheel Fork	1	F227	3/8 x 1-1/4 x 1/8 Washer		2
30	8769-12	Bearing Cup (1/2 ID)	2	F241	.375 x .875 x .10 Washer		4
31	5037-1	Bearing, Tail Wheel	2	F246	1/4-20 x 1/2 PTHMS		8
32	5035	Tail Wheel & Tire Assembly (13 x 6.50-6)	1	F257	3/8 x 1-11/16 Shoulder Bolt		2
	5035-1	Tail Wheel Tire (13 x 6.50-6)	*	F292	1/2-13 x 8-1/2 Hex Bolt, GR 5		1
	5036	Tail Wheel & Hub (6 x 4.5)	*	F341	Coil Roll Pin (7/64 x 9/16)		1
33	5038-1	Axle Spacer Tube (6-5/8)	1	F342	5/16 Conical Washer		2
34	6390-4	Battery Guard	1	F413	5/16-24 x 5/16 Set Screw		2
35	5146	10mm Ball Stud	2	F438	5/16-18 x 2-3/4 Hex Bolt		4
36	5145-4	Gas Spring Assembly (Includes Item # 35)	1	F477	1/4-20 x 5/8 Carriage Bolt		2
37	7383-1	Body Latch Hook	1	F570	3/8-16 Flange Top Lock Nut		4
38	7854	Plastic Tip, Red	1	F630	Washer .835 x .505 x .080		2
39	7222	Extension Spring (1/4 x 3)	1	* Service Part Only			
40	4102-2	Body Guide, Lower	1	** Complete Tilt-Up Latch Assembly Kit available by ordering kit # 5747.			

BODY / CHASSIS ASSEMBLY



Beginning S/N 153873
Use only genuine **Walker®** replacement parts.

REAR BODY ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
-------------	-------------	-------------	--------------

Rear Body Assembly

1	6832	Cable Clamp (9/16 x 1/4)	2
2	5100-13	Rear Body Tie-In	1
3	5100-11	Rear Body Panel, LH	1
4	5100-12	Rear Body Panel, RH	1
5	5977-8	Grommet (1 x 1-3/4)	1
6	8515-14	Catcher Handle Plate, RH	1
7	8515-13	Catcher Handle Plate, LH	1
8	7147	Spring Clip	2
9	7146	13mm Ball Stud	2
10	7145	Gas Spring Assembly (Includes Items # 8 & 9)	1
11	6515	Catcher Support Frame	1


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
-------------	-------------	-------------	--------------

Fasteners

F002	10-24 Keps Nut	2
F009	5/16-18 Whiz Locknut	10
F025	10-24 x 3/8 PPHMS	2
F031	1/4-20 x 5/8 Hex Bolt	1
F032	1/4-20 x 3/4 Hex Bolt	2
F034	5/16-18 x 3/4 Hex Bolt	8
F390	1/4-20 x 7/8 Carriage Bolt	2
F569	1/4-20 Flange Top Lock Nut	5

NOTE: Rear Bumper Assembly for GHS Models is not shown here.
Refer to **BODY / CHASSIS ASSEMBLY**, Page 4.


REAR BODY ASSEMBLY



MAIN COMPONENT POWER TRANSMISSION

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
PTO Drive Assembly				44	6243-5	Hub, Idler Pulley	1
1	4850	Handle Grip, Black	1	45	5270	Bearing W/Collar (1")	1
2	6358-29	Clutch Lever	1	46	6273-3	Jackshaft (1 x 12-13/16)	1
3	5830	Grease Fitting	2	47	6394-4	Jackshaft Bearing Housing	1
4	4303-7	Clutch Actuator Bolt (5/16)	1	48	6273-4	Bearing (7/8")	1
5	7380	Knuckle Joint	1	Blower Brake Assembly			
6	5830-4	Grease Fitting (90 Degree)	1	49	7523-2	Clevis Pin W/Hole (1/4 x 5/8)	1
7	2358-6	5/16-18 x 1-3/4 Stud	2	50	8304	Brake Band (14-1/2)	1
8	5103-2	Pivot Bushing (5/16 ID)	2	51	4359-1	Brake Band Link, Front	2
9	6325-5	Clutch Arm	1	Fasteners			
10	7377	Plastic Washer (1 x .438 x .025)	2	F004	1/4-20 Keps Nut		9
11	7378	Pivot Bearing (7/16 x 9/16)	1	F005	1/4-20 ESNA Nut		1
12	5214-3	Ball Joint (5/16-24LH) (Nylon Lined)	1	F009	5/16-18 Whiz Locknut		11
13	6325-6	Clutch Arm Support Bracket	1	F010	5/16-24 ESNA Nut		3
14	6410-3	Clutch Pull Rod 8-5/8	1	F012	3/8-16 Keps Nut		1
15	5214-2	Ball Joint (5/16-24) (Nylon Lined)	1	F013	3/8-16 Whiz Locknut		3
16	5221	Extension Spring (3/4 x 4)	1	F019	1/4-20 ESNA Wing Nut		2
17	5214-4	Ball Joint (5/16-24) W/O Stud	1	F024	5/16-24 Jam Nut		2
18	5226-1	Spring (3/4 x 2-1/2)	1	F029	1/4-20 x 1/2 Hex Bolt		1
19	6325-10	Spacer / Stop (3/8 x 7/8 x 1/2)	1	F031	1/4-20 x 5/8 Hex Bolt		6
20	5247-2	V-Groove Idler (4")	1	F034	5/16-18 x 3/4 Hex Bolt		6
21	5234-7	PTO Drive Belt (B31-K)	1	F035	5/16-18 x 1-1/4 Hex Bolt		1
22	5238-22	PTO Drive Pulley (5/B)	1	F038	3/8-16 x 1 Hex Bolt		1
23	5830-3	Grease Fitting (45 Degree)	1	F040	3/8-16 x 1-1/2 Hex Bolt		1
24	6358-4	PTO / Clutch / Brake Actuator (Includes Items # 23 & 28)	1	F041	3/8-16 x 1-3/4 Hex Bolt		1
25	5300-11	Guide Top	1	F042	3/8-16 x 2-1/4 Hex Bolt		2
26	5300-12	Belt Guide Base	1	F050	1/4 SAE Washer		2
27	6358-5	PTO / Clutch / Brake Support	1	F051	3/8 SAE Washer		1
28	7201-3	Fiberglide Bearing	4	F054	AN960616 Washer		2
29	7201-5	Inner Race (2-1/4)	1	F060	AN960516 Washer		2
30	5303-3	Belt Guide Mount	1	F061	1/4 Star Lock Washer		1
Engine Belt Tightener Assembly				F063	3/8 Int. Star Lock Washer		2
31	6394-5	Jackshaft Washer	1	F067	3/16 x 3/16 x 1 Key		2
32	5240-3	Compound Pulley, 4B	1	F069	3/32 x 1/2 Cotter Pin		1
33	4230-1	Engine / PTO Belt	1	F070	1-3/4 Internal Snap Ring		1
34	9051	Washer (5/16 x 1-3/8)	2	F106	3/8-16 x 5/8 Hex Bolt		2
35	5841	Retainer Washer (3/8 x 1-1/4)	2	F171	5/16-18 x 3/8 Set Screw		2
36	5237-3	Engine Pulley (4.25 / AA)	1	F178	1/4 x 1 Fender Washer		1
37	4245-1	Idler Pulley (4 / Flat)	1	F183	.312 x .700 x .074 Washer		1
38	5221-1	Extension Spring (3/4 x 5)	1	F187	1/4-20 x 1-1/2 Hex Bolt		1
39	7201-4	Inner Race (1-1/2)	1	F241	.375 x .875 x .10 Washer		1
40	6345-5	Idler Arm (Includes Items # 3 & 28)	1	F350	1/4-20 LP Nylock		1
41	6325-3	Spacer Bushing (9/16)	1	F373	5/16-24 Hex Nut, LH		1
42	6245-2	Idler Pulley (4.5 / AA)	1	F393	3/8-16 x 3-1/4 Hex Bolt		1
43	5265-20	Bearing (3/4)	1	F477	1/4-20 x 5/8 Carriage Bolt		2
				F595	5/16-18 x 7/8 Hex Bolt Grade 8		1

MAIN COMPONENT POWER TRANSMISSION



ENGINE GROUP


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Fuel Tank Assembly				Throttle and Choke Assemblies			
1	5082-4	2-1/4 Ratchet Fuel Cap	1	36	8108-4	Control Cable (58"), Throttle	1
2	8055-2	Fuel Tank Gauge	1	37	5122-3	Control Cable (58"), Choke	1
3	M246	Fuel Line, Tank to Filter (1/4 x 8-1/2")	1**	38	5108-1	Control Lever, Throttle and Choke	2
4	5879-3	Hose Clamp (1/2)	3	39	5108-5	Throttle Control Knob, Red	1
5	5083-8	Tank Tube (13")	1	40	5108-11	Friction Washer (.062)	1
6	8043-8	Roll Over Valve	1	41	5108-6	Choke Control Knob, Black	1
7	5083-1	Bushing, Rubber (Fits 5083)	1	42	7108	Control Assembly, Throttle and Choke (Includes Items # 38, 40, 43-45 & F201)	*
8	5977-7	Roll Over Grommet (.900 x 1-1/2)	1		2108-2	Throttle Control and Cable Assembly (Complete Control and Cable Assembly)	*
9	5020	Fuel Filter	1		5121-3	Choke Control and Cable Assembly (Complete Control and Cable Assembly)	*
10	5975-3	Cable Tie (#50 x 7")	3				
11	4010-5	3/8 NPT Street L	1	43	5108-8	Control Bracket	2
12	7833-2	Cable Clamp (1 x 1/4)	2	44	5108-10	Friction Washer (.125)	1
13	M246	Fuel Line, Filter to Engine (1/4 x 21")	1**	45	5108-7	Control Lock Tab	2
14	M113	Fuel Line (3/16 x 26")	1**	46	5172	Bearing, Delrin (.250 x .375 x .250)	2
15	5086-7	Hose (1/4 x 6)	1	Fasteners			
16	5020-2	Fuel Filter, In Tank	1				
17	6055-2	Fuel Tank, 4.0 Gal. Gas (Black) (Includes Items # 2, 5, 6, 8, 15 & 16)	1	F002	10-24 Keps Nut		6
Engine Assembly				F004	1/4-20 Keps Nut		4
18	5303-11	Engine Support Brace	1	F005	1/4-20 ESNA Nut		2
19	4104-9	Heat Shield, Aluminum	1	F009	5/16-18 Whiz Locknut		9
20	NS	18 HP Engine (Briggs & Stratton)	1	F025	10-24 x 3/8 PPHMS		4
21	5013-16	Exhaust Clamp (1-1/4")	1	F034	5/16-18 x 3/4 Hex Bolt		5
22	5013-13	Muffler Pipe Extension	1	F049	5/16 SAE Washer		1
23	6545-3	Engine Pulley Washer	2	F050	1/4 SAE Washer		4
24	5270-1	Ball Bearing	1	F115	#8 SAE Washer		2
25	5237-4	Engine Pulley Bushing	1	F164	10-24 x 1/4 x 3/8 SHL Bolt		2
26	5237-5	Engine Pulley Mount Plate	1	F183	.312 x .700 x .074 Washer		4
Precleaner Assembly				F184	1/4-20 x 1/2 Hex Bolt, SS		2
27	6029	Hose Clamp (1-3/4 to 2-1/4)	2	F185	1/4 Internal Star Lock Washer, SS		2
28	6087-7	Air Intake Hose	1	F201	1/4 Belleville Spring Washer		4
29	2090-21	Air Cleaner Assembly (Includes Items # 32-35)	1	F316	5/16-18 x 1-3/4 Hex Bolt		4
30	5088-15	1/8" Female NPT Brass Cap	1	F328	M6 x 1.0 x 16 Hex Bolt		2
31	7854-1	Plastic Tip, Black (.218 ID)	1	F392	1/4-20 x 1 Set Screw, SS (Cup Point)		2
32	5088-3	Air Cleaner Band	1	F435	1/4 x 1/4 x 1-1/4 Key		1
33	2090-3	Safety Filter Insert	1	F467	2" Internal Snap Ring		1
34	2090-1	Air Cleaner Cartridge	1	F481	Washer 5/16 x 1 x .125		1
35	2088-2	Air Cleaner Cap	1	F497	M8 x 20 Hex Bolt		1
				F572	3/8-24 x 5/8 SFH Cap Screw		2
				F573	3/8-24 x 1-1/4 SFH Cap Screw		1
				* Service Part Only			
				** Required hose specifications:			
				M113 - 3/16" ID fuel/oil/vapor hose (Gates 4219-0093 or equivalent)			
				M246 - 1/4" ID low permeation (<15g/m^2/day) fuel hose (Parker 38904 or equivalent)			

[illegible]

HYDROSTATIC GROUND DRIVE ASSEMBLIES

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Transaxle Reservoir Assembly				40	6406-4	Parking Brake Pull Mount, Inner	2
1	2025-1	Oil Expansion Reservoir (71327)	1	41	6406-5	Parking Brake Pull Mount, Outer	2
2	4025-2	Reservoir Bottle Mount	1	42	5665-1	Compression Spring (2-1/2)	2
3	5879-8	Hose Clamp (13/16)	3	43	5222	Extension Spring (1/2 x 3-1/4)	2
4	2025-8	Reservoir Bottom Caps	1	44	5942-19	Parking Brake Safety Switch Mount	1
5	4025-3	Elbow (1/4 x 1/2)	1	45	2406-4	Clevis Pin (5/16 x 1-1/8)	1
6	5879-3	Hose Clamp (1/2)	4	46	6406-3	Parking Brake Actuator	1
7	M111	Hose (1/4 x 14")	1**	Wheel Assembly			
8	2025-17	Straight Thread Hose Fitting	2	47	5075-3	LP Wheel & Tire Assembly (18 x 8.50-10)	2
9	5879-4	Hose Clamp (7/16)	2		5075-2	LP Tire (18 x 8.50-10)	*
10	M111	Hose (1/4 x 6-5/8")	1**		5075-5	LP Wheel (10 x 7)	*
11	8043-9	1/4 x 1/4 x 1/4 Tee	1	Fasteners			
12	M111	Hose (1/4 x 1-5/8")	1**		F002	10-24 Keps Nut	2
13	7364-9	Reservoir Hose Guide	1		F004	1/4-20 Keps Nut	7
14	5087-1	Hose (1/2 x 1-3/4)	1		F005	1/4-20 ESNA Nut	2
Ground Drive Assemblies					F009	5/16-18 Whiz Locknut	6
15	5026-21	Hydro-Gear ZT3100, RH	1		F013	3/8-16 Whiz Locknut	5
16	2028-6	Lockout Arm, RH	1		F015	1/2-20 Wheel Lug Nut	8
17	4407-4	Bow Tie Cotter Pin	3		F020	5/16-18 ESNA Nut	2
18	7364-3	Idler Spring Bushing	1		F025	10-24 x 3/8 PPHMS	2
19	7364-2	Torsion Spring	1		F029	1/4-20 x 1/2 Hex Bolt	1
20	5025-18	Hydro Fan Washer	2		F031	1/4-20 x 5/8 Hex Bolt	7
21	5025-17	Hydro Fan	2		F032	1/4-20 x 3/4 Hex Bolt	2
22	7244-22	Hydro Pulley (4.075) Splined	2		F034	5/16-18 x 3/4 Hex Bolt	2
23	5025-19	Hydro Fan Nut	2		F041	3/8-16 x 1-3/4 Hex Bolt	1
24	7241-2	Transmission Drive Pulley (3-1/4MV) (Includes Items # F067 & F171)	1		F042	3/8-16 x 2-1/4 Hex Bolt	2
25	5232-1	Ground Drive Belt (Micro V)	1		F050	1/4 SAE Washer	2
26	5245-1	Idler Pulley	1		F067	3/16 x 3/16 x 1 Key	1
27	6325-2	Spacer Bushing (5/16)	1		F069	3/32 x 1/2 Cotter Pin	5
28	6345-4	Idler Arm	1		F129	10-24 x 1/2 PTHMS	6
29	2028-5	Lockout Arm, LH	1		F171	5/16-18 x 3/8 Set Screw	2
30	5025-21	Hydro-Gear ZT3100, LH	1		F182	1/4 x 5/8 x 1/8 Washer	2
31	9430-1	Spacer Tube	4		F183	.312 x .700 x .074 Washer	2
32	6215	Shock Mount / Body Lift Arm (Includes Item # 22)	1		F336	3/8-16 Jam Nut	1
33	5830	Grease Fitting	2		F388	3/8-16 x 2-1/2 Hex Bolt	2
Parking Brake Assembly					F489	Washer 1/4 x 7/8 x .090	1
34	7406-1	Handle Grip, Red	1		F529	Washer 1.0 OD x .515 ID x 1/8	2
35	6406-6	Parking Brake Lever (Includes Item # 33)	1		F533	Socket Cap Bolt, 5/16-18 x 3-1/2	4
36	8655-4	Clevis Pin (5/16 x 3/4)	5	* Service Part Only			
37	6406-1	Brake Actuator Pull	1	** Required hose specifications:			
38	2280	Clevis (3/8)	1	M111 - 1/4" ID fuel/oil/vapor hose (Gates 4219-0103 or equivalent)			
39	6406-2	Parking Brake Pull Rod	2				

HYDROSTATIC GROUND DRIVE ASSEMBLIES



STEERING CONTROL ASSEMBLIES

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Steering Lever & FSC Assemblies				Fasteners			
1	5850-2	Handle Grip, Foam (5-1/2)	3	F004	1/4-20 Keps Nut		2
2	4170-1	FSC Lever Assembly (Includes Item # 4)	*	F005	1/4-20 ESNA Nut		2
3	2170-1	Step Washer	1	F009	5/16-18 Whiz Locknut		8
4	5830	Grease Fitting	1	F010	5/16-24 ESNA Nut		2
5	5214-4	Ball Joint (5/16-24) W/O Stud	4	F024	5/16-24 Jam Nut		4
6	4173-3	Control Rod (4-7/16)	1	F035	5/16-18 x 1-1/4 Hex Bolt		1
7	4219	Extension Spring (3/4 x 6-1/2)	1	F044	5/16-24 x 3/4 Hex Bolt		2
8	4451-9	FSC Friction Actuator	1	F059	3/8 Wave Spring Washer		1
9	8201-3	Fiberglide Bearing	4	F093	5/16-18 x 1 Hex Bolt		4
10	6451-2	Speed Control Actuator, RH (Includes Items # 9 & 12)	1	F146	1/4-20 Jam Nut		2
11	4452-6	Steering Pivot (1/4-20 x 1-5/8)	2	F167	5/16-18 Hex Nut		1
12	5830-3	Grease Fitting (45 Degree)	2	F183	.312 x .700 x .074 Washer		8
13	5146	10mm Ball Stud	4	F188	1/4-20 Self-Locking Nut		4
14	4199-2	Steering Lever Dampener Assembly	2	F192	3/8-24 Self-Locking Nut		1
15	5463-6	Washer 5/16 x 3/4 x .250	2	F198	.250 x .625 x .040 Washer, SS		2
16	5463-5	Steering Arm Pivot Bushing (SS)	2	F211	1/4-20 x 7/8 Hex Bolt		1
17	7201-2	Fiberglide Bearing (1/2")	2	F226	5/16-18 x 7/8 Hex Bolt		2
18	5463-4	Steering Lever Actuator	2	F312	3/8 x 3/8 Shoulder Bolt		1
19	5665-1	Compression Spring (2-1/2)	2	F345	1/4-20 x .770 Knurled Bolt		4
20	4213-2	Control Rod (6-3/4)	2	F385	1/4 x 1-1/4 Roll Pin		1
21	2212-3	Seal Retainer	2	F386	5/16-18 x 1-1/2 x 3/8 Shoulder Bolt		1
22	2212	Transmission Control Arm Stop	2	F391	1/4-20 x 1/2 Set Screw, SS		2
23	6212-2	Transmission Control Arm, RH	1	F407	Belleville Washer 3/8 x 1.187, SS		1
24	6212-3	Transmission Control Arm, LH	1	F551	5/16-18 Flange Top Lock Nut		1
25	6451-1	Speed Control Actuator, LH (Includes Items # 9 & 12)	1	* Service Part Only			
26	4451-1	Steering Pivot Shaft W/Stop	1				
27	9704-3	Pivot Rod Bushing / Plastic	2				
28	4142-2	FSC Friction Washer (1-1/2 x 1-1/32 x 1/16)	1				
29	5141	FSC Friction Washer (1-1/2 x 3/8 x 1/16)	1				
30	4142-1	FSC Cam	1				
31	5222	Extension Spring (1/2 x 3-1/4)	2				
32	5450	D-Clip	2				
33	6452-1	Steering Lever Tube W/Tab	2				
34	5453-10	Steering Lever Handle / Adjustable (Includes Items # 1 & F345)	2				

[illegible]

GHS GROUP


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Delivery Chute Assembly				Fasteners			
1	5515-4	Elbow Delivery Spout	1	F002	10-24 Keps Nut		4
2	5592-24	Backing Plate, Grass-Pak® Switch	1	F004	1/4-20 Keps Nut		14
3	5592-23	Grass-Pak® Housing Spacer	1	F009	5/16-18 Whiz Locknut		2
4	5578-1	Rear Clip Notched, Chute Mount	1	F013	3/8-16 Whiz Locknut		2
5	5577	Side Clip, Chute Mount	2	F023	10-24 ESNA Nut		2
6	6530-6	Body Chute	1	F031	1/4-20 x 5/8 Hex Bolt		2
7	7511-5	Outside Chute Cover Lip	1	F032	1/4-20 x 3/4 Hex Bolt		4
8	7511-4	Inside Chute Cover Lip	1	F039	3/8-16 x 1-1/4 Hex Bolt		2
9	7511-2	7.0 Delivery Chute W/Clips (Includes Items # 4, 5, F079 & F411)	1	F050	1/4 SAE Washer		2
Blower Assembly				F079	A/A66D Aluminum Pop Rivet		8
10	6543-5	Blower Scroll	1	F128	10-24 x 3/8 PTHMS		4
11	6349-2	Flanged Bearing (3/4")	1	F411	3/16 Bulbex Rivet		6
12	6349-1	Sleeve .3150 x .375 x 3/8	2	F420	5/16-18 x 1-1/4 Carriage Bolt		2
13	4349-14	Flanged Bearing (1") Machine Flat	1	F531	1/4-20 x 5 Hex Bolt		11
14	5526-9	Receiver Cone	1	F532	1/4-20 x 5-1/2 Hex Bolt		1
15	7275-3	U-Joint Tube, Splined	1	F577	10-24 x 5/8 Carriage Bolt		2
16	7275-9	Quick Coupler Installation Tool	*	* The Quick Coupler Installation Tool is used to assist the installation of the Quick Coupler Tube and PTO Shaft connection by holding the disconnect ring in the retracted position when joined to the tractor spline shaft on the PTO gearbox.			
17	6545-7	Blower Wheel	1	NOTE: Refer to ELECTRICAL CONNECTORS , Page 26, for identification of all Electrical Wiring Service Parts.			
18	6543-8	Blower Faceplate	1				
19	5794-5	Fixed Chute	1				



GHS POWERFIL® ASSEMBLY (7.0)


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
7.0 GHS Powerfil® Assembly				Fasteners			
1	5552	Ball Joint (1/4-28)	2		F003	1/4-28 Hex Nut	2
2	5553-3	Bushing, Powerfil® Actuator	4		F023	10-24 ESNA Nut	10
3	5553-1	Compression Spring (1/2 x 2)	2		F054	AN960616 Washer	1
4	5558-2	Powerfil® Actuator Rod	1		F085	3/16 Rivet Backup Washer	1
	5549	Actuator Rod Assembly (Includes Items # 1-5 & F003)	*		F101	10-24 x 1-1/4 SHC Screw	1
5	5558-1	Powerfil® Push Rod	1		F109	1/8 x 5/8 Roll Pin	1
6	5551-3	Bearing Cap, Powerfil®	1		F261	AN960616L Washer	1
7	5551-1	Pivot Bearing (#S3PP)	2		F287	1/4-28 Keps Nut	2
8	5518-2	Pivot, Delivery Spout	1		F612	10-24 x 5/8 Truss Head Torx	7
9	5517-2	Pivot Mount	1		F613	10-24 x 1/2 Truss Head Torx	2
10	5519-5	Actuator Motor (12V) (Includes Items # 11 & 12)	1	*	Service Part Only		
11	5519-2	Motor Mount Washer	*				
12	5519-3	Motor Mount Nut (5/8-24)	*				
13	5554	Actuator Arm	1				

GHS POWERFIL® ASSEMBLY (7.0)



GHS 7.0 BUSHEL CATCHER ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Upper Baffle Screen Assembly (Removable)				40	7607-8	Powerfil® Cover Plate	1
1	7512-12	Removable Screen (3/16 Hole) (Includes Items # 2, F190 & F617)	1**	41	7608-4	Hinge Plate, RH	1
2	7506	Knob / Threaded Insert (10-24)	2	42	8155-8	7.0 Gas Spring Cover, RH	1
3	7509-7	Channel Top, LH	1	43	7607-14	Catcher Door Arm, RH	1
4	8606-2	Channel Bottom	2	44	7584-3	Reinforcing Strap	1
5	6856-1	Edge Molding (21-3/4")	1	45	5801-3	Decal Plate, Round (Set of 2)	1
6	6507	Screen Seal (23-1/4")	1	46	7608-5	Door Arm Stop	2
7	7505	Mustache Spring	2	5598-2 Optional Dump Bag (Not Shown)			
8	7509-6	C-Channel With Spring (Includes Items # 7 & F340)	1	May be ordered as an option. Contact your Walker dealer.			
9	7509-8	Channel Top, RH	1	Fasteners			
7.0 Exhaust Deflector Door Assembly				F020	5/16-18 ESNA Nut		2
10	7607-3	Upper Door Seal	1	F023	10-24 ESNA Nut		28
11	7510-4	7.0 Catcher Box Door (Includes Frame) (Includes Items # 10, 12, 13, 15, F085, F330 & F411)	1	F029	1/4-20 x 1/2 Hex Bolt		2
12	5583	Handle	1	F031	1/4-20 x 5/8 Hex Bolt		2
13	7607-6	Lower Door Stiffener (7.0)	1	F049	5/16 SAE Washer		4
14	8607-8	Door Guide	1	F050	1/4 SAE Washer		4
15	7607-5	Upper Door Stiffener	1	F079	A/A66D Aluminum Pop Rivet		4
GHS 7.0 Bushel Catcher Assembly				F085	3/16 Rivet Backup Washer		4
16	7503-8	Center Strap (7.0)	1	F094	8-32 x 1/2 PTHMS		6
17	7503-6	Upper Frame Doubler (7.0)	2	F190	#10 Internal Star Lock Washer		2
18	7503-5	Lower Frame Doubler (7.0)	2	F196	1/4-20 x 1 PPHMS, SS		4
19	7503-4	Outside Box Strap (7.0)	2	F230	1/4-20 x 1-1/4 PPHMS, SS		4
20	8608-11	Catcher Door Finger	1	F242	1/4-20 x 7/8 PPHMS, SS		8
21	8608-4	Center Frame Doubler	1	F275	5/16-18 x 2 Hex Bolt		2
22	7503-11	Catcher Mount	1	F330	3/16D x 21/32L Rivet, SS		4
23	7610-4	Catcher Dump Flap Spacer (7.0)	1	F340	Rivet, Aluminum		4
24	7610-8	Catcher Dump Flap With Plate	1	F351	Aluminum Pop Rivet		6
25	8610-3	Backing Plate / Dump Flap	1	F360	1/4-20 x 3/8 Hex Bolt		2
26	7620-3	Pivot Bushing (1/2 x 9/16)	4	F390	1/4-20 x 7/8 Carriage Bolt		4
27	7607-7	Bushing	2	F411	3/16 Bulbex Rivet		32
28	7608-3	Hinge Plate, LH	1	F442	1/4-20 x 5/8 PTHMS		2
29	7607-15	Catcher Door Arm, LH	1	F477	1/4-20 x 5/8 Carriage Bolt		4
30	8155-7	7.0 Gas Spring Cover, LH	1	F524	3/16 x 3/8 Aluminum Rivet, Black		6
31	5155-5	Gas Spring	2	F540	1/4-20 x 1-3/4 PPHMS, SS		1
32	5155-13	3/4 Ball Stud	2	F551	5/16-18 Flange Top Lock Nut		2
33	5523-6	Gas Spring Plate	2	F569	1/4-20 Flange Top Lock Nut		29
34	5155-12	5/16 Ball Stud	2	F612	10-24 x 5/8 Truss Head Torx		4
35	5155-15	Box Support, Gas Spring	2	F613	10-24 x 1/2 Truss Head Torx		10
36	7532-1	Handle, Catcher Lift	2	F615	1.0 x .255 x .125 Washer		4
37	7511-6	Chute Cover	1	F617	10-24 x 3/8 Truss Head Torx		4
38	7557-1	7.0. Wire Harness Channel	1	F618	10-24 x 3/4 Truss Head Torx		12
39	7510-3	7.0 Bushel Catcher Box	1	* Service Part Only			
	7502-6	7.0 Catcher W/Powerfil® (Includes Door)	*	** This screen can be replaced by P/N 7512-13 Removable Screen (3/4" holes) for improved air flow performance in wet conditions.			



Beginning S/N 153873
Use only genuine **Walker®** replacement parts.

ELECTRICAL ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
----------	----------	-------------	-----------

Electrical Assembly

1	7834-3	Wire Saddle (3 Wires)	4
2	5942-11	Delta Hex Nut	1
3	5942-9	Safety Switch (NO), Delta Threaded	1
4	5832	Cable Clamp (1/2)	3
5	5975-1	Cable Tie (18# x 3-3/4")	3
6	8404-8	Plastic Cover, Red	3
7	8941	Circuit Breaker (30 Amp) (Auto Reset/Sealed)	1
8	6922	Battery Cable (+)	1
9	4929	Starter Solenoid	1
10	5942-8	Safety Switch (NO), Delta Side Mount	2
11	5833-1	Cable Clamp (1/4 x 1/4)	3
12	6681-23	Plastic Cap, Black	2
13	4940-15	30A Fuse, Jumper Wire Assembly	1
14	5943-10	Wire Harness Assembly	1
15	5835-4	Cable Clamp (1/2) .343 Hole	1
16	5942-10	Safety Switch (NC), Delta Side Mount	1
17	4024-13	Safety Switch Plate	1
18	6942	Relay Switch 20/40 Amp (NC)	3
19	8990-1	Hourmeter (Global)	1
20	8960-15	Ignition Switch (With Keys) (Includes Items # 20, 21 & F349)	1
21	7854	Plastic Tip / Red	1
22	8960-3	Key Set W/Umbrella	1
23	7941-3	Boot, Circuit Breaker	1
24	7941-8	Circuit Breaker (5 Amp)	1

Battery Assembly

25	5844-3	Battery Hold-Down Bar	1
26	5839	Hook Bolt	2
27	5933	Battery Terminal Insul., Red (+)	1
28	4940-8	Started Solenoid Cable	1
29	NS	Battery (12V/300.CA/Wet)	1
30	6390-3	Battery Pan	1
31	6923	Battery Cable (-)	1
32	5932	Battery Terminal Insul., Black (-)	1

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
----------	----------	-------------	-----------

Fasteners

F002	10-24 Keps Nut	8
F004	1/4-20 Keps Nut	8
F013	3/8-16 Whiz Locknut	2
F019	1/4-20 ESNA Wing Nut	2
F025	10-24 x 3/8 PPHMS	1
F026	10-24 x 1/2 PPHMS	5
F027	10-24 x 5/8 PPHMS	2
F029	1/4-20 x 1/2 Hex Bolt	2
F031	1/4-20 x 5/8 Hex Bolt	4
F050	1/4 SAE Washer	2
F112	5/8 x 1-1/4 x .03 Washer	3
F146	1/4-20 Jam Nut	1
F182	1/4 x 5/8 x 1/8 Washer	2
F187	1/4-20 x 1-1/2 Hex Bolt	1
F211	1/4-20 x 7/8 Hex Bolt	1
F232	10-32 Keps Nut	2
F306	3/8-16 x 3/4 Hex Bolt	2
F349	Washer .835 ID 1.122 OD, SS	1
F505	6-32 x 7/8 Hex Trim MS, SS	6
F506	6-32 Nylock Nut	6

NOTE: Refer to **ELECTRICAL CONNECTORS**, Page 26, for identification of all Electrical Wiring Service Parts.

NOTE: Decals for this assembly are not shown here. Refer to **TRACTOR DECALS**, Page 2, for Decal listing and placement information.

[illegible]

ELECTRICAL ASSEMBLIES (GHS 7.0 BUSHEL COMPONENTS)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
-------------	-------------	-------------	--------------

Horn & Harness Channel Assemblies

1	5536-2	Horn, Full Signal	*
2	5976-2	Grommet (3/16 x 3/4)	2
3	5975-1	Cable Tie (18# x 3-3/4")	1

Harness & Grass-Pak® Switch Assemblies

4	8950-4	Powerfil Wire Harness (7.0/10.0)	1
5	7834	Nylon Clamp (1/4)	1
6	5833	Cable Clamp (1/4)	2
7	5594-6	Aluminum Shaft & Vane Assembly	1
8	5592-20	Grass-Pak® Switch Assembly	1

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
-------------	-------------	-------------	--------------


Fasteners

F002	10-24 Keps Nut	1
F023	10-24 ESNA Nut	3
F025	10-24 x 3/8 PPHMS	1
F411	3/16 Bulbex Rivet	1
F508	4-40 Keps Nut, SS	2
F509	4-40 x 1/2 Hex Head, SS	2
F612	10-24 x 5/8 Truss Head Torx	1
F613	10-24 x 1/2 Truss Head Torx	2

* Service Part Only

NOTE: Refer to **ELECTRICAL CONNECTORS**, Page 26, for identification of all Electrical Wiring Service Parts.


ELECTRICAL ASSEMBLIES (GHS 7.0 BUSHEL COMPONENTS)



ELECTRICAL CONNECTORS

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Electrical Wiring Service Parts				29	7942-1	2-Way Locking Connector, Female	*
1	5996-1	16-14 GA Butt Connector	*	30	7942-2	2-Way Connector, Male	*
2	5996-11	12-10 GA Butt Connector	*	31	7942-3	2-Way Connector, Female	*
3	7942-14	16-14 GA Shrink Connector	*	32	7942-10	2-Way Locking Connector, Male	*
4	7942-13	12-10 GA Shrink Connector	*	33	5940-8	3-Way Connector, Male	*
5	5995-1	Wire Terminal Adapter	*	34	7942-9	3-Way Connector, Male	*
6	5996-4	16-14 GA Bullet Conn., Male	*	35	8944	3-Way Locking Connector, Male	*
7	5996-5	16-14 GA Bullet Conn., Female	*	36	8944-1	3-Way Locking Connector, Female	*
8	5940-4	16-14 GA Spg. Loaded Term., Female	*	37	7942-11	4-Way Connector, Male	*
9	5940-7	Wire Clip, Female	*	38	7942-12	4-Way Connector, Female	*
10	5996	1/4 x 16-14 GA QDF Terminal	*	39	7942-5	5-Way Connector, Male	*
11	5996-2	3/16 x 22-18 GA QKS Term., Female	*	40	5940-2	5-Way Connector, Male	*
12	7996	16-14 GA QKS Term., Female	*	41	8942-1	5-Way Connector, Female	*
13	5940-5	16-14 GA Spg. Loaded Term., Male	*	42	7942-6	6-Way Connector, Male	*
14	5996-0	1/4 x 22-18 GA QKS Term., Male	*	43	7942-7	6-Way Connector, Male	*
15	5996-18	16-14 GA Ring Term. (#8) Nylon Insulated	*	44	7942-8	8-Way Connector, Male	*
16	7996-1	1/4 x 16-14 GA QKS Term., Male	*	45	8942-2	8-Way Connector, Female	*
17	5996-8	6 GA Ring Lug (5/16) Insulated	*	46	8942-3	5-Way Connector, Male	*
18	5996-9	22-18 GA Ring Term. (#10)	*	47	5940-9	3-Way Connector (M)	*
19	5996-10	16-14 GA Ring Term. (5/16) Insulated	*	48	7942-15	6-Way Connector (Female)	*
20	5996-12	12-10 GA Ring Term. (5/16)	*	49	7940-3	Packard Plug (Male)	*
21	5996-13	16-14 GA Ring Term. (#10) Insulated	*	50	7940-4	Packard Plug (Female)	*
22	5996-15	12-10 GA Ring Term. (1/2)	*	* Service Part Only			
23	5996-16	6 GA Ring Terminal (1/4)	*	NOTE: Not all Electrical Connectors are used with all assemblies.			
24	5996-17	16-14 GA Ring Term. (1/4)	*	NOTE: Refer to ELECTRICAL ASSEMBLY , Page 22, for locations of Wiring Harness, Electrical Components and of all Electrical Wiring Service Parts.			
25	5996-20	12-10 GA Ring Term. (1/4) Insulated	*				
26	5996-21	12-10 GA Ring Term. (#10) Insulated	*				
27	7942-4	Single Connector, Male	*				
28	8942	2-Way Connector, Male	*				

ELECTRICAL CONNECTORS



LUBRICATION POINTS

ITEM NO.	LOCATION	LUBRICATION TYPE	NO. PLACES
Lubrication Points			
1	Steering Lever Pivot	Grease	2
2	FSC Lever Pivot	Grease	1
3	Deck-to-PTO Coupling (Grease Spline Slide Area)	Grease	1
4	Universal Joint Tube Assembly	Grease*	1
5	Deck Support Arm Pivot	Grease	2
6	Hydro Idler Pivot	Grease	1
7	PTO Clutch Lever Pivot	Grease	1
8	Transaxle Oil Reservoir	Oil/20W-50	1
9	Body Latch Pivot	Oil	1
10	Clutch Actuator Push Rod (Grease Slide Area)	Grease	1
11	PTO Belt Tightener Pivot	Grease	1
12	Brake Band Pivot Pins (Clevis)	Oil	2


ITEM NO.	LOCATION	LUBRICATION TYPE	NO. PLACES
13	Catcher Hinge Point	Oil	2
14	Throttle Control Cable Ends	Oil	2
15	Engine Dipstick / Oil Filler	Oil**	1
16	Choke Control Cable Ends	Oil	2
17	Engine Idler Pivot	Grease	1
18	Parking Brake Lever	Grease	1
19	Choke Control Pivot	Oil	1
20	Throttle Control Pivot	Oil	1

* Grease every 25 hours.

** Refer to S18 **Operator's Manual** for procedure for checking and changing oil in Engine Crankcase.


NOTE: See Model S18 **Operator's Manual** (5000-41) for proper lubrication intervals.

LUBRICATION POINTS



WIRING SCHEMATIC

WALKER MODEL S18 Beginning S/N 153873



MAINTENANCE AND SERVICE RECORD SHEET

[illegible]

MAINTENANCE AND SERVICE RECORD SHEET

[illegible]

LIMITED WARRANTY FOR WALKER MODEL S18 RIDER MOWER

1. WHAT THIS WARRANTY COVERS, AND FOR HOW LONG:

Walker Manufacturing company will, at its option, repair or replace, without charge, any part covered by this warranty which is found to be defective in material and/or workmanship within two (2) years* after the date of sale to the original retail purchaser unless the product is used for rental purposes, in which case this warranty is limited to ninety (90) days. At Walker's request, customer will make the defective part available for inspection by Walker and/or return the defective part to Walker, transportation charges prepaid. All parts and components of the Walker Mower are covered by this warranty **except** the following components which are warranted separately by their respective manufacturers:

Briggs & Stratton Engine
Battery

The available warranties covering these items are furnished with each mower. Walker does not assume any warranty obligation, liability or modification for these items, which are covered exclusively by the stated warranty of the respective manufacturers noted above.

* A two (2) year or 2000 hour (whichever comes first) warranty is offered for Hydro-Gear ZT3100 hydrostatic transmissions; covers full cost of replacement up to 1000 hours of use, and after 1000 hours warranty coverage is prorated against 2000 hours.

2. WHAT THIS WARRANTY DOES NOT COVER:


- A. This warranty does not cover defects caused by depreciation or damage caused by normal wear, accidents, improper maintenance, improper use or abuse of the product, alterations, or failure to follow the instructions contained in the Operator's Manual for operation and maintenance.
- B. The customer shall pay any charges for making service calls and/or for transporting the mower to and from the place where the inspection and/or warranty work is performed.

3. HOW TO OBTAIN SERVICE UNDER THIS WARRANTY:

Warranty service can be arranged by contacting the dealer where you purchased the mower or by contacting Walker Manufacturing Company, 5925 East Harmony Road, Ft. Collins, CO 80528. Proof of the date of purchase may be required to verify warranty coverage.

4. WARRANTY LIMITATION:

- A. **THERE IS NO OTHER EXPRESS WARRANTY. ANY WARRANTY THAT MAY BE IMPLIED FROM THIS PURCHASE INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE IS HEREBY LIMITED TO THE DURATION OF THIS WARRANTY AND TO THE EXTENT PERMITTED BY LAW ANY AND ALL IMPLIED WARRANTIES ARE EXCLUDED.** Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.
- B. **WALKER WILL NOT BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES AND/OR EXPENSES IN CONNECTION WITH THE PURCHASE OR USE OF THE MOWER.** Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation(s) or exclusion(s) may not apply to you.
- C. Only the warranty expressed in this limited warranty shall apply and no dealer, distributor, or individual is authorized to amend, modify, or extend this warranty in any way. Accordingly, additional statements such as dealer advertising or presentations, whether oral or written, do not constitute warranties by Walker, and should not be relied upon.
- D. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.



WALKER

WALKER MFG. CO. • 5925 E. HARMONY ROAD, FORT COLLINS, CO 80528 • (970) 221-5614
FORM NO. 020520 PRINTED IN USA www.walker.com ©2020 WALKER MFG. CO