




WALKER

Illustrated Parts Manual

C19i



Beginning S/N: 187255
P/N 6000-44

KEY TO ABBREVIATIONS USED IN THIS MANUAL

<i>Abbreviation</i>	<i>What it Represents</i>
° (Dimension)	Degrees (Angle)
" (Dimension)	inches
(-)	Negative (Polarity)
(+)	Positive (Polarity)
-1 (as deck style designation)	Standard (Aluminum) Gear Drive Deck
-2 (as deck style designation)	Heavy Duty (Cast Iron) Gear Drive Deck
-3 (as deck style designation)	Belt Drive Deck
AT	All-Terrain
CCW	Counter-clockwise
CW	Clockwise
D	Diameter
DC	Deck, Collection (number refers to size in inches)
DM	Deck, Mulching (number refers to size in inches)
DR	Deck, Rear Discharge (number refers to size in inches)
DS	Deck, Side Discharge (number refers to size in inches)
DU	Garlock (Bearing)
ESNA (Fastener)	Nylon Insert Locknut
FSC	Forward Speed Control
GA	Gauge
gal	gallon
GHS	Grass Handling System
GR (Fastener)	Grade
HD	Heavy Duty
HP	Horse Power
ID	Identification or Inside Diameter
L	Length
LH	Left Hand (orientated with operator on seat)
LP	Low Profile
mm (Dimension)	millimeters
MS (Fastener)	Machine Screw
NS (as part number)	Item is not sold by Walker Manufacturing
OD	Outside Diameter
oz	ounce
PFH (Fastener)	Phillips Flat Head
P/N	Part Number
PPH (Fastener)	Phillips Pan Head
PTH (Fastener)	Phillips Truss Head
PTO	Power Take-Off
QKS	Quick Slide
qt	quart
RH	Right Hand (orientated with operator on seat)
SAE (Fastener)	Society of Automotive Engineers
SBH (Fastener)	Socket Button Head (Bolt)
SFH (Fastener)	Slotted Flat Head
SHC (Fastener)	Socket Head Cap
SHL (Fastener)	Shoulder (Bolt)
SM (Fastener)	Sheet Metal (Screw)
S/N	Serial Number
SQH (Fastener)	Square Head
SS (Fastener)	Stainless Steel
ST (Fastener)	Self-Tapping (Screw)
TOPS™	Transmission Oil Performance System
V	Volts
VLR	Very Low Restriction

NOTE: In some instances, combinations of abbreviations may be used (e.g. PPHMS - Phillips Pan Head Machine Screw).

Model C19i Beginning S/N 187255
Use only genuine **Walker®** replacement parts.

ILLUSTRATED PARTS LIST

<i>Section of Tractor Covered</i>	<i>Page</i>
Decals	
Tractor Decals	2
Body / Chassis Assemblies	
Body / Chassis Assembly	4
Rear Body Assembly	6
Tractor Components	
Main Component Power Transmission	8
Engine Group	10
Engine Group (Fuel Components)	12
Hydrostatic Ground Drive Assemblies	14
Steering Control Assemblies	16
Throttle Control Assembly	18
Parking Brake Assembly	20
GHS Group	22
GHS Powerfil® Assembly (7.0)	24
GHS 7.0 Bushel Catcher Assembly	26


<i>Section of Tractor Covered</i>	<i>Page</i>
Electrical Components	
Electrical Assembly	28
Electrical Assemblies (GHS 7.0 Bushel Components)	30
Maintenance	
Lubrication Points	32
Wiring Schematic	34
Maintenance And Service Record Sheet	35
Warranty	
Limited Warranty	37

TRACTOR DECALS

ITEM NO.	PART NO.	DESCRIPTION	LOCATION	NO. REQUIRED
Walker Product and Operation Decals				
1	8600-33	RH Fender	Body, RH Near Seat	1
2	5813-2	Decal, 4" Grass-Pak Powerfil®	Powerfil® Cover Plate	1
3	5800-22	Walker (8" Round)	7.0 Bushel Catcher (one on each side)	2
4	8600-37	LH Fender	Body, LH Near Seat	1
5	8821-18	Decal, C19i	Body	1
6	5856-1	Made in USA	Body	1
Danger Decals Warning Decals Caution Decals				
7	8600-10	Danger, Pinch Point	7.0 Bushel Catcher Mounting Frame Assembly (one on each side)	2
8	8600-4	Danger, Rotating Blower Blades	Body, Near Body Chute	1
9	8600-12	Danger, Engine Exhaust	Front Body, LH Side	1
10	5810-3	Decal, Hydro Warning	LH Gear Axle Drive Assembly	1
Maintenance Decals				
11	5869	Removable Screen	7.0 Bushel Catcher Removable Screen	1
12	5855	Important, Engine Cooling	Engine	1
13	6895-103	Kohler 300 Hour Oil	Oil Cooler / Regulator Mount	1
14	8600-16	Front Body Closure	Rear Cross Member, Body	1
15	5024-24	Decal, TOPS™	Oil Reservoir Tank	1
16	5810-1	Axle Oil Level	Gear Axle Drive Assemblies (one on each)	2
17	6875	PTO Alignment Arrow	Universal Joint Tube Assembly	1
18	6807-1	Oil Pressure	Body	1
19	5802-5	Engine Service Light	Body	1
20	8600-30	Parking Brake	Body, RH Side Below Seat	1
21	7827	Oil Level	Jackshaft Support	1

NOTE: All parts requiring decals are shipped with decals applied.


TRACTOR DECALS



BODY / CHASSIS ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Seat Assembly				36	5038-1	Axle Spacer Tube (6-5/8)	1
1	5103-3	Seat W/Switch	1	37	6307-7	Chassis Frame	1
2	7440-5	Shock Mount (1-1/4 x 3/4)	4	38	5075-3	LP Wheel & Tire (18 x 8.50-10)	2
Rear Bumper Assembly					5075-2	LP Tire (18 x 8.50-10)	*
3	7516-5	Catcher Pivot Bushing	2		5075-5	LP Wheel (10 x 7)	*
4	5517-8	7.0 Rear Bumper	1		5033-6	Wheel & Tire (18 x 7.00-8)	**
5	7517-3	Catcher Pivot Plate	2		5030-6	Narrow Tire (18 x 7.00-8)	*
6	5162	Roller Wheel (5" Rubber)	2		5031-2	Narrow Wheel (8 x 5-5)	*
Body Assembly					5030-4	Tire Tube (18 x 8.50-8)	*
7	7383-6	Body Latch Bracket, RH	1	Fasteners			
8	7383-5	Body Latch Lever	1	F002	10-24 Keps Nut		2
9	7383-7	Body Latch Bracket, LH	1	F004	1/4-20 Keps Nut		8
10	7222	Extension Spring (1/4 x 3)	1	F009	5/16-18 Whiz Locknut		10
11	5845	Rubber Bumper (1.50 OD x 1.25)	4	F012	3/8-16 Keps Nut		6
12	6101-9	Front Body Engine Guard	1	F014	3/8-16 ESNA Nut		4
13	NS	Body ID Plate	1	F016	1/2-13 Self-Locking Nut		1
14	5989-12	Dome Plug (3/16)	1	F020	5/16-18 ESNA Nut		1
15	5989-10	Dome Plug (9/16)	1	F025	10-24 x 3/8 PPHMS		2
16	8118	Heat Deflector	1	F029	1/4-20 x 1/2 Hex Bolt		6
17	5989-3	Dome Plug (5/16)	4	F031	1/4-20 x 5/8 Hex Bolt		2
18	5989-4	Dome Plug (3/8)	3	F038	3/8-16 x 1 Hex Bolt		8
19	6100-53	Front Body	1	F040	3/8-16 x 1-1/2 Hex Bolt		2
20	5146	10mm Ball Stud	2	F041	3/8-16 x 1-3/4 Hex Bolt		2
21	2145	Gas Spring Assembly (Includes Item # 20)	1	F042	3/8-16 x 2-1/4 Hex Bolt		2
22	5180	Edge Molding, Lever Opening	2	F050	1/4 SAE Washer		2
Tilt-Up Latch Assembly***				F051	3/8 SAE Washer		2
23	5847	Plastic Tip	1	F059	3/8 Wave Spring Washer		2
24	5744-20	Spring Arm, Tilt-Up Latch	1	F093	5/16-18 x 1 Hex Bolt		1
25	5744-10	Spring Pivot Bushing	1	F157	1/2-20 x 1-1/4 Wheel Lug Bolt		8
26	5744-15	Compression Spring (3/8 x 5/8)	1	F206	#2 x 3/16 Drive Pin		2
27	5744-13	Mount Angle, LH	1	F241	.375 x .875 x .10 Washer		4
28	5744-12	Hook, Tilt-Up Latch	1	F292	1/2-13 x 8-1/2 Hex Bolt, GR 5		1
29	5744-14	Mount Angle, RH	1	F341	Coil Roll Pin (7/64 x 9/16)		1
Chassis Assembly				F342	5/16 Conical Washer		2
30	5267-1	Retainer Collar (1") (Includes Item # F413)	1	F413	5/16-24 x 5/16 Set Screw		2
31	5270-1	Ball Bearing	2	F570	3/8-16 Flange Top Lock Nut		4
32	5420-2	Tail Wheel Fork	1	F637	Washer .835 x .505 x .125		2
33	8769-12	Bearing Cup (1/2 ID)	2	F710	1/4-28 x 1/4 Set Screw (Knurled Cup), SS		1
34	5037-1	Bearing, Tail Wheel	2	* Service Part Only			
35	5035	Tail Wheel & Tire Assembly (13 x 6.50-6)	1	** May be ordered as a factory-installed option or for dealer installation. Narrow Drive Tires are used when installing a 36" Deck. Contact your Walker dealer.			
	5035-1	Tail Wheel Tire (13 x 6.50-6)	*	*** Complete Tilt-Up Latch Assembly Kit available by ordering kit # 5744-5.			
	5036	Tail Wheel & Hub (6 x 4.5)	*				

BODY / CHASSIS ASSEMBLY



REAR BODY ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
-------------	-------------	-------------	--------------

Rear Body Assembly


1	5976-2	Grommet (3/16 x 3/4)	1
2	5105-1	Rear Body Cover	1
3	8515-18	Catcher Handle Plate, RH	1
4	8389-5	Splash Guard	1
5	7146	13mm Ball Stud	2
6	7147	Spring Clip	2
7	7145	Gas Spring Assembly (Includes Items # 5 & 6)	1
8	7190-1	Insulation Foam Pad, LH	1
9	7190-2	Insulation Foam Pad, RH	1
10	5105-6	Rear Body, Catcher Support Frame	1
11	8515-17	Catcher Handle Plate, LH	1

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
-------------	-------------	-------------	--------------

Fasteners

F002	10-24 Keps Nut	4
F009	5/16-18 Whiz Locknut	2
F023	10-24 ESNA Nut	4
F026	10-24 x 1/2 PPHMS	4
F031	1/4-20 x 5/8 Hex Bolt	2
F032	1/4-20 x 3/4 Hex Bolt	1
F390	1/4-20 x 7/8 Carriage Bolt	2
F569	1/4-20 Flange Top Lock Nut	5
F615	1.0 x .255 x .125 Washer	1
F617	10-24 x 3/8 Truss Head Torx	4

NOTE: Rear Bumper Assembly is not shown here. Refer to **BODY / CHASSIS ASSEMBLY**, Page 4.



Model C19i Beginning S/N 187255
Use only genuine **Walker®** replacement parts.

MAIN COMPONENT POWER TRANSMISSION

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Clutch Lever Assembly				42	7833	Cable Clamp (7/8 x 1/4)	1
1	8358-3	Clutch Lever (Includes Items # 2 & 3)	1	43	8539	Starter Relay Mount	1
2	5830	Grease Fitting	8	44	7241-2	Transmission Drive Pulley (3-1/4MV) (Includes Items # F067 & F171)	1
3	4850	Handle Grip, Black	1	45	5268	Bearing W/Collar (3/4)	2
4	7303-10	Clutch Actuator Bolt (3/8)	1	46	8349	Transmission Belt Tightener Arm	1
5	7380-5	Knuckle Joint (3/8 ID)	1	47	5245	Idler Pulley (3")	1
6	7226-10	Compression Spring (3/4 x 2-1/2)	1	48	8394-6	Hydro Jackshaft Mount Assembly (Includes Items # 2, 9, 12, 40, 45, 49, F012, F042, F067 & F171)	*
7	8130-5	Pushrod, Clutch Actuator (Threaded Tube) (Includes Item # 2)	1	49	8273-1	Jackshaft (3/4 x 8-1/8)	1
8	8130-10	Clutch Actuator Rod Assembly (Includes Items # 2, 4-7, F054, F336 & F353)	1	50	7240-7	Jackshaft Drive Pulley (3.3/3V) (Includes Items # F067 & F171)	1
9	7201-3	Fiberglide Bearing	6	Fasteners			
10	7201-5	Inner Race (2-1/4)	1		F002	10-24 Keps Nut	1
11	8368	PTO Belt Tightener	1		F003	1/4-28 Hex Nut	2
12	5841	Retainer Washer (3/8 x 1-1/4)	4		F004	1/4-20 Keps Nut	2
13	8243-1	Clutch Idler Pulley	1		F005	1/4-20 ESNA Nut	1
	8243	Clutch Idler Pulley Assembly (Includes Items # 13-15 & F070)	*		F009	5/16-18 Whiz Locknut	3
14	5265	Bearing (3/4)	1		F012	3/8-16 Keps Nut	6
15	8243-3	Hub, Idler Pulley	1		F025	10-24 x 3/8 PPHMS	1
16	8375	PTO Belt Tightener Stop	1		F029	1/4-20 x 1/2 Hex Bolt	1
17	7377	Plastic Washer (1 x .438 x .025)	2		F034	5/16-18 x 3/4 Hex Bolt	2
18	7378	Pivot Bearing (7/16 x 9/16)	1		F041	3/8-16 x 1-3/4 Hex Bolt	2
19	5281-5	Clevis Pin (1/4 x 0.80)	2		F042	3/8-16 x 2-1/4 Hex Bolt	3
20	5280	Clevis (1/4)	2		F043	3/8-16 x 3 Hex Bolt	1
21	8305	Brake Actuator Rod	1		F047	3/8-16 x 4-1/2 Hex Bolt	1
22	8370	Bearing, Brake Actuator	1		F054	AN960616 Washer	3
23	8250	Brake Spring (1/2 x 2-1/2)	1		F061	1/4 Internal Star Lock Washer	1
24	8369	Brake Actuator (Includes Items # 2 & 22)	1		F067	3/16 x 3/16 x 1 Key	2
PTO Drive Shaft Assembly					F069	3/32 x 1/2 Cotter Pin	3
25	7050-1	Dipstick, Gearbox	1		F070	1-3/4 Internal Snap Ring	1
26	8371-1	Mount Bracket, Brake Band	1		F116	1/4-20 x 1-1/4 Hex Bolt	1
27	8377	Brake Band Guide	1		F121	5/16-18 x 3/8 x 1 SHL Bolt	1
28	8050-11	PTO Gearbox / Flange Pulley	1		F131	5/16-18 x 1/2 Hex Bolt	2
29	7248	Ground Drive Belt, Micro-V	1		F132	1/4-20 x 2-3/4 Hex Bolt	1
30	7275-16	Universal Joint Tube Assembly (Spline)	1		F168	5/16 Split Lock Washer	10
31	8304	Brake Band (14-1/2)	1		F171	5/16-18 x 3/8 Set Screw	4
32	7523-2	Clevis Pin W/Hole (1/4 x 5/8)	1		F178	1/4 x 1 Fender Washer	1
33	6250-1	Drive Belt (3VX370)	1		F182	1/4 x 5/8 x 1/8 Washer	2
34	7236-1	PTO Drive Pulley (4-1/2/3V) (Includes Items # F168 & F226)	1		F226	5/16-18 x 7/8 Hex Bolt	14
35	8237-3	Engine Pulley (4/3.8/3V) (Includes Item # F226)	1		F241	.375 x .875 x .10 Washer	1
36	8230	Engine PTO Belt	1		F261	AN960616L Washer	1
Jackshaft Assembly					F336	3/8-16 Jam Nut	1
37	7245-1	Idler Pulley (3/8 Groove)	1		F353	3/8-16 ESNA LP Nut	1
38	6325-2	Spacer Bushing (5/16)	2	* Service Part Only			
39	8349-4	Idler Arm	1				
40	7201-4	Inner Race (1-1/2)	2				
41	5221-1	Extension Spring (3/4 x 5)	2				

This diagram is an exploded view of a vehicle chassis and engine assembly. It shows the following components and their assembly references:


- Engine Group:** The main engine unit, labeled "Refer to Engine Group".
- Hydrostatic Ground Drive Assemblies:** Two units, each labeled "Refer to Hydrostatic Ground Drive Assemblies".
- GHS Group:** Components labeled "Refer to GHS Group", including a pump and various mounting brackets.
- Body / Chassis Assembly:** The main frame structure, labeled "Refer to Body / Chassis Assembly".
- Other Components:**
 - Various pulleys, belts, and rollers (e.g., F171, F042, F041, F004, F009, F012, F016, F017, F018, F019, F020, F021, F022, F023, F024, F025, F026, F027, F028, F029, F030, F031, F032, F033, F034, F035, F036, F037, F038, F039, F040, F041, F042, F043, F044, F045, F046, F047, F048, F049, F050, F051, F052, F053, F054, F055, F056, F057, F058, F059, F060, F061, F062, F063, F064, F065, F066, F067, F068, F069, F070, F071, F072, F073, F074, F075, F076, F077, F078, F079, F080, F081, F082, F083, F084, F085, F086, F087, F088, F089, F090, F091, F092, F093, F094, F095, F096, F097, F098, F099, F100, F101, F102, F103, F104, F105, F106, F107, F108, F109, F110, F111, F112, F113, F114, F115, F116, F117, F118, F119, F120, F121, F122, F123, F124, F125, F126, F127, F128, F129, F130, F131, F132, F133, F134, F135, F136, F137, F138, F139, F140, F141, F142, F143, F144, F145, F146, F147, F148, F149, F150, F151, F152, F153, F154, F155, F156, F157, F158, F159, F160, F161, F162, F163, F164, F165, F166, F167, F168, F169, F170, F171, F172, F173, F174, F175, F176, F177, F178, F179, F180, F181, F182, F183, F184, F185, F186, F187, F188, F189, F190, F191, F192, F193, F194, F195, F196, F197, F198, F199, F200, F201, F202, F203, F204, F205, F206, F207, F208, F209, F210, F211, F212, F213, F214, F215, F216, F217, F218, F219, F220, F221, F222, F223, F224, F225, F226, F227, F228, F229, F230, F231, F232, F233, F234, F235, F236, F237, F238, F239, F240, F241, F242, F243, F244, F245, F246, F247, F248, F249, F250, F251, F252, F253, F254, F255, F256, F257, F258, F259, F260, F261, F262, F263, F264, F265, F266, F267, F268, F269, F270, F271, F272, F273, F274, F275, F276, F277, F278, F279, F280, F281, F282, F283, F284, F285, F286, F287, F288, F289, F290, F291, F292, F293, F294, F295, F296, F297, F298, F299, F300, F301, F302, F303, F304, F305, F306, F307, F308, F309, F310, F311, F312, F313, F314, F315, F316, F317, F318, F319, F320, F321, F322, F323, F324, F325, F326, F327, F328, F329, F330, F331, F332, F333, F334, F335, F336, F337, F338, F339, F340, F341, F342, F343, F344, F345, F346, F347, F348, F349, F350, F351, F352, F353, F354, F355, F356, F357, F358, F359, F360, F361, F362, F363, F364, F365, F366, F367, F368, F369, F370, F371, F372, F373, F374, F375, F376, F377, F378, F379, F380, F381, F382, F383, F384, F385, F386, F387, F388, F389, F390, F391, F392, F393, F394, F395, F396, F397, F398, F399, F400, F401, F402, F403, F404, F405, F406, F407, F408, F409, F410, F411, F412, F413, F414, F415, F416, F417, F418, F419, F420, F421, F422, F423, F424, F425, F426, F427, F428, F429, F430, F431, F432, F433, F434, F435, F436, F437, F438, F439, F440, F441, F442, F443, F444, F445, F446, F447, F448, F449, F450, F451, F452, F453, F454, F455, F456, F457, F458, F459, F460, F461, F462, F463, F464, F465, F466, F467, F468, F469, F470, F471, F472, F473, F474, F475, F476, F477, F478, F479, F480, F481, F482, F483, F484, F485, F486, F487, F488, F489, F490, F491, F492, F493, F494, F495, F496, F497, F498, F499, F500, F501, F502, F503, F504, F505, F506, F507, F508, F509, F510, F511, F512, F513, F514, F515, F516, F517, F518, F519, F520, F521, F522, F523, F524, F525, F526, F527, F528, F529, F530, F531, F532, F533, F534, F535, F536, F537, F538, F539, F540, F541, F542, F543, F544, F545, F546, F547, F548, F549, F550, F551, F552, F553, F554, F555, F556, F557, F558, F559, F560, F561, F562, F563, F564, F565, F566, F567, F568, F569, F570, F571, F572, F573, F574, F575, F576, F577, F578, F579, F580, F581, F582, F583, F584, F585, F586, F587, F588, F589, F590, F591, F592, F593, F594, F595, F596, F597, F598, F599, F600, F601, F602, F603, F604, F605, F606, F607, F608, F609, F610, F611, F612, F613, F614, F615, F616, F617, F618, F619, F620, F621, F622, F623, F624, F625, F626, F627, F628, F629, F630, F631, F632, F633, F634, F635, F636, F637, F638, F639, F640, F641, F642, F643, F644, F645, F646, F647, F648, F649, F650, F651, F652, F653, F654, F655, F656, F657, F658, F659, F660, F661, F662, F663, F664, F665, F666, F667, F668, F669, F670, F671, F672, F673, F674, F675, F676, F677, F678, F679, F680, F681, F682, F683, F684, F685, F686, F687, F688, F689, F690, F691, F692, F693, F694, F695, F696, F697, F698, F699, F700, F701, F702, F703, F704, F705, F706, F707, F708, F709, F710, F711, F712, F713, F714, F715, F716, F717, F718, F719, F720, F721, F722, F723, F724, F725, F726, F727, F728, F729, F730, F731, F732, F733, F734, F735, F736, F737, F738, F739, F740, F741, F742, F743, F744, F745, F746, F747, F748, F749, F750, F751, F752, F753, F754, F755, F756, F757, F758, F759, F760, F761, F762, F763, F764, F765, F766, F767, F768, F769, F770, F771, F772, F773, F774, F775, F776, F777, F778, F779, F780, F781, F782, F783, F784, F785, F786, F787, F788, F

9

ENGINE GROUP

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Precleaner Assembly				Fasteners			
1	4090	Air Cleaner Assembly (90 Deg. 2") (Includes Item # 4)	*	F004	1/4-20 Keps Nut		3
2	7840-5	Hose Clamp (1.56 to 2.50)	1	F009	5/16-18 Whiz Locknut		7
3	6087-5	Air Intake Hose	1	F029	1/4-20 x 1/2 Hex Bolt		2
4	NS	Air Cleaner Band	1	F031	1/4-20 x 5/8 Hex Bolt		4
5	5090-5	Safety Filter Insert, VLR	1	F034	5/16-18 x 3/4 Hex Bolt		2
6	5090-6	Air Cleaner Cartridge, VLR	1	F038	3/8-16 x 1 Hex Bolt		1
7	5091-19	Air Flow Indicator W/Bracket (Vacuum 15" H2O)	1	F049	5/16 SAE Washer		2
8	7334-3	Air Cleaner Bracket	1	F050	1/4 SAE Washer		4
9	6029	Hose Clamp (1-13/16 to 2-3/4)	1	F051	3/8 SAE Washer		2
10	M258	Vacuum Hose (17")	1**	F061	1/4 Internal Star Lock Washer		2
11	5091-0	1/8 Pipe Thread Male W/Barb	1	F063	3/8 Internal Star Lock Washer		2
12	5091-16	Street Elbow 90' (1/8 x 1/8)	1	F091	5/16-18 x 5/8 Hex Bolt		4
Engine Assembly				F151	3/8-16 x 7/8 Hex Bolt		2
13	5845	Rubber Bumper (1.50 x 1.25)	1	F175	1/2 Split Lock Washer		4
14	8010-2	Engine Bumper Mount	1	F184	1/4-20 x 1/2 Hex Bolt, SS		3
15	NS	Oil Filter	1 ^Δ	F185	1/4 Int. Star Lock Washer, SS		3
16	NS	19 HP Engine, EFI (Kohler)	1	F198	.250 x .625 x .040 Washer, SS		3
Remote Oil Cooler Assembly				F273	M6 x 1.0 Nut		4
17	NS	Clamp	4***	F285	1/2-13 x 1-1/2 Hex Bolt		4
18	NS	Oil Cooler Hose	2***	F482	8-32 Nylock Nut		2
19	NS	Oil Cooler	1***	F483	8-32 x 3/4 PPHMS		2
20	8016-8	Oil Cooler / Regulator Mount	1	F547	M6 x 1.0 x 45 Stud		2
Exhaust Assembly				F570	3/8-16 Flange Top Lock Nut		1
21	NS	Gasket (Kohler)	2***	F646	3/8-16 x 3/4 Serrated Hex Bolt		2
22	NS	Nut (Kohler)	4***	* Service Part Only			
23	6013-14	Muffler	1	** Required hose specifications: M258 - 7/64" ID automotive vacuum hose			
24	6013-18	Muffler Heat Shield	1	*** Use the engine model and spec number from Kohler to order this item.			
25	6013-19	Muffler Brace	1	Δ Refer to the Operator's Manual for recommended part number.			
26	8021-2	Engine Brace, Chassis	1	NOTE: Refer to Kohler Engine Decal (NS) for Engine Identification Numbers.			
27	8021-1	Engine Brace	1				
28	NS	Sensor, Oxygen (Kohler)	1				

ENGINE GROUP




ENGINE GROUP (FUEL COMPONENTS)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Fuel Tank Assembly				Fasteners			
1	8018-4	Fuel Module Cover	1	F002	10-24 Keps Nut		4
2	8018-7	Fuel Module Bracket	1	F004	1/4-20 Keps Nut		3
3	8018-2	Fuel Bracket Spacer	3	F009	5/16-18 Whiz Locknut		2
4	M113	Fuel Line (3/16 x 12")	1**	F025	10-24 x 3/8 PPHMS		2
5	5879-4	Hose Clamp (7/16)	1	F029	1/4-20 x 1/2 Hex Bolt		2
6	8046-16	Quick Connector 5/16 x 5/16 - 45°	1	F034	5/16-18 x 3/4 Hex Bolt		2
7	5879-2	Hose Clamp (7/16 Silver)	2	F050	1/4 SAE Washer		3
8	5879-9	Stepless Ear Clamp, Black (15.7)	2	F061	1/4 Internal Star Lock Washer		2
9	M246	Fuel Line (1/4 x 6")	1**	F079	A/A66D Aluminum Pop Rivet		1
10	5975-3	Cable Tie (50# x 7")	2	F128	10-24 x 3/8 PTHMS		1
11	M247	Fuel Line (5/16 x 6")	1**	F129	10-24 x 1/2 PTHMS		1
12	5879-3	Hose Clamp (1/2)	4	F398	1/4-20 x 2 Hex Bolt		3
13	8046-14	Quick Connector, Male (5/16)	1				
14	NS	Clamp (Kohler)	1	* Service Part Only			
15	8123	Insulating Sleeve (3/8 x 6)	1				
16	M246	Fuel Line (1/4 x 23")	1**	** Required hose specifications:			
17	5020-3	Fuel Filter	1	M113 - 3/16" ID fuel/oil/vapor hose (Gates 4219-0093 or equivalent)			
18	7833	Cable Clamp (7/8 x 1/4)	1	M246 - 1/4" ID low permeation (<15g/m ² /day) fuel hose (Parker 38904 or equivalent)			
19	6055-2	Fuel Tank, 4.0 Gallon, Gas (Includes Items # 20, 21, 24, 26, 28 & 29)	1	M247 - 5/16" ID low permeation (<15g/m ² /day) fuel hose (Parker 38905 or equivalent)			
20	5086-7	Hose (1/4 x 6)	1				
21	5020-2	Fuel Filter, In Tank	1				
22	8023	Fuel Tank Support	1				
23	5082-4	2-1/4 Ratchet Fuel Cap	*				
24	8043-8	Roll Over Valve	1				
25	M113	Fuel Line (3/16 x 26")	1**				
26	5977-7	Roll Over Grommet (.900 x 1-1/2)	1				
27	5083-1	Bushing, Rubber	*				
28	8055-2	Fuel Tank Gauge	1				
29	5083-8	Tank Tube (13")	1				
30	M246	Fuel Line (1/4 x 20")	1**				
31	8016-6	ECU Mount	1				

NOTE: Refer to Kohler Engine Decal (NS) for Engine Identification Numbers.


ENGINE GROUP (FUEL COMPONENTS)



HYDROSTATIC GROUND DRIVE ASSEMBLIES

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
TOPS™ Components				40	5028-5	Lockout Lever	2
1	5024-22	3/8 Hose Barb x #6/ORB 90 Degree	2	41	5027-5	Lockout Mount	1**
2	5879-11	Hose Clamp (16mm)	6	Deck Support Arm Assemblies			
3	M358	High Temp Hose (3/8" x 8-1/4")	1	42	6430-10	Outboard Mount, LH	1
4	5024-30	Pulley	1	43	6431-1	Deck Support Arm, LH (Includes Item # 47)	1
5	5025-51	Hydro Pump Assembly (Includes Items # 7 & 19)	1	44	5775-2	Hitch Pin (# 6)	2
6	M358	High Temp Hose (3/8" x 8-3/4")	1	45	6431-2	Deck Support Arm, RH (Includes Item # 47)	1
7	5024-15	1/4-18 Pipe Thread, 3/8 Barb Fitting	2	46	6430-9	Outboard Mount, RH	1
8	5024-13	Transmission Oil Filter	1	47	5830	Grease Fitting	2
9	5975-3	Cable Tie (50# x 7")	1	48	6840-1	Support Arm Bushing (2-1/16)	2
10	6206-1	Air Vent Valve	3	Transmission Repair Parts			
11	5024-27	1-1/16"-12 Socket Plug Reservoir Cap	1	49	5025-16	Control Shaft Repair Kit	*
12	5024-25	Oil Reservoir Sight Gauge	1	50	5025-13	Hydro Input Shaft / Repair Kit (Includes Items # 51-53)	*
13	5024-9	90 Degree Fitting W/Filter	1	51	5025-8	Bearing, Input Shaft	*
14	5025-42	Oil Tank Reservoir Assembly (Includes Items # 7, 10-13 & 15-16)	1	52	5025-7	Snap Ring	*
15	7427-12	Brass Pipe Plug (1/4 NPTF)	1	53	NS	Seal, Input Shaft	*
16	5024-23	90 Degree Male Fitting, 3/8 Barb 1/4 Thread	1	54	5025-53	O-Ring & Plug	*
17	M358	High Temp Hose (3/8" x 6-1/2")	1	Fasteners			
18	5024-11	Left Hand Hose (7-3/8")	1	F004	1/4-20 Keps Nut		4
19	5024-10	Elbow, 90 Degree (1/2-20 x 9/16-18)	4	F012	3/8-16 Keps Nut		2
20	5022	Reservoir/Casting Gasket	2	F023	10-24 ESNA Nut		2
21	5024-7	Transmission Reservoir Adapter Fitting	2	F027	10-24 x 5/8 PPHMS		2
22	5024-12	Right Hand Hose (9-3/8")	1	F029	1/4-20 x 1/2 Hex Bolt		2
Ground Drive Assemblies				F032	1/4-20 x 3/4 Hex Bolt		3
23	6209-11	Bridge Spacer Plate	1	F040	3/8-16 x 1-1/2 Hex Bolt		4
24	6209-8	Bridge Assembly (Includes Items # 23, F004, F032 & F120)	1***	F043	3/8-16 x 3 Hex Bolt		6
25	6243-6	Fan Guard	1	F053	7/16 Internal Star Lock Washer		4
26	6243-1	Hydro Fan, CW	1	F063	3/8 Internal Star Lock Washer		17
27	7244	Hydro Pulley (3-7/8/MV) (Includes Items # F064 & F359)	2	F064	1/8 x 1/2 Woodruff Key (#3)		4
28	5026-34	Hydrostatic Drive, CW	1	F081	A/A45D Aluminum Pop Rivet		2
29	6200-9	Gear Axle Drive Assembly (Includes Items # 10 & 30)	2	F120	AN960416 Washer		2
30	6207-12	Pipe Plug (1/4 NPTF)	4	F160	External Snap Ring (.669 Shaft)		2
31	5126	Cable Retainer (Uses existing bolt on Gear Axle Drive Assembly)	1	F178	1/4 x 1 Fender Washer		2
32	6233-1	Pinion Gear	2	F182	1/4 x 5/8 x 1/8 Washer		1
33	6234	Spacer, Pinion Gear	2	F194	7/16 x 1-1/4 x 1/8 Washer		2
34	6201	O-Ring Seal	2	F200	7/16-20 x 3 Grade 8 Bolt		2
35	5025-34	Hydrostatic Drive, CCW	1	F211	1/4-20 x 7/8 Hex Bolt		2
36	6243-2	Hydro Fan, CCW	1	F244	7/16-20 x 3/4 Hex Bolt		2
Transmission Lockout Assembly				F262	3/8-16 x 4 Hex Bolt All Thread		2
37	5028-3	Transmission Lockout Assembly (Includes Items # 38-41, F023, F027 & F081)	*	F359	5/16-18 x 5/16 Set Screw (Knurl Point)		4
38	5847	Plastic Tip	2	F398	1/4-20 x 2 Hex Bolt		4
39	5057	Lockout Cam (Includes Item # F081)	2	F569	1/4-20 Flange Top Lock Nut		3
				F579	3/8-16 x 1 Hex Bolt Grade 8		4
				F659	1/8 x 1/8 x 3/4 Key		1
				F669	1/4-20 x 5/8 Hex Bolt W/Loctite		1
				* Service Part Only			
				** Part not used on Jackshaft side of tractor.			
				*** Includes Spacer Options—See Advisory Bulletin #23300.			

HYDROSTATIC GROUND DRIVE ASSEMBLIES




STEERING CONTROL ASSEMBLIES

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Transmission Spring Assemblies				Steering Lever Assemblies			
1	6201-4	Shock Mount Gear Drive, RH	1	32	5217-1	Pivot Pin, Steering Lever	1
2	5146	10mm Ball Stud	4	33	5391-3	Steering Lever Support	1
3	5199-4	Steering Lever Dampener Assembly	2	34	5225-4	Extension Spring (5/8 x 2)	2
4	6201-3	Shock Mount Gear Drive, LH	1	35	5451-12	Steering Lever Assembly, LH / Adjustable (Includes Items # 2, 9-11, 16, 34, F009, F034 & F582)	1
5	5214-2	Ball Joint (5/16-24) Nylon Lined	2	36	5453-14	Steering Lever Handle, Adjustable (Includes Items # 14 & F345)	2
6	6212-7	Transmission Control Arm, LH	1	37	5450-12	Steering Lever Assembly, RH / Adjustable (Includes Items # 2, 9-11, 16, 34, F009, F034 & F582)	1
7	5213-3	Control Rod (6")	1	Fasteners			
8	5665-1	Compression Spring (2-1/2)	2	F004	1/4-20 Keps Nut		5
9	7201-2	Fiberglide Bearing 1/2"	2	F007	5/16-18 Jam Nut		2
10	5463-5	Steering Arm Pivot Bearing (SS)	2	F009	5/16-18 Whiz Locknut		7
11	5463-7	Steering Lever Actuator	2	F010	5/16-24 ESNA Nut		4
12	5213-4	Control Rod (14-3/4")	1	F012	3/8-16 Keps Nut		2
13	5212-7	Transmission Control Arm, RH	1	F024	5/16-24 Jam Nut		4
Forward Speed Control Assemblies				F029	1/4-20 x 1/2 Hex Bolt		2
14	5850-2	Handle Grip, Foam (5-1/2)	3	F031	1/4-20 x 5/8 Hex Bolt		1
15	7170-2	FSC Lever Assembly (Includes Item # 16)	1	F032	1/4-20 x 3/4 Hex Bolt		2
16	5830	Grease Fitting	6	F034	5/16-18 x 3/4 Hex Bolt		4
17	5975-3	Cable Tie (50# x 7")	1	F038	3/8-16 x 1 Hex Bolt		2
18	5214-4	Ball Joint (5/16-24) W/O Stud	2	F050	1/4 SAE Washer		1
19	5219	Extension Spring (3/4 x 6-3/4)	1	F051	3/8 SAE Washer		2
20	5172	Bearing, Delrin (.250 x .375 x .250)	2	F064	1/8 x 1/2 Woodruff Key (#3)		2
21	5141-1	FSC Actuator Block	1	F069	3/32 x 1/2 Cotter Pin		1
22	5140-9	FSC Brace	1	F146	1/4-20 Jam Nut		1
23	5141	FSC Friction Washer (1-1/2 x 3/8 x 1/16)	2	F182	1/4 x 5/8 x 1/8 Washer		1
24	5142-8	FSC Key	1	F183	.312 x .700 x .074 Washer		3
	5140-25	FSC Control Assembly (Includes Items # 16, 23-25, 28, F182, F192 & F193)	*	F186	5/64 x 1/2 Cotter Pin		1
25	5140-35	FSC Friction Body (Includes Item # 16)	1	F188	1/4-20 Self-Locking Nut		4
26	5141-2	FSC Actuator Rod	1	F192	3/8-24 Self-Locking Nut		1
27	5281-5	Clevis Pin (1/4 x 0.80)	1	F193	3/8 Belleville Spring Washer		3
28	5142-9	FSC Actuator Cam	1	F198	.250 x .625 x .040 Washer, SS		2
29	5141-3	Spacer (.750 x .313 x .688)	1	F226	5/16-18 x 7/8 Hex Bolt		1
30	5141-4	FSC Rod	1	F316	5/16-18 x 1-3/4 Hex Bolt		1
31	5470-2	Speed Control Stop	1	F345	1/4-20 x .770 Knurled Bolt		4
				F350	1/4-20 LP Nylock		1
				F353	3/8-16 ESNA LP Nut		2
				F401	.504 x .751 x .030 Washer		1
				F562	5/16-18 x 1 Set Screw		2
				F582	Washer 5/16 x 7/8 x .125		2

* Service Part Only

STEERING CONTROL ASSEMBLIES




Model C19i Beginning S/N 187255
Use only genuine **Walker®** replacement parts.

THROTTLE CONTROL ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Throttle Control Assembly				Fasteners			
1	5108-5	Throttle Control Knob, Red	1	F002	10-24 Keps Nut		1
2	5108-31	Control Lever	1	F085	3/16 Rivet Backup Washer		1
3	5108-10	Friction Washer (.125)	2	F202	10-24 x 5/8 SHC Screw GR 5		1
4	5108-29	Control Bracket	1	F350	1/4-20 LP Nylock		1
5	5172-6	Bushing, SS (.375 x .188 x .290)	1	F638	1/4-20 x 1 Carriage Bolt		1
6	8121-1	Throttle Cable	1	F642	1/4 x .042 Belleville Washer		1
7	8123	Insulating Sleeve (3/8 x 6)	1				
8	5975-1	Cable Tie (18# x 3-3/4")	2				


THROTTLE CONTROL ASSEMBLY



PARKING BRAKE ASSEMBLY


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Parking Brake Assembly				Fasteners			
1	7406-1	Handle Grip, Red	1	F002	10-24 Keps Nut		2
2	7406-9	Parking Brake Lever	1	F003	1/4-28 Hex Nut		1
3	7406-10	Lever Mount	1	F004	1/4-20 Keps Nut		4
4	5830	Grease Fitting	1	F025	10-24 x 3/8 PPHMS		2
5	7407	Clevis Pin (3/16 x 1/2)	2	F029	1/4-20 x 1/2 Hex Bolt		3
6	7404-6	Brake Actuator Arm	2	F032	1/4-20 x 3/4 Hex Bolt		1
7	7405	Pin, Transmission Lock	2	F054	AN960616 Washer		2
8	7402	Clevis	2	F072	1/4 "E" Retainer Ring		2
9	7408	Compression Spring (1/2 x 3/4)	2	F086	#10 SAE Washer		4
10	7415	Rubber Dust Shield (5/8 x 3/8 x 1/32)	2	F109	1/8 x 5/8 Roll Pin		2
11	5567-3	O-Ring (1/4 x 3/8)	4	F111	1/8 x 3/4 Cotter Pin		1
12	7403	Plunger Bushing, Gear Axle	2	F112	5/8 x 1-1/4 x .03 Washer		2
13	7404-7	Brake Actuator Mount	2	F127	1/16 x 1/2 Cotter Pin		4
14	7412	Clevis Pin (3/16 x 5/8)	2	F261	AN960616L Washer		5
15	5833	Cable Clamp (1/4)	2	F287	1/4-28 Keps Nut		1
16	7410	Brake Control Cable, LH (25.5")	1				
17	7409	Brake Control Cable, RH (20.5")	1				
18	7401-3	Cable Mount Bracket	1				
19	7401-1	Cable Pull Rod	1				
20	5552	Ball Joint (1/4-28)	1				

PARKING BRAKE ASSEMBLY



GHS GROUP


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Delivery Chute Assembly				Fasteners			
1	5515-4	Elbow Delivery Spout	1	F002	10-24 Keps Nut		4
2	5592-24	Backing Plate, Grass-Pak® Switch	1	F004	1/4-20 Keps Nut		3
3	5592-23	Grass-Pak® Housing Spacer	1	F009	5/16-18 Whiz Locknut		7
4	5578	Rear Clip, Chute Mount	1	F012	3/8-16 Keps Nut		3
5	5577	Side Clip, Chute Mount	2	F023	10-24 ESNA Nut		2
6	7511-5	Outside Chute Cover Lip	1	F029	1/4-20 x 1/2 Hex Bolt		3
7	7511-4	Inside Chute Cover Lip	1	F034	5/16-18 x 3/4 Hex Bolt		1
8	5511-3	Delivery Chute W/Clips, 7.0 (Includes Items # 4, 5 & F411)	1	F039	3/8-16 x 1-1/4 Hex Bolt		1
9	7530-4	Body Chute (10.5 Blower)	1	F040	3/8-16 x 1-1/2 Hex Bolt		1
Blower Belt Tightener Assembly				F042	3/8-16 x 2-1/4 Hex Bolt		1
				F050	1/4 SAE Washer		1
				F051	3/8 SAE Washer		1
				F054	AN960616 Washer		1
10	7238-6	Blower Drive Pulley (Includes Items # F075, F114 & F231)	1	F067	3/16 x 3/16 x 1 Key		1
11	7234-2	Blower Belt (Micro-V)	1	F075	5/16-18 x 1/2 SQH Set Screw		2
12	7239-1	Blower Pulley (Micro-V) (Includes Items # F067, F075 & F114)	1	F079	A/A66D Aluminum Pop Rivet		2
13	7364-2	Torsion Spring	1	F090	1/4-20 x 2-1/2 Hex Bolt		1
14	7201-3	Fiberglide Bearing	2	F114	5/16-18 x 5/8 SQH Set Screw		2
15	5830-3	Grease Fitting (45 Degree)	1	F128	10-24 x 3/8 PTHMS		4
16	7364-1	Blower Belt Tightener Arm	1	F131	5/16-18 x 1/2 Hex Bolt		3
17	7201-4	Inner Race (1-1/2)	1	F132	1/4-20 x 2-3/4 Hex Bolt		1
18	5841	Retainer Washer (3/8 x 1-1/4)	1	F168	5/16 Split Lock Washer		3
19	5245	Idler Pulley (3")	1	F217	7/16-14 Hex Nut		1
Blower Assembly				F218	7/16 Split Lock Washer		1
				F231	1/4 x 3/4 Woodruff Key (# 806)		1
				F281	7/16-14 x 1-3/4 Hex Bolt		1
20	7544	Blower Assembly (10.5") (Includes Items # 21-25, F004, F009, F029, F050, F131, F168 & F426)	*	F411	3/16 Bulbex Rivet		12
21	5268	Bearing W/Collar (3/4)	2	F426	1/4-20 x 1/2 Carriage Bolt		1
22	7544-3	Blower Housing (10.5")	1	F577	10-24 x 5/8 Carriage Bolt		2
23	7545-2	Blower Output Shaft (10.5")	1	* Service Part Only			
24	7545	Blower Wheel (10.5")	1	** Plugs Blower when GHS is not in use. Furnished only with Mulching Decks, SD Decks used on a GHS Tractor, Rotary Broom Attachment and Snowblower Attachment. Use of this part may be replaced by installing Blower Lockout Kit (P/N 7541-1).			
25	7543-1	Blower Faceplate (10.5")	1				
26	7526	Intake Tube (10.5" Blower)	1				
27	5595-2	Intake Cover, GHS	**				
28	7528-5	Skid Bar	1				



GHS POWERFIL® ASSEMBLY (7.0)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
7.0 GHS Powerfil® Assembly				Fasteners			
1	5552	Ball Joint (1/4-28)	2		F003	1/4-28 Hex Nut	2
2	5553-3	Bushing, Powerfil® Actuator	4		F023	10-24 ESNA Nut	10
3	5553-1	Compression Spring (1/2 x 2)	2		F054	AN960616 Washer	2
4	5558-2	Powerfil® Actuator Rod	1		F085	3/16 Rivet Backup Washer	1
	5549	Actuator Rod Assembly (Includes Items # 1-4, F003, F287 & F704)	*		F101	10-24 x 1-1/4 SHC Screw	1
5	5551-3	Bearing Cap, Powerfil®	1		F109	1/8 x 5/8 Roll Pin	1
6	5551-1	Pivot Bearing (#S3PP)	2		F287	1/4-28 Keps Nut	2
7	5518-6	Pivot, Delivery Spout	1		F612	10-24 x 5/8 Truss Head Torx	7
8	5517-2	Pivot Mount	1		F613	10-24 x 1/2 Truss Head Torx	2
9	5519-5	Actuator Motor (12V) (Includes Items # 10 & 11)	1		F704	1/4-28 x 6-1/2 Hex Bolt Grade 5, Clear Zinc	1
10	5519-2	Motor Mount Washer	*	* Service Part Only			
11	5519-3	Motor Mount Nut (5/8-24)	*				
12	5554	Actuator Arm	1				


GHS POWERFIL® ASSEMBLY (7.0)



GHS 7.0 BUSHEL CATCHER ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Upper Baffle Screen Assembly (Removable)				39	7510-2	7.0 Bushel Catcher Box	1
1	7512-12	Removable Screen (3/16 Hole) (Includes Items # 2, F190 & F617)	1**		7502-5	7.0 Catcher W/Powerfil® (Includes Door)	*
2	7506	Knob / Threaded Insert (10-24)	2	40	7607-8	Powerfil® Cover Plate	1
3	7509-7	Channel Top, LH	1	41	7608-4	Hinge Plate, RH	1
4	8606-2	Channel Bottom	2	42	8155-8	7.0 Gas Spring Cover, RH	1
5	6856-1	Edge Molding (21-3/4")	1	43	7607-14	Catcher Door Arm, RH	1
6	6507	Screen Seal (23-1/4")	1	44	7584-3	Reinforcing Strap	1
7	7505	Mustache Spring	2	45	5801-4	Decal Plate, Round	2
8	7509-6	C-Channel With Spring (Includes Items # 7 & F340)	1	46	7608-5	Door Arm Stop	2
9	7509-8	Channel Top, RH	1	5598-2 Optional Dump Bag (Not Shown)			
7.0 Exhaust Deflector Door Assembly				May be ordered as an option. Contact your Walker dealer.			
10	7607-3	Upper Door Seal	1	Fasteners			
11	7510-4	7.0 Catcher Box Door (Includes Frame) (Includes Items # 10, 12, 13, 15, F085, F411, F649 & F654)	1	F020	5/16-18 ESNA Nut		2
12	5583	Handle	1	F023	10-24 ESNA Nut		28
13	7607-6	Lower Door Stiffener (7.0)	1	F029	1/4-20 x 1/2 Hex Bolt		2
14	8607-8	Door Guide	1	F031	1/4-20 x 5/8 Hex Bolt		2
15	7607-5	Upper Door Stiffener	1	F049	5/16 SAE Washer		4
GHS 7.0 Bushel Catcher Assembly				F050	1/4 SAE Washer		4
16	7503-8	Center Strap (7.0)	1	F079	A/A66D Aluminum Pop Rivet		4
17	7503-6	Upper Frame Doubler (7.0)	2	F085	3/16 Rivet Backup Washer		10
18	7503-5	Lower Frame Doubler (7.0)	2	F094	8-32 x 1/2 PTHMS		6
19	7503-4	Outside Box Strap (7.0)	2	F190	#10 Internal Star Lock Washer		2
20	8608-4	Center Frame Doubler	1	F196	1/4-20 x 1 PPHMS, SS		4
21	8608-11	Catcher Door Finger	1	F230	1/4-20 x 1-1/4 PPHMS, SS		4
22	7503-11	Catcher Mount	1	F242	1/4-20 x 7/8 PPHMS, SS		8
23	7610-4	Catcher Dump Flap Spacer (7.0)	1	F275	5/16-18 x 2 Hex Bolt		2
24	7610-9	Catcher Dump Flap (7.0)	1	F340	Rivet, Aluminum		4
25	8610-3	Backing Plate / Dump Flap	1	F351	Aluminum Pop Rivet		6
26	7620-3	Pivot Bushing (1/2 x 9/16)	4	F360	1/4-20 x 3/8 Hex Bolt		2
27	7607-7	Bushing	2	F390	1/4-20 x 7/8 Carriage Bolt		4
28	7608-3	Hinge Plate, LH	1	F411	3/16 Bulbex Rivet		32
29	7607-15	Catcher Door Arm, LH	1	F442	1/4-20 x 5/8 PTHMS		2
30	8155-7	7.0 Gas Spring Cover, LH	1	F524	3/16 x 3/8 Aluminum Rivet, Black		8
31	5155-5	Gas Spring	2	F540	1/4-20 x 1-3/4 PPHMS, SS		1
32	5155-13	3/4 Ball Stud	2	F551	5/16-18 Flange Top Lock Nut		2
33	5523-6	Gas Spring Plate	2	F569	1/4-20 Flange Top Lock Nut		25
34	5155-12	5/16 Ball Stud	2	F612	10-24 x 5/8 Truss Head Torx		4
35	5155-15	Box Support, Gas Spring	2	F613	10-24 x 1/2 Truss Head Torx		10
36	7532-1	Handle, Catcher Lift	2	F617	10-24 x 3/8 Truss Head Torx		4
37	7511-6	Chute Cover	1	F618	10-24 x 3/4 Truss Head Torx		12
38	7557-1	7.0 Wire Harness Channel	1	F649	3/16 x .510/.625 Grip Range Rivet, SS		4
				* Service Part Only			
				** This screen can be replaced by P/N 7512-13 Removable Screen (3/4" holes) for improved air flow performance in wet conditions.			

GHS 7.0 BUSHEL CATCHER ASSEMBLY



ELECTRICAL ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Harness Assembly				Fasteners			
1	7941-3	Boot, Circuit Breaker	1	F002	10-24 Keps Nut		10
2	7941-5	Circuit Breaker (7 Amp)	1	F004	1/4-20 Keps Nut		4
3	8990-1	Hourmeter (Global)	1	F009	5/16-18 Whiz Locknut		1
4	8996-9	Red Indicator Light Assembly	1	F019	1/4-20 ESNA Wing Nut		2
5	5835-3	Cable Clamp (1/2) .218 Hole	3	F025	10-24 x 3/8 PPHMS		2
6	7834-2	Wire Saddle (2 Wires)	1	F026	10-24 x 1/2 PPHMS		7
7	6105-3	Harness Clip	1	F031	1/4-20 x 5/8 Hex Bolt		2
8	6104-12	Adapter Harness	1	F032	1/4-20 x 3/4 Hex Bolt		2
9	8960-15	Ignition Switch (With Keys) (Includes Items # 10, 11 & F349)	1	F050	1/4 SAE Washer		2
10	8960-3	Key Set W/Umbrella	1	F061	1/4 Internal Star Lock Washer		1
11	7854	Plastic Tip, Red	1	F079	A/A66D Aluminum Pop Rivet		1
12	8536-2	Warning Horn Assembly	1	F093	5/16-18 x 1 Hex Bolt		1
13	5942-8	Safety Switch (NO), Delta Side Mount	3	F129	10-24 x 1/2 PTHMS		1
14	5975-3	Cable Tie (50# x 7")	4	F182	1/4 x 5/8 x 1/8 Washer		2
15	6941-9	Relay Switch 30/40 Amp	3	F232	10-32 Keps Nut		2
16	7948-6	Time Delay Module (.5 Second Delay)	1	F349	Washer .835 ID 1.122 OD, SS		1
17	7948-3	Time Delay Harness	1	F505	6-32 x 7/8 Hex Trim MS, SS		6
18	8941	Circuit Breaker (30 Amp) Auto Reset / Sealed	1	F506	6-32 Nylock Nut		6
19	7941-10	Circuit Breaker Cap	1	* Service Part Only			
20	5832	Cable Clamp (1/2)	5				
21	6940-26	Wire Harness	1				
22	8018-3	Wire Extension	1				
23	NS	Rectifier	*				
24	8012-7	Ground Wire	1				
25	8012-5	Regulator Adapter Harness	1				
Battery Assembly							
26	8943	Battery Lead Wire (+)	1				
27	5975-1	Cable Tie (18# x 3-3/4")	3				
28	5844-3	Battery Hold-Down Bar	1				
29	5839	Hook Bolt	2				
30	6390-6	Battery Pan	1				
31	NS	Battery (12V/350 CCA/Wet/SP-40)	1				
32	5932	Battery Terminal Insul., Black (-)	1				
33	5933	Battery Terminal Insul., Red (+)	1				
34	6923	Battery Cable (-)	1				

[illegible]

ELECTRICAL ASSEMBLIES (GHS 7.0 BUSHEL COMPONENTS)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
-------------	-------------	-------------	--------------

Horn & Harness Channel Assemblies

1	5536-2	Horn, Full Signal	*
2	5976-2	Grommet (3/16 x 3/4)	2
3	5975-1	Cable Tie (18# x 3-3/4")	1

Harness & Grass-Pak® Switch Assemblies

4	8950-4	Powerfil Wire Harness (7.0/10.0)	1
5	5833	Cable Clamp (1/4)	2
6	5594-7	Grass-Pak® Vane	1
7	5592-20	Grass-Pak® Switch Assembly	1


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
-------------	-------------	-------------	--------------

Fasteners

F002	10-24 Keps Nut	1
F023	10-24 ESNA Nut	3
F025	10-24 x 3/8 PPHMS	1
F508	4-40 Keps Nut, SS	2
F612	10-24 x 5/8 Truss Head Torx	1
F613	10-24 x 1/2 Truss Head Torx	2
F712	4-40 x 3/8 Hex Head, SS	2
F713	Washer #4, SS	2

* Service Part Only


ELECTRICAL ASSEMBLIES (GHS 7.0 BUSHEL COMPONENTS)



LUBRICATION POINTS

ITEM NO.	LOCATION	LUBRICATION TYPE	NO. PLACES	ITEM NO.	LOCATION	LUBRICATION TYPE	NO. PLACES
Lubrication Points				17	Brake Actuator Rod and Brake Band Pivot Pins (Clevis)	Oil	3
1	Steering Lever Pivot	Grease	4	18	Brake Actuator Pivot	Grease	1
2	Body Hinge Point	Oil	2	19	Catcher Hinge Point	Oil	2
3	Deck-to-PTO Coupling (Grease Spline Slide Area)	Grease	1	20	Engine Dipstick / Oil Fill	Oil**	1
4	FSC Actuator Rod Pivot Pins	Oil	2	21	Throttle Control Cable Ends	Oil	2
5	(FSC) Friction Body Pivot	Grease	1	22	Belt Tightener Pivot, Blower Drive	Grease	1
6	FSC Lever Pivot	Grease	1	23	Belt Tightener Pivot, Ground Drive	Grease	1
7	Deck Support Arm Pivot	Grease	2	24	PTO Gearbox Dipstick	Oil**	1
8	Gear Axle	Oil**	2	25	Throttle Control Pivot	Oil	1
9	Universal Joint Tube Assembly	Grease*	1	* Grease every 25 hours.			
10	Parking Brake Lever Pivot	Grease	1	** See Operator's Manual for procedure for checking and changing oil in Engine Crankcase, Hydrostatic Transmissions, and Gear Axles.			
11	Universal Joint Quick Connect Spline (Grease Slide Area)	Grease	1	NOTE: See Model C19i Operator's Manual (P/N 6000-38) for proper lubrication intervals.			
12	Hydrostatic Drive / Oil Reservoir	Oil**	3				
13	Belt Tightener Pivot, Jackshaft Drive	Grease	1				
14	PTO Clutch Lever Pivot	Grease	1				
15	Clutch Actuator Push Rod	Grease	2				
16	Belt Tightener Pivot, PTO Clutch	Grease	1				

LUBRICATION POINTS



WIRING SCHEMATIC

WALKER MODEL C19i Beginning S/N 2019-154995


IGNITION SWITCH CIRCUITS	
OFF	G + M
START	B + A / S1 + S2
RUN	B + A

S1 = START CIRCUIT
S2 = START/ACCESSORY CIRCUIT
M = MAGNETO GROUND CIRCUIT
B = BATTERY CIRCUIT
A = ACCESSORY CIRCUIT
G = GROUND CIRCUIT

RELAY - A	
IGNITION RELAY	
OFF	30 + 87A
START	30 + 87A
PTO ON	30 + 87

RELAY - B	
START RELAY	
OFF	30 + 87A
START	30 + 87
PTO ON	30 + 87A

RELAY - C	
DELAY RELAY	
OFF	30 + 87A
START	30 + 87A
RUN	30 + 87A



MAINTENANCE AND SERVICE RECORD SHEET

[illegible]

MAINTENANCE AND SERVICE RECORD SHEET

[illegible]

LIMITED WARRANTY FOR WALKER COMMERCIAL RIDER MOWER

1. WHAT THIS WARRANTY COVERS, AND FOR HOW LONG:

Walker Manufacturing company will, at its option, repair or replace, without charge, any part covered by this warranty which is found to be defective in material and/or workmanship within two (2) years* after the date of sale to the original retail purchaser unless the product is used for rental purposes, in which case this warranty is limited to ninety (90) days. At Walker's request, customer will make the defective part available for inspection by Walker and/or return the defective part to Walker, transportation charges prepaid. All parts and components of the Walker Mower are covered by this warranty **except** the following components which are warranted separately by their respective manufacturers:

Kohler Engine

Battery

The available warranties covering these items are furnished with each mower. Walker does not assume any warranty obligation, liability or modification for these items, which are covered exclusively by the stated warranty of the respective manufacturers noted above.

* Extended warranties are offered for the following powertrain components:

- A three (3) year unlimited hour warranty is offered for the Walker P/N 6200-9 Gear Axle Assembly.
- A three (3) year or 3000 hour (whichever comes first) warranty is offered for Danfoss Model 7 Hydrostatic transmissions; covers full cost of replacement up to 1000 hours of use, and after 1000 hours warranty coverage is prorated against 3000 hours. If the transmissions are serviced at the recommended intervals by an authorized Walker Dealer using only Mobil SHC™ 630 oil (P/N 6450-20) and Walker filters (P/N 5024-13), the warranty will be extended to three (3) years, full replacement coverage, and unlimited hours.

2. WHAT THIS WARRANTY DOES NOT COVER:

- A. This warranty does not cover defects caused by depreciation or damage caused by normal wear, accidents, improper maintenance, improper use or abuse of the product, alterations, or failure to follow the instructions contained in the Operator's Manual for operation and maintenance.
- B. The customer shall pay any charges for making service calls and/or for transporting the mower to and from the place where the inspection and/or warranty work is performed.

3. HOW TO OBTAIN SERVICE UNDER THIS WARRANTY:

Warranty service can be arranged by contacting the dealer where you purchased the mower or by contacting Walker Manufacturing Company, 5925 East Harmony Road, Ft. Collins, CO 80528. Proof of the date of purchase may be required to verify warranty coverage.

4. WARRANTY LIMITATION:

- A. **THERE IS NO OTHER EXPRESS WARRANTY. ANY WARRANTY THAT MAY BE IMPLIED FROM THIS PURCHASE INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE IS HEREBY LIMITED TO THE DURATION OF THIS WARRANTY AND TO THE EXTENT PERMITTED BY LAW ANY AND ALL IMPLIED WARRANTIES ARE EXCLUDED.** Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.
- B. **WALKER WILL NOT BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES AND/OR EXPENSES IN CONNECTION WITH THE PURCHASE OR USE OF THE MOWER.** Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation(s) or exclusion(s) may not apply to you.
- C. Only the warranty expressed in this limited warranty shall apply and no dealer, distributor, or individual is authorized to amend, modify, or extend this warranty in any way. Accordingly, additional statements such as dealer advertising or presentations, whether oral or written, do not constitute warranties by Walker, and should not be relied upon.
- D. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.



WALKER

WALKER MFG. CO. • 5925 E. HARMONY ROAD, FORT COLLINS, CO 80528 • (970) 221-5614
FORM NO. 032624 PRINTED IN USA www.walker.com ©2024 WALKER MFG. CO