




WALKER

Illustrated Parts Manual

T30i



Beginning S/N: 147169
P/N 8000-26

KEY TO ABBREVIATIONS USED IN THIS MANUAL

<i>Abbreviation</i>	<i>What it Represents</i>
° (Dimension)	Degrees (Angle)
" (Dimension)	inches
(-)	Negative (Polarity)
(+)	Positive (Polarity)
AT	All-Terrain
CCW	Counter-clockwise
Conn.	Connector
CW	Clockwise
D	Diameter
DC	Deck, Collection (number refers to size in inches)
DM	Deck, Mulching (number refers to size in inches)
DR	Deck, Rear Discharge (number refers to size in inches)
DS	Deck, Side Discharge (number refers to size in inches)
DU	Garlock (Bearing)
ESNA (Fastener)	Nylon Insert Locknut
FSC	Forward Speed Control
GA	Gauge
gal	gallon
GHS	Grass Handling System
GR (Fastener)	Grade
HD	Heavy Duty
HP	Horse Power
ID	Identification or Inside Diameter
L	Length
LH	Left Hand (orientated with operator on seat)
LP	Low Profile
mm (Dimension)	millimeters
MS (Fastener)	Machine Screw
NS (as part number)	Item is not sold by Walker Manufacturing
OD	Outside Diameter
oz.	ounce
PFH (Fastener)	Phillips Flat Head
P/N	Part Number
PPH (Fastener)	Phillips Pan Head
PTH (Fastener)	Phillips Truss Head
PTO	Power Take-Off
QKS	Quick Slide
qt	quart
RH	Right Hand (orientated with operator on seat)
SAE (Fastener)	Society of Automotive Engineers
SBH (Fastener)	Socket Button Head (Bolt)
SD	Side Discharge
SFH (Fastener)	Slotted Flat Head
SHC (Fastener)	Socket Head Cap
SHL (Fastener)	Shoulder (Bolt)
SM (Fastener)	Sheet Metal (Screw)
S/N	Serial Number
Spg.	Spring
SQH (Fastener)	Square Head
SS (Fastener)	Stainless Steel
ST (Fastener)	Self-Tapping (Screw)
Term	Terminal
V	Volts

NOTE: In some instances, combinations of abbreviations may be used (e.g. PPHMS - Phillips Pan Head Machine Screw).

ILLUSTRATED PARTS LIST


<i>Section of Tractor Covered</i>	<i>Page</i>	<i>Section of Tractor Covered</i>	<i>Page</i>
Decals		Electrical Components	
Tractor Decals	2	Electrical Assembly	32
Body / Chassis Assemblies		Electrical Assembly (EFI Components)	34
Body / Chassis Assembly	4	Electrical Assemblies	
Rear Body Assembly	6	(GHS 10.0 Bushel Components)	36
Tractor Components		Electrical Connectors	38
Main Component Power Transmission	8	Maintenance	
Engine Group	10	Lubrication Points	40
Engine Group (Fuel Components)	12	Wiring Schematic	42
Radiator Group	14	Maintenance And Service Record Sheet	44
Hydrostatic Ground Drive Assemblies	16	Warranty	
Steering Control Assemblies	18	Limited Warranty	45
Throttle Control Assembly	20		
Parking Brake Assembly	22		
GHS Group	24		
GHS Powerfil® Assembly (10.0)	26		
GHS 10.0 Bushel Catcher Assembly	28		
Instrument Panel Assembly	30		

TRACTOR DECALS

ITEM NO.	PART NO.	DESCRIPTION	LOCATION	NO. REQ'D GHS
Walker Product and Operation Decals				
1	8600-33	RH Fender	Body, RH Side Near Seat	1
2	5800-11	Walker (8" Round)	10.0 Bushel Catcher (one on each side)	2
3	8821-12	Decal, T30i	Body	1
4	5856-1	Made in USA	Body	1
Danger Decals Warning Decals Caution Decals				
5	8600-34	Warning, Read Manual	Body	1
6	5810-3	Decal, Hydro Warning	LH Gear Axle Drive Assembly	1
7	8600-12	Danger, Engine Exhaust	Radiator Guard	1
8	8600-10	Danger, Pinch Point	10.0 Bushel Catcher Mounting Frame Assembly (one on each side)	2
9	8600-4	Danger, Rotating Blower Blades	Body, Near Body Chute	1
Maintenance Decals				
10	8600-30	Parking Brake	Body, RH Side Below Seat	1
11	5869	Removable Screen	10.0 Bushel Catcher Removable Screen	1
12	8600-16	Front Body Closure	Rear Cross Member, Body	1
13	7827	Oil Level	Jackshaft Support	1
14	5810-1	Axle Oil Level	Gear Axle Drive Assemblies (one on each)	2
15	8600-31	Throttle	Body, LH Side	1
16	6875	PTO Alignment Arrow	Universal Joint Tube Assembly	1
17	NS	Sealed Reservoir	Hydrostatic Drives (one on each)	2

NOTE: All parts requiring decals are shipped with decals applied.


TRACTOR DECALS



BODY / CHASSIS ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Seat Assembly				44	8038-1	Spacer, Tail Wheel Axle	2
1	6103-14	Suspension Seat	1	45	8037	Bearing Cone (3/4 ID)	4
2	6103-44	Grammer Seat Mount Channel, RH	1	46	8035	Tail Wheel & Tire Assembly (13 x 5.00-6)	2
3	6103-45	Grammer Seat Mount Channel, LH	1			(With Bearing Race)	
4	6105-1	Shoulder Washer	2		7035-1	Tail Wheel Tire (13 x 5.00-6)	*
Rear Bumper Assembly					8036	Wheel & Hub (6 x 3.25)	*
5	7516-7	GHS Rear Bumper	1			(Includes Items # 41 & Bearing Race)	
6	7516-5	Catcher Pivot Bushing	2		8037-2	Bearing Race	*
7	5162	Roller Wheel (5" Rubber)	2		7420-20	Dual Tail Wheel & Tire Assembly	*
8	7517-3	Catcher Pivot Plate	2			(Includes Items # 42-47)	
Body Assembly				47	8038	Tail Wheel Axle (3/4 x 10-3/8)	1
9	8531-19	Heat Guard	1	48	7070	Wheel & Tire Assembly (18 x 9.50-8)	2
10	8531-12	Body Grass Shield Assembly	1		7070-1	Drive Tire (18 x 9.50-8)	*
		(Includes Items # 9, F004, F050, F031 & F362)			5070-4	Wide Wheel (8 x 7)	*
11	7383-6	Body Latch Bracket, RH	1	49	5140-17	FSC Support	1
12	7383-5	Body Latch Lever	1	50	8300-17	Chassis Frame	1
13	7383-7	Body Latch Bracket, LH	1	Fasteners			
14	7222	Extension Spring (1/4 x 3)	1		F002	10-24 Keps Nut	1
15	7833-2	Cable Clamp (1 x 1/4)	1		F004	1/4-20 Keps Nut	9
16	5977-3	Grommet (9/16)	1		F009	5/16-18 Whiz Locknut	16
17	NS	Body ID Plate	1		F012	3/8-16 Keps Nut	6
18	5845	Rubber Bumper (1.50 OD x 1.25)	4		F014	3/8-16 ESNA Nut	4
19	7422	Panel Guard	1		F020	5/16-18 ESNA Nut	1
20	5989-4	Dome Plug (3/8)	4		F025	10-24 x 3/8 PPHMS	1
21	5989-3	Dome Plug (5/16)	2		F029	1/4-20 x 1/2 Hex Bolt	6
22	6105-3	Harness Clip	2		F031	1/4-20 x 5/8 Hex Bolt	3
23	7146	13mm Ball Stud	2		F034	5/16-18 x 3/4 Hex Bolt	2
24	7145	Gas Spring Assembly (Includes Item # 23)	1		F038	3/8-16 x 1 Hex Bolt	8
25	7844	Rubber Bumper (1.25 OD x .250)	1		F040	3/8-16 x 1-1/2 Hex Bolt	2
26	5989-9	Dome Plug (1/4)	4		F041	3/8-16 x 1-3/4 Hex Bolt	2
27	5180	Edge Molding, Lever Opening	2		F042	3/8-16 x 2-1/4 Hex Bolt	2
28	8100-9	Front Body	1		F050	1/4 SAE Washer	3
29	5989-55	Dome Plug (1/2)	1		F051	3/8 SAE Washer	2
30	5989-5	Dome Plug (7/16)	1		F059	3/8 Wave Spring Washer	2
Tilt-Up Latch Assembly**					F091	5/16-18 x 5/8 Hex Bolt	4
31	5847	Plastic Tip	1		F093	5/16-18 x 1 Hex Bolt	1
32	5744-20	Spring Arm, Tilt-Up Latch	1		F157	1/2-20 x 1-1/4 Wheel Lug Bolt	8
33	5744-10	Spring Pivot Bushing	1		F191	3/8 x 1-1/2 x 3/16 Washer	2
34	5744-15	Compression Spring (3/8 x 5/8)	1		F205	5/16-18 x 1/4 Set Screw, Knurl Point	2
35	5744-13	Mount Angle, LH	1		F206	#2 x 3/16 Drive Pin	2
36	5744-12	Hook, Tilt-Up Latch	1		F218	7/16 Split Lock Washer	2
37	5744-14	Mount Angle, RH	1		F219	7/16-14 x 1-1/4 Hex Bolt	2
Chassis Assembly					F226	5/16-18 x 7/8 Hex Bolt	4
38	5267-1	Retainer Collar (1")	1		F241	.375 x .875 x .10 Washer	4
		(Includes Item # F413)			F341	Coil Roll Pin (7/64 x 9/16)	1
39	5270-1	Pivot Bearing	2		F342	5/16 Conical Washer	2
40	7420	Tail Wheel Fork	1		F362	A/A62D Alum. Pop Rivet (3/16 D x 13/32 L)	6
41	5830-3	Grease Fitting (45 Degree)	2		F413	5/16-24 x 5/16 Set Screw	2
42	8039	Nut, Tail Wheel Axle	2		F570	3/8-16 Flange Top Lock Nut	4
43	8768-2	Seal, Reverse Lip	4	* Service Part Only			
				** Complete Tilt-Up Latch Assembly Kit available by ordering kit # 5747.			

BODY / CHASSIS ASSEMBLY



Beginning S/N 147169
Use only genuine **Walker®** replacement parts.

REAR BODY ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
-------------	-------------	-------------	--------------

Rear Body Assembly

1	8515-13	Catcher Handle Plate, LH	1
2	8515-14	Catcher Handle Plate, RH	1
3	8615-4	Catcher Support Frame, 10.0	1
4	7190-2	Insulation Foam Pad, RH	1
5	7190-1	Insulation Foam Pad, LH	1
6	5832	Cable Clamp (1/2)	1
7	8389-6	Splash Guard	1
8	7145	Gas Spring Assembly (Includes Items # 9 & 10)	1
9	7147	Spring Clip	2
10	7146	13mm Ball Stud	2
11	8082-2	Heat Shield, 10.0	1
12	7190-4	Insulation Foam Pad / GHS	1
13	8105-16	Rear Body Panel	1


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
-------------	-------------	-------------	--------------

Fasteners

F002	10-24 Keps Nut	12
F004	1/4-20 Keps Nut	5
F009	5/16-18 Whiz Locknut	2
F025	10-24 x 3/8 PPHMS	5
F026	10-24 x 1/2 PPHMS	7
F027	10-24 x 5/8 PPHMS	1
F031	1/4-20 x 5/8 Hex Bolt	2
F032	1/4-20 x 3/4 Hex Bolt	1
F085	3/16 Rivet Backup Washer	3
F178	1/4 x 1 Fender Washer	1
F390	1/4-20 x 7/8 Carriage Bolt	2

NOTE: Rear Bumper Assembly for GHS Models is not shown here. Refer to **BODY / CHASSIS ASSEMBLY**, Page 4.

REAR BODY ASSEMBLY



Beginning S/N 147169
Use only genuine **Walker®** replacement parts.

MAIN COMPONENT POWER TRANSMISSION

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Clutch Lever Assembly				41	6325-4	Spacer Bushing (3/16)	1
1	8358-3	Clutch Lever (Includes Items # 2 & 3)	1	42	7201-4	Inner Race (1-1/2)	2
2	5830	Grease Fitting	7	43	5221-1	Extension Spring (3/4 x 5)	2
3	4850	Handle Grip, Black	1	44	8539	Starter Relay Mount	1
4	7303-10	Clutch Actuator Bolt (3/8)	1	45	5268	Bearing W/Collar (3/4)	2
5	7380-5	Knuckle Joint (3/8 ID)	1	46	7241-2	Transmission Drive Pulley (3-1/4MV) (Includes Items # F067 & F171)	1
6	7226-10	Compression Spring (3/4 x 2-1/2)	1	47	7833	Cable Clamp (7/8 x 1/4)	1
7	8130-5	Pushrod, Clutch Actuator (Threaded Tube) (Includes Item # 2)	1	48	8349	Transmission Belt Tightener Arm	1
8	8130-10	Clutch Actuator Rod Assembly (Includes Items # 2, 4-7, F054, F336 & F353)	1	49	6325-2	Spacer Bushing (5/16)	1
9	7201-3	Fiberglide Bearing	6	50	8394-1	Hydro Jackshaft Mount Assembly (Includes Items # 2, 9, 42, 45, 50 & 51)	*
10	7201-5	Inner Race (2-1/4)	1	51	8273	Jackshaft (3/4 x 7-1/2)	1
11	8368	PTO Belt Tightener	1	52	7240-4	Jackshaft Drive Pulley (3.3/3V) (Includes Items # F067 & F171)	1
12	5841	Retainer Washer (3/8 x 1-1/4)	4	Fasteners			
13	8243-1	Clutch Idler Pulley	1	F003	1/4-28 Hex Nut		2
	8243	Clutch Idler Pulley Assembly (Includes Items # 13-15 & F070)	*	F004	1/4-20 Keps Nut		3
14	5265	Bearing (3/4)	1	F005	1/4-20 ESNA Nut		1
15	8243-3	Hub, Idler Pulley	1	F009	5/16-18 Whiz Locknut		3
16	8375	PTO Belt Tightener Stop	1	F012	3/8-16 Keps Nut		7
17	7377	Plastic Washer (1 x .438 x .025)	2	F029	1/4-20 x 1/2 Hex Bolt		1
18	7378	Pivot Bearing (7/16 x 9/16)	1	F040	3/8-16 x 1-1/2 Hex Bolt		1
19	5281-5	Clevis Pin (1/4 x 0.80)	2	F041	3/8-16 x 1-3/4 Hex Bolt		2
20	5280	Clevis (1/4)	2	F042	3/8-16 x 2-1/4 Hex Bolt		3
21	8305	Brake Actuator Rod	1	F043	3/8-16 x 3 Hex Bolt		1
22	8370	Bearing, Brake Actuator	1	F047	3/8-16 x 4-1/2 Hex Bolt		1
23	8250	Brake Spring (1/2 x 2-1/2)	1	F054	AN960616 Washer		3
24	8369	Brake Actuator (Includes Items # 2 & 22)	1	F061	1/4 Internal Star Lock Washer		1
PTO Drive Shaft Assembly				F067	3/16 x 3/16 x 1 Key		2
25	7050-1	Dipstick, Gearbox	1	F069	3/32 x 1/2 Cotter Pin		3
26	8371-1	Mount Bracket, Brake Band	1	F070	1-3/4 Internal Snap Ring		1
27	8377	Brake Band Guide	1	F090	1/4-20 x 2-1/2 Hex Bolt		1
28	8050-11	PTO Gearbox / Flange Pulley	1	F116	1/4-20 x 1-1/4 Hex Bolt		1
29	5245	Idler Pulley (3")	2	F121	5/16-18 x 3/8 x 1 SHL Bolt		1
30	7248	Ground Drive Belt, Micro-V	1	F131	5/16-18 x 1/2 Hex Bolt		2
31	7275-16	Universal Joint Tube Assembly / Spline	1	F132	1/4-20 x 2-3/4 Hex Bolt		1
32	7275-9	Quick Coupler Installation Tool	1	F168	5/16 Split Lock Washer		14
33	7523-2	Clevis Pin W/Hole (1/4 x 5/8)	1	F171	5/16-18 x 3/8 Set Screw		4
34	8304	Brake Band (14-1/2)	1	F178	1/4 x 1 Fender Washer		1
35	6250-1	Drive Belt (3VX370)	1	F182	1/4 x 5/8 x 1/8 Washer		2
36	7236-1	PTO Drive Pulley (4-1/2/3V) (Includes Items # F168 & F226)	1	F226	5/16-18 x 7/8 Hex Bolt		14
37	8237-2	Engine Pulley, Bolt On (4/3.8/3V) (Includes Items # F168 & F226)	1	F241	.375 x .875 x .10 Washer		1
38	8230	Engine PTO Belt	1	F255	5/16-18 x 1-1/2 Hex Bolt		2
Jackshaft Assembly				F261	AN960616L Washer		1
39	7245-1	Idler Pulley (3/8 Groove)	1	F336	3/8-16 Jam Nut		1
40	8349-3	Idler Arm	1	F353	3/8-16 ESNA LP Nut		1
				* Service Part Only			


This detailed exploded view diagram illustrates the assembly of a skid steer loader, showing the relationship between various components. The diagram is organized into several main sections:

- Top Section:** Shows the upper chassis and steering components, including the steering knuckle (1), tie rod (8), and various pins and bushings (e.g., F009, F054, F336, F353, F116, F182, F004, F043, F042, F070, F131, F226, F168).
- Middle Section:** Displays the engine (28) and transmission (29) assembly, along with the hydrostatic ground drive assemblies (31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52). These components are connected by a drive belt (30) and various pulleys (F005, F069, F040, F012, F171, F090, F004).
- Bottom Section:** Shows the main chassis frame (53) and the body/chassis assembly (54), which includes the rear axle (55) and various mounting brackets and fasteners (e.g., F003, F006, F007, F008, F010, F011, F013, F014, F015, F016, F017, F018, F019, F020, F021, F022, F023, F024, F025, F026, F027, F028, F029, F030, F031, F032, F033, F034, F035, F036, F037, F038, F039, F040, F041, F042, F043, F044, F045, F046, F047, F048, F049, F050, F051, F052, F053, F054, F055, F056, F057, F058, F059, F060, F061, F062, F063, F064, F065, F066, F067, F068, F069, F070, F071, F072, F073, F074, F075, F076, F077, F078, F079, F080, F081, F082, F083, F084, F085, F086, F087, F088, F089, F090, F091, F092, F093, F094, F095, F096, F097, F098, F099, F100, F101, F102, F103, F104, F105, F106, F107, F108, F109, F110, F111, F112, F113, F114, F115, F116, F117, F118, F119, F120, F121, F122, F123, F124, F125, F126, F127, F128, F129, F130, F131, F132, F133, F134, F135, F136, F137, F138, F139, F140, F141, F142, F143, F144, F145, F146, F147, F148, F149, F150, F151, F152, F153, F154, F155, F156, F157, F158, F159, F160, F161, F162, F163, F164, F165, F166, F167, F168, F169, F170, F171, F172, F173, F174, F175, F176, F177, F178, F179, F180, F181, F182, F183, F184, F185, F186, F187, F188, F189, F190, F191, F192, F193, F194, F195, F196, F197, F198, F199, F200, F201, F202, F203, F204, F205, F206, F207, F208, F209, F210, F211, F212, F213, F214, F215, F216, F217, F218, F219, F220, F221, F222, F223, F224, F225, F226, F227, F228, F229, F230, F231, F232, F233, F234, F235, F236, F237, F238, F239, F240, F241, F242, F243, F244, F245, F246, F247, F248, F249, F250, F251, F252, F253, F254, F255, F256, F257, F258, F259, F260, F261, F262, F263, F264, F265, F266, F267, F268, F269, F270, F271, F272, F273, F274, F275, F276, F277, F278, F279, F280, F281, F282, F283, F284, F285, F286, F287, F288, F289, F290, F291, F292, F293, F294, F295, F296, F297, F298, F299, F300, F301, F302, F303, F304, F305, F306, F307, F308, F309, F310, F311, F312, F313, F314, F315, F316, F317, F318, F319, F320, F321, F322, F323, F324, F325, F326, F327, F328, F329, F330, F331, F332, F333, F334, F335, F336, F337, F338, F339, F340, F341, F342, F343, F344, F345, F346, F347, F348, F349, F350, F351, F352, F353, F354, F355, F356, F357, F358, F359, F360, F361, F362, F363, F364, F365, F366, F367, F368, F369, F370, F371, F372, F373, F374, F375, F376, F377, F378, F379, F380, F381, F382, F383, F384, F385, F386, F387, F388, F389, F390, F391, F392, F393, F394, F395, F396, F397, F398, F399, F400, F401, F402, F403, F404, F405, F406, F407, F408, F409, F410, F411, F412, F413, F414, F415, F416, F417, F418, F419, F420, F421, F422, F423, F424, F425, F426, F427, F428, F429, F430, F431, F432, F433, F434, F435, F436, F437, F438, F439, F440, F441, F442, F443, F444, F445, F446, F447, F448, F449, F450, F451, F452, F453, F454, F455, F456, F457, F458, F459, F460, F461, F462, F463, F464, F465, F466, F467, F468, F469, F470, F471, F472, F473, F474, F475, F476, F477, F478, F479, F480, F481, F482, F483, F484, F485, F486, F487, F488, F489, F490, F491, F492, F493, F494, F495, F496, F497, F498, F499, F500, F501, F502, F503, F504, F505, F506, F507, F508, F509, F510, F511, F512, F513, F514, F515, F516, F517, F518, F519, F520, F521, F522, F523, F524, F525, F526, F527, F528, F529, F530, F531, F532, F533, F534, F535, F536, F537, F538, F539, F540, F541, F542, F543, F544, F545, F546, F547, F548, F549, F550, F551, F552, F553, F554, F555, F556, F557, F558, F559, F560, F561, F562, F563, F564, F565, F566, F567, F568, F569, F570, F571, F572, F573, F574, F575, F576, F577, F578, F579, F580, F581, F582, F583, F584, F585, F586, F587, F588, F589, F590, F591, F592, F593, F594, F595, F596, F597, F598, F599, F600, F601, F602, F603, F604, F605, F606, F607, F608, F609, F610, F611, F612, F613, F614, F615, F616, F617, F618, F619, F620, F621, F622, F623, F624, F625, F626, F627, F628, F629, F630, F631, F632, F633, F634, F635, F636, F637, F638, F639, F640, F641, F642, F643, F644, F645, F646, F647, F648, F649, F650, F651, F652, F653, F654, F655, F656, F657, F658, F659, F660, F661, F662, F663, F664, F665, F666, F667, F668, F669, F670, F671, F672, F673, F674, F675, F676, F677, F678, F679, F680, F681, F682, F683, F684, F685, F686, F687, F688, F689, F690, F691, F692, F693, F694, F695, F696, F697, F698, F699, F700, F701, F702, F703, F704, F705, F706, F707, F708, F709, F710, F711, F712, F713, F714, F715, F716, F717, F718, F719, F720, F721, F722, F723, F724, F725, F726, F727, F728, F729, F730, F731, F732, F733, F734, F735, F736, F737, F738, F739, F740, F741, F742, F743, F744, F745, F746, F747, F7

9

ENGINE GROUP

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Precleaner Assembly				33	8533-3	Muffler Base Shield	1
1	7026-2	Remote Precleaner (Includes Item # 5)	1	34	8533-4	Muffler Shield	1
2	7440	Shock Mount (1 x 3/4)	3	35	8318-3	Engine Brace	1
3	7028-20	Rear Precleaner Mount	1	36	8531-10	Rear Muffler Heat Shield	1
4	7032	Elbow, Precleaner	1	37	NS	Oxygen Sensor (Kohler)	1
5	7840-5	Hose Clamp (1-1/2 to 2)	3	38	NS	Gasket (Kohler)	2
6	5091-2	Air Flow Indicator (Vacuum 10" H2O)	1	39	NS	Nut (Kohler)	4
7	5091-4	Indicator Nipple	1	Fasteners			
8	5088-12	Air Cleaner Assembly (Includes Items # 6, 7 & 10-14)	*	F002	10-24 Keps Nut		4
9	5088-3	Air Cleaner Band	1	F004	1/4-20 Keps Nut		3
10	5090-3	Safety Filter Insert	1	F009	5/16-18 Whiz Locknut		11
11	5090-1	Air Cleaner Cartridge	1	F012	3/8-16 Keps Nut		8
12	5088-5	Air Cleaner Draw Latch	2	F025	10-24 x 3/8 PPHMS		1
13	5088-11	Air Cleaner Cap (Includes Item # 12)	1	F028	10-24 x 3/4 PPHMS		2
14	5090-2	Vacuator Valve	1	F032	1/4-20 x 3/4 Hex Bolt		3
15	7334-1	Air Cleaner Adapter Plate	1	F038	3/8-16 x 1 Hex Bolt		3
16	6029	Hose Clamp (1-3/4 to 2-1/4)	2	F041	3/8-16 x 1-3/4 Hex Bolt		4
17	8026-10	Air Hose, Cleaner	1	F050	1/4 SAE Washer		2
18	7031-3	Tube Support Arm	1	F051	3/8 SAE Washer		4
19	7028-6	Precleaner Tube, 1-3/4 GHS	1	F053	7/16 Internal Star Lock Washer		2
Engine Assembly				F061	1/4 Internal Star Lock Washer		1
20	7306-15	Water Temperature Sender	1	F063	3/8 Internal Star Lock Washer		1
21	7306-17	Temperature Sender Adapter	1	F091	5/16-18 x 5/8 Hex Bolt		5
22	NS	Oil Filter (Kohler 1205001)	1	F128	10-24 x 3/8 PTHMS		1
23	NS	30 HP Kohler EFI Engine	1	F129	10-24 x 1/2 PTHMS		4
24	8016-2	Regulator Mount	1	F132	1/4-20 x 2-3/4 Hex Bolt		1
25	NS	Screw (Kohler)	1	F140	7/16-14 x 1 Hex Bolt		2
26	NS	Regulator (Kohler)	1	F151	3/8-16 x 7/8 Hex Bolt		1
Exhaust Assembly				F187	1/4-20 x 1-1/2 Hex Bolt		2
27	5665	Compression Spring (1/2 x 1)	2	F188	1/4-20 Self-Locking Nut		2
28	8013-38	Muffler	1	F396	10-24 x 1-1/4 PPH Bolt		1
29	8532-5	Upper Grass Shield	1	F511	10-32 x 1/2 HWH Trilobe Screw		1
30	8532-2	Rear Shield	1	* Service Part Only			
31	8530-15	Muffler End Shield	1	NOTE: Refer to Kohler Engine Decal (NS) for Engine Identification Numbers.			
32	8533-2	Top Shield	1				




Beginning S/N 147169
Use only genuine **Walker®** replacement parts.

ENGINE GROUP (FUEL COMPONENTS)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Fuel Tank Assembly				27	5082-4	2-1/4 Ratchet Fuel Cap	1
1	7046-1	Fuel Return Tube	1	28	8055-2	Fuel Tank Gauge	1
2	5879-3	Hose Clamp (1/2)	2	29	5977-7	Roll Over Grommet (.900 x 1-1/2)	1
3	M111	Fuel Line (1/4 x 16")	1*	30	8043-8	Roll Over Valve	1
4	M247	Fuel Line (5/16 x 21")	1*	31	M113	Fuel Line (3/16 x 15")	1*
		Regulator To Filter (Includes Item # 5)		32	5975-1	Cable Tie (18# x 3-3/4")	1
5	5879-5	Stepless Ear Clamp (5/8)	7	33	5083-1	Bushing, Rubber	1
6	8026-14	Clamp, Loop Style	1	Fasteners			
7	NS	Fuel Filter (Kohler)	1		F002	10-24 Keps Nut	6
8	M247	Fuel Line (5/16 x 26") Filter to Engine	1*		F004	1/4-20 Keps Nut	4
9	M247	Fuel Line (5/16 x 16")	1*		F009	5/16-18 Whiz Locknut	4
		Pump To Regulator			F025	10-24 x 3/8 PPHMS	1
10	M113	Vent Tube, Regulator (3/16 x 4")	1*		F026	10-24 x 1/2 PPHMS	7
11	NS	Fuel Regulator (Kohler)	1		F029	1/4-20 x 1/2 Hex Bolt	4
12	7014-8	Regulator / Filter Mount	1		F031	1/4-20 x 5/8 Hex Bolt	2
13	7833	Cable Clamp (7/8 x 1/4)	1		F034	5/16-18 x 3/4 Hex Bolt	2
14	NS	Fuel Pump (Kohler)	1		F061	1/4 Internal Star Lock Washer	2
15	NS	Clamp (Kohler)	2		F255	5/16-18 x 1-1/2 Hex Bolt	2
16	7014-5	Fuel Pump Mount	1				
		(Includes Items # F002 & F004)		* Required hose specifications:			
17	7014-6	Fuel Pump Cover	1			M111 - 1/4" ID fuel/oil/vapor hose (Gates 4219-0103 or equivalent)	
18	5832	Cable Clamp (1/2)	1			M113 - 3/16" ID fuel/oil/vapor hose (Gates 4219-0093 or equivalent)	
19	8023	Fuel Tank Support	1			M247 - 5/16" ID low permeation (<15g/m ² /day) fuel hose (Parker 38905 or equivalent)	
20	M247	Fuel Line (5/16 x 8") Tank to Pump	1*	NOTE: Refer to Kohler Engine Decal (NS) for Engine Identification Numbers.			
21	7014-7	Fuel Line Guard	1				
22	5083-2	Tank Tube Elbow	1				
23	5083-4	Plug Bushing (Viton)	1				
24	5086-7	Hose (1/4 x 6")	1				
25	5020-2	Fuel Filter, In Tank	1				
26	8055-1	Fuel Tank, 4.7 Gallon, Gas (Black)	1				
		(Includes Items # 1, 23-25, 28-30 & 33)					

RADIATOR GROUP

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Radiator Assembly				Fasteners			
1	7017-12	Upper Radiator Hose, RH	1		F002	10-24 Keps Nut	6
2	7840-3	Hose Clamp (1/2 to 1-1/4)	4		F004	1/4-20 Keps Nut	4
3	8531-13	Tee Coupling	1		F014	3/8-16 ESNA Nut	2
4	7833-2	Cable Clamp (1 x 1/4)	2		F025	10-24 x 3/8 PPHMS	2
5	7017-11	Upper Radiator Hose, LH	1		F026	10-24 x 1/2 PPHMS	3
6	8123-2	Insultherm (1 x 6)	1		F028	10-24 x 3/4 PPHMS	1
7	7840-4	Hose Clamp (3/4 to 1-1/2)	2		F029	1/4-20 x 1/2 Hex Bolt	5
8	7017-6	Lower Radiator Hose	1		F031	1/4-20 x 5/8 Hex Bolt	6
9	7432	Shock Mount (1.00 OD x .75)	1		F032	1/4-20 x 3/4 Hex Bolt	6
10	7426-3	Rubber Isolator Mount	1		F061	1/4 Internal Star Lock Washer	14
11	7426-5	Screen Channel	2		F073	1/4 x 1.5 Fender Washer	2
12	7426-7	Radiator Brace	1		F129	10-24 x 1/2 PTHMS	4
13	7425-3	Radiator Screen	1		F132	1/4-20 x 2-3/4 Hex Bolt	2
14	7426-8	Screen Stop	2		F350	1/4-20 LP Nylock	2
15	7431-2	Radiator Channel Seal	2		F360	1/4-20 x 3/8 Hex Bolt	1
16	7427-9	Radiator Cap	*		F477	1/4-20 x 5/8 Carriage Bolt	2
17	7427-13	Radiator	1				
18	7426-6	Radiator Fan Shroud	1	*	Service Part Only		
19	7427-22	Fan Mount Tab, RH	2				
20	7429-6	Radiator Cooling Fan	*				
21	7429-7	Fan Blade Replacement	*				
22	7427-21	Fan Mount Tab, LH	2				
23	8532-2	Rear Shield	1				
24	8531-6	Lower Shield	1				
25	7430-6	Radiator Guard	1				
26	7430-11	Radiator Guard Flap	1				
27	7430-10	Back Up Plate	1				
28	7426-4	Radiator Mount	1				
29	7434	Washer (3/8 x 1-1/4 x 1/4)	4				
30	5841	Retainer Washer (3/8 x 1-1/4)	2				
31	7427-3	Coolant Recovery Tank	1				
32	7427-10	Recovery Tank Mount	1				
33	7427-11	Recovery Tank Keeper	1				
34	7015-13	Recovery Tank Hose (25")	1				
35	5975-3	Cable Tie (50# x 7")	3				



Beginning S/N 147169
Use only genuine **Walker®** replacement parts.

HYDROSTATIC GROUND DRIVE ASSEMBLIES

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
----------	----------	-------------	-----------

Transmission Lockout Assembly

1	5028-3	Transmission Lockout Assembly (Includes Items # 2-5, F023, F027 & F081)	*
2	5847	Plastic Tip	2
3	5057	Lockout Cam (Includes Item # F081)	2
4	5028-5	Lockout Lever	2
5	5027-5	Lockout Mount	1**

Ground Drive Assemblies

6	6209-5	Bridge Assembly	1
7	6209-10	Idler Pulley Mount	1
8	6243-2	Hydro Fan, CCW	1
9	5026	Hydrostatic Drive, CW	1
10	6206-1	Air Vent Valve	*
11	6200-9	Gear Axle Drive Assembly (Includes Items # 10 & 12)	2
12	6207-12	Pipe Plug (1/4 NPTF)	4
13	5126	Cable Retainer (Uses existing bolt on Gear Axle Drive Assembly)	1
14	6233-1	Pinion Gear	2
15	6234	Spacer, Pinion Gear	2
16	6201	O-Ring Seal	2
17	7244	Hydro Pulley (3-7/8/MV) (Includes Items # F064 & F359)	2
18	6243-1	Hydro Fan, CW	1
19	5025	Hydrostatic Drive, CCW	1

Deck Support Arm Assemblies

20	6430-10	Outboard Mount, LH	1
21	6431-1	Deck Support Arm, LH (Includes Item # 25)	1
22	5775-2	Hitch Pin (# 6)	2
23	6431-2	Deck Support Arm, RH (Includes Item # 25)	1
24	6430-9	Outboard Mount, RH	1
25	5830	Grease Fitting	2
26	6840-1	Support Arm Bushing (2-1/16)	2

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
----------	----------	-------------	-----------

Transmission Repair Parts


27	5025-13	Hydro Input Shaft	*
28	5025-8	Bearing, Input Shaft	*
29	5025-7	Snap Ring	*
30	5025-2	Seal, Input Shaft	*
31	5022	Reservoir to Casting Gasket	*
32	5024	Reservoir Cap and Gasket	*
33	5023	Transmission Reservoir Kit	*
34	5023-1	Rubber Bladder	*
35	5025-6	O-Ring & Plug Assembly	*
36	5025-3	Seal, Control Shaft	*

Fasteners

F009	5/16-18 Whiz Locknut	2
F012	3/8-16 Keps Nut	2
F023	10-24 ESNA Nut	2
F027	10-24 x 5/8 PPHMS	2
F034	5/16-18 x 3/4 Hex Bolt	2
F036	1/4-20 x 1/2 SBH Screw	2
F040	3/8-16 x 1-1/2 Hex Bolt	4
F043	3/8-16 x 3 Hex Bolt	6
F053	7/16 Internal Star Lock Washer	4
F063	3/8 Internal Star Lock Washer	16
F064	1/8 x 1/2 Woodruff Key (#3)	4
F081	A/A45D Aluminum Pop Rivet	2
F160	External Snap Ring (.669 Shaft)	2
F178	1/4 x 1 Fender Washer	2
F194	7/16 x 1-1/4 x 1/8 Washer	2
F200	7/16-20 x 3 Grade 8 Bolt	2
F244	7/16-20 x 3/4 Hex Bolt	2
F262	3/8-16 x 4 Hex Bolt All Thread	2
F359	5/16-18 x 5/16 Set Screw (Unbrako Knurl Point)	4
F579	3/8-16 x 1 Hex Bolt Grade 8	4

* Service Part Only

** Part not used on Jackshaft side of tractor.




Beginning S/N 147169
Use only genuine **Walker®** replacement parts.

STEERING CONTROL ASSEMBLIES

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Transmission Spring Assemblies				Steering Lever Assemblies			
1	6201-2	Shock Mount Gear Drive, RH	1	32	5850-2	Handle Grip, Foam (5-1/2)	2
2	5146	10mm Ball Stud	4	33	5223	Extension Spring (1/4 x 5-1/2)	2
3	5199-3	Steering Lever Dampener Assembly	2	34	5450	D-Clip	2
4	6201-1	Shock Mount Gear Drive, LH	1	35	5451-11	Steering Lever Assembly, LH / Adjustable (Includes Items # 9-11, 21, F034 & F582)	1
5	5214-2	Ball Joint (5/16-24) Nylon Lined	2	36	5391-3	Steering Lever Support	1
6	6212-6	Transmission Control Arm, LH	1	37	5217	Pivot Pin, Steering Lever	1
7	5213-3	Control Rod (6")	1	38	5453-20	Steering Lever Handle +1" Adjustable / SS (Includes Items # 32, F188, F198 & F345)	2
8	5665-1	Compression Spring (2-1/2)	2	39	5450-11	Steering Lever Assembly, RH / Adjustable (Includes Items # 9-11, 21, F034 & F582)	1
9	7201-2	Fiberglide Bearing 1/2"	2	Fasteners			
10	5463-5	Steering Arm Pivot Bushing (SS)	2	F004	1/4-20 Keps Nut		4
11	5463-4	Steering Lever Actuator	2	F007	5/16-18 Jam Nut		1
12	5213-4	Control Rod (14-3/4")	1	F008	5/16-24 Keps Nut		2
13	5212-6	Transmission Control Arm, RH	1	F009	5/16-18 Whiz Locknut		7
Forward Speed Control Assemblies				F010	5/16-24 ESNA Nut		2
14	5862	FSC Knob	1	F012	3/8-16 Keps Nut		2
15	7170-1	FSC Lever Assembly (Includes Item # 21)	1	F024	5/16-24 Jam Nut		4
16	5975-3	Cable Tie (50# x 7")	1	F029	1/4-20 x 1/2 Hex Bolt		2
17	5214-4	Ball Joint (5/16-24) W/O Stud	2	F032	1/4-20 x 3/4 Hex Bolt		2
18	5219	Extension Spring (3/4 x 6-3/4)	1	F034	5/16-18 x 3/4 Hex Bolt		3
19	5172	Bearing, Delrin (.255 x .379 x .250)	2	F038	3/8-16 x 1 Hex Bolt		2
20	5141-1	FSC Actuator Block	1	F050	1/4 SAE Washer		1
21	5830	Grease Fitting	6	F051	3/8 SAE Washer		2
22	5140-9	FSC Brace	1	F064	1/8 x 1/2 Woodruff Key (#3)		2
23	5141	FSC Friction Washer (1-1/2 x 3/8 x 1/16)	2	F068	1/8 x 1 Cotter Pin		1
24	5142-8	FSC Key	1	F069	3/32 x 1/2 Cotter Pin		1
	5140-12	FSC Control Assembly (Includes Items # 21, 23-25, 28, F182, F192 & F193)	*	F093	5/16-18 x 1 Hex Bolt		1
25	5140-30	FSC Friction Body (Includes Item # 21)	1	F146	1/4-20 Jam Nut		1
26	5141-2	FSC Actuator Rod	1	F182	1/4 x 5/8 x 1/8 Washer		1
27	5281-5	Clevis Pin (1/4 x 0.80)	1	F183	.312 x .700 x .074 Washer		3
28	5142-9	FSC Actuator Cam	1	F186	5/64 x 1/2 Cotter Pin		1
29	5141-3	Spacer	1	F188	1/4-20 Self-Locking Nut		4
30	5141-4	FSC Rod	1	F192	3/8-24 Self-Locking Nut		1
31	5470-2	Speed Control Stop	1	F193	3/8 Belleville Spring Washer		3
				F198	.250 x .625 x .040 Washer, SS		2
				F226	5/16-18 x 7/8 Hex Bolt		1
				F316	5/16-18 x 1-3/4 Hex Bolt		1
				F345	1/4-20 x .770 Knurled Bolt		4
				F350	1/4-20 LP Nylock		1
				F353	3/8-16 ESNA LP Nut		2
				F401	.504 x .751 x .030 Washer		1
				F582	Washer 5/16 x 7/8 x .125		2

* Service Part Only

STEERING CONTROL ASSEMBLIES




Beginning S/N 147169
Use only genuine **Walker®** replacement parts.

THROTTLE CONTROL ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Throttle Control Assembly				Fasteners			
1	8108-3	Throttle Cable	1		F002	10-24 Keps Nut	2
2	5172	Bearing, Delrin (.255 x .379 x .250)	1		F005	1/4-20 ESNA Nut	1
3	5108-7	Control Lock Tab	1		F025	10-24 x 3/8 PPHMS	2
4	5108-10	Friction Washer (.125)	1		F050	1/4 SAE Washer	1
5	5108-1	Control Lever, Throttle & Choke	1		F129	10-24 x 1/2 PTHMS	1
6	5108-5	Throttle Control Knob, Red	1		F145	4-40 Keps Nut	2
7	5108-11	Friction Washer (.062)	1		F164	10-24 x 1/4 x 3/8 SHL Bolt	1
8	5108-8	Control Bracket	1		F201	1/4 Belleville Spring Washer	2
9	7108	Control Assembly	1		F491	4-40 x 3/8 PPHMS	2
		(Includes Items # 3-5, 7, 8 & F201)					
	8108	Throttle Control and Cable Assembly (Includes Item # 6)	*	*	Service Part Only		
10	8123	Insulation Sleeve (3/8 x 6)	1				
11	8108-8	Throttle Bracket	1				
12	5975-1	Cable Tie (18# x 3-3/4")	1				
13	8108-9	Cable Mount	1				
14	NS	Bolt (Kohler)	1				
15	NS	Wire Clamp	1				

THROTTLE CONTROL ASSEMBLY



PARKING BRAKE ASSEMBLY


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Parking Brake Assembly				Fasteners			
1	7406-1	Handle Grip, Red	1	F002	10-24 Keps Nut		2
2	7406-8	Parking Brake Lever (4-1/4)	1	F003	1/4-28 Hex Nut		1
3	7406-2	Lever Mount	1	F004	1/4-20 Keps Nut		4
4	5830	Grease Fitting	1	F025	10-24 x 3/8 PPHMS		2
5	7407	Clevis Pin (3/16 x 1/2)	2	F029	1/4-20 x 1/2 Hex Bolt		3
6	7404-6	Brake Actuator Arm	2	F032	1/4-20 x 3/4 Hex Bolt		1
7	7405	Pin, Transmission Lock	2	F054	AN960616 Washer		2
8	7402	Clevis	2	F072	1/4 "E" Retainer Ring		2
9	7408	Compression Spring (1/2 x 3/4)	2	F086	#10 SAE Washer		4
10	7415	Rubber Dust Shield (5/8 x 3/8 x 1/32)	2	F109	1/8 x 5/8 Roll Pin		2
11	5567-3	O-Ring Seal (1/4 x 3/8)	4	F111	1/8 x 3/4 Cotter Pin		1
12	7403	Plunger Bushing, Gear Axle	2	F112	5/8 x 1-1/4 x .03 Washer		2
13	7404-7	Brake Actuator Mount	2	F127	1/16 x 1/2 Cotter Pin		4
14	7412	Clevis Pin (3/16 x 5/8)	2	F261	AN960616L Washer		5
15	5833	Cable Clamp (1/4)	2	F287	1/4-28 Keps Nut		1
16	7410	Brake Control Cable, LH (25.5")	1				
17	7409	Brake Control Cable, RH (20.5")	1				
18	7401-3	Cable Mount Bracket	1				
19	7401-1	Cable Pull Rod	1				
20	5552	Ball Joint (1/4-28)	1				

Beginning S/N 147169
Use only genuine **Walker®** replacement parts.



GHS GROUP


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Delivery Chute Assembly				Fasteners			
1	5515-4	Elbow Delivery Spout	1	F002	10-24 Keps Nut		6
2	5592-24	Backing Plate, Grass-Pak® Switch	1	F004	1/4-20 Keps Nut		3
3	5592-23	Grass-Pak® Housing Spacer	1	F009	5/16-18 Whiz Locknut		7
4	5578	Rear Clip, Chute Mount	1	F012	3/8-16 Keps Nut		3
5	5577	Side Clip, Chute Mount	2	F029	1/4-20 x 1/2 Hex Bolt		3
6	8511-1	Delivery Chute W/Clips / 10.0 (Includes Items # 4, 5, 7, F362 & F411)	1	F034	5/16-18 x 3/4 Hex Bolt		1
7	5578-10	Front Clip, Chute Mount	1	F040	3/8-16 x 1-1/2 Hex Bolt		2
8	7530-4	Body Chute (10.5 Blower)	1	F042	3/8-16 x 2-1/4 Hex Bolt		1
Blower Belt Tightener Assembly				F050	1/4 SAE Washer		1
				F051	3/8 SAE Washer		1
				F054	AN960616 Washer		1
9	7238-6	Blower Drive Pulley (Includes Items # F075, F114 & F231)	1	F067	3/16 x 3/16 x 1 Key		1
10	7234-2	Blower Belt (Micro-V)	1	F075	5/16-18 x 1/2 SQH Set Screw		2
11	7239-1	Blower Pulley (Mirco-V) (Includes Items # F067, F075 & F114)	1	F079	A/A66D Aluminum Pop Rivet		6
12	7364-2	Torsion Spring	1	F114	5/16-18 x 5/8 SQH Set Screw		2
13	7201-3	Fiberglide Bearing	2	F128	10-24 x 3/8 PTHMS		4
14	5830-3	Grease Fitting (45 Deg.)	1	F131	5/16-18 x 1/2 Hex Bolt		3
15	7364-1	Blower Belt Tightener Arm	1	F132	1/4-20 x 2-3/4 Hex Bolt		2
16	7201-4	Inner Race (1-1/2)	1	F168	5/16 Split Lock Washer		3
17	5841	Retainer Washer (3/8 x 1-1/4)	1	F217	7/16-14 Hex Nut		1
18	5245	Idler Pulley (3")	1	F218	7/16 Split Lock Washer		1
Blower Assembly				F231	1/4 x 3/4 Woodruff Key (# 806)		1
				F281	7/16-14 x 1-3/4 Hex Bolt		1
19	7544	Blower Assembly (10.5") (Includes Items # 20-25, F004, F009, F029, F050, F131, F168 & F426)	1	F362	A/A62D Alum. Pop Rivet (3/16D x 13/32L)		2
20	5268	Bearing W/Collar (3/4)	2	F411	3/16 Bulbex Rivet		6
21	7544-3	Blower Housing (10.5)	1	F426	1/4-20 x 1/2 Carriage Bolt		1
22	7545-2	Blower Output Shaft (10.5)	1	F577	10-24 x 5/8 Carriage Bolt		2
23	7545	Blower Wheel (10.5")	1				
24	7543-1	Blower Faceplate (10.5)	1				
25	7526	Intake Tube (10.5 Blower)	1				
26	5595-2	Intake Cover / GHS	1				
27	7528-4	Skid Bar (10.5" Blower)	1				



GHS POWERFIL® ASSEMBLY (10.0)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
10.0 GHS Powerfil® Assembly				Fasteners			
1	5551-3	Bearing Cap, Powerfil®	1		F002	10-24 Keps Nut	10
2	5551-1	Pivot Bearing (#S3PP)	2		F003	1/4-28 Hex Nut	3
3	5518-2	Pivot, Delivery Spout	1		F026	10-24 x 1/2 PPHMS	1
4	5517-2	Pivot Mount	1		F037	10-24 x 5/8 PTH Screw	2
5	5552	Ball Joint (1/4-28)	2		F054	AN960616 Washer	1
6	5558-1	Powerfil® Push Rod	1		F085	3/16 Rivet Backup Washer	1
7	5553-3	Bushing, Powerfil® Actuator	4		F101	10-24 x 1-1/4 SHC Screw	1
8	5553-1	Compression Spring (1/2 x 2)	2		F109	1/8 x 5/8 Roll Pin	1
9	5558-2	Powerfil® Actuator Rod	1		F129	10-24 x 1/2 PTHMS	6
	5549	Actuator Rod Assembly (Includes Items # 5-9 & F003)	*		F261	AN960616L Washer	1
10	5554	Actuator Arm	1		F287	1/4-28 Keps Nut	1
11	5519-3	Motor Mount Nut (5/8-24)	*	* Service Part Only			
12	5519-2	Motor Mount Washer	*				
13	5976-2	Grommet (3/16 x 3/4)	1				
14	5519-5	Actuator Motor (12V) (Includes Items # 11 & 12)	1				


GHS POWERFIL® ASSEMBLY (10.0)



GHS 10.0 BUSHEL CATCHER ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Upper Baffle Screen Assembly (Removable)				45	8608-10	Box Support, Gas Spring	2
1	7512-2	Removable Screen (3/16 Hole) (Includes Items # 2, 5, F025 & F190)	1**	46	7532-1	Handle, Catcher Lift	2
2	7506	Knob / Threaded Insert (10-24)	2	47	8117	Wire Harness Channel	1
3	8606-3	Channel Top, LH	1	48	5976-2	Grommet (3/16 x 3/4)	1
4	8606-2	Channel Bottom	2	49	5977-3	Grommet (9/16)	1
5	7856-1	Edge Molding (26")	1	50	8602-3	10.0 Catcher W/O Powerfil®, Gray (Includes Door)	*
6	7507	Screen Seal (27-1/2)	1		8602-4	10.0 Catcher W/Powerfil®, Gray (Includes Door)	*
7	7505	Mustache Spring	2		8610-5	10.0 Bushel Catcher Box, Gray	*
8	8606	C-Channel (10.0)	1	51	8607-9	Powerfil® Cover Plate	1
	8606-20	C-Channel With Spring (10.0) (Includes Items # 7, 8 & F340)	*	52	8155-2	Gas Spring Cover, RH	1
9	8606-4	Channel Top, RH	1	53	8608-8	Hinge Plate, RH	1
10.0 Exhaust Deflector Door Assembly				54	8608-9	Torsion Bar	1
10	8607-16	Upper Seal Support	1	5598-2 Optional Dump Bag (Not Shown)			
11	8607-17	Upper Door Seal	1	May be ordered as an option. Contact your Walker dealer.			
12	8607-18	Backup Plate	1	Fasteners			
13	8512-4	10.0 Catcher Box Door (Includes Items # 10-14, 16, 17, F085, F330 & F411)	1	F002	10-24 Keps Nut		29
14	5583	Handle	1	F004	1/4-20 Keps Nut		25
15	8607-1	Door Mount, LH	1	F009	5/16-18 Whiz Locknut		4
16	8607-12	Upper Door Stiffener	1	F020	5/16-18 ESNA Nut		2
17	8607-7	Lower Door Stiffener	1	F024	5/16-24 Jam Nut		4
18	8607-8	Door Guide	1	F025	10-24 x 3/8 PPHMS		4
19	8607-2	Door Mount, RH	1	F026	10-24 x 1/2 PPHMS		2
GHS 10.0 Bushel Catcher Assembly				F027	10-24 x 5/8 PPHMS		6
20	8608-5	Center Strap	1	F029	1/4-20 x 1/2 Hex Bolt		10
21	8608-3	Upper Frame Doubler	2	F049	5/16 SAE Washer		8
22	8608-1	Outside Box Strap	2	F050	1/4 SAE Washer		2
23	8608-2	Lower Frame Doubler	2	F068	1/8 x 1 Cotter Pin		2
24	8608-4	Center Frame Doubler	1	F079	A/A66D Aluminum Pop Rivet		5
25	8608-11	Catcher Door Finger	1	F085	3/16 Rivet Backup Washer		6
26	8608-6	Catcher Mount	1	F094	8-32 x 1/2 PTHMS		6
27	8610-4	Catcher Dump Flap W/Plate 10.0	1	F129	10-24 x 1/2 PTHMS		17
28	8610-3	Backing Plate, Dump Flap	1	F190	#10 Internal Star Lock Washer		2
29	7584	Reinforcing Strap	1	F195	1/4-20 x 3/4 PPHMS, SS		4
30	5103-5	Pivot Bushing Inner	2	F196	1/4-20 x 1 PPHMS, SS		4
31	5801-3	Decal Plate, Round (Set of 2)	1	F208	5/16-18 x 2-1/4 Hex Bolt		2
32	7620-3	Pivot Bushing (1/2 x 9/16)	2	F230	1/4-20 x 1-1/4 PPHMS, SS		4
33	8608-7	Hinge Plate, LH	1	F242	1/4-20 x 7/8 PPHMS, SS		8
34	5103-7	Outside Torsion Bushing	2	F330	3/16D x 21/32L Rivet, SS		9
35	8607-4	Upper Arm	2	F340	Rivet, Aluminum		4
36	5214-12	Ball Joint (5/16-24)	4	F351	Aluminum Pop Rivet		6
37	5155-12	5/16 Ball Stud	2	F360	1/4-20 x 3/8 Hex Bolt		2
38	5155-4	Gas Spring	2	F390	1/4-20 x 7/8 Carriage Bolt		4
39	5147	Spring Clip	4	F411	3/16 Bulbex Rivet		19
40	8155-1	Gas Spring Cover, LH	1	F456	5/16-18 x 3/4 SBH Cap Screw, SS		4
41	8607-3	Lower Arm	2	F503	1/4-20 x 1-1/2 PPHMS, SS		1
42	5103-6	Pivot Bushing Outer	2	F524	3/16 x 3/8 Aluminum Rivet, Black		6
43	5155-13	3/4 Ball Stud	2	* Service Part Only			
44	5523-6	Gas Spring Plate	2	** This screen can be replaced by P/N 7512-3 Removable Screen (3/4" holes) for improved air flow performance in wet conditions.			

GHS 10.0 BUSHEL CATCHER ASSEMBLY



INSTRUMENT PANEL ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Instrument Panel Assembly			
1	7307-2 8306-7	Instrument Panel Cover (Optional) Instrument Panel Assembly (Includes Items # 2-15, 24, 25, F129, F228, F250, F251 & F349)	** 1
2	7307-7	Panel Frame	1
3	8820-6	Panel Faceplate W/Decal	1
4	7386	Panel Gasket	1
5	8960-15	Ignition Switch (With Keys) (Includes Items # 17, 18 & F349)	1
6	8996-15	Red Indicator Light Assembly	3
7	7941-3	Boot, Circuit Breaker	2
8	7941-5	Circuit Breaker (7 Amp)	1
9	7941-2	Circuit Breaker (10 Amp)	1
10	8990-1	Hourmeter (Global)	1
11	5995	Toggle Switch (Off-On)	1
12	5995-2	Switch Boot	1
13	7306-14	Water Temperature Gauge	1
14	8997	Voltmeter Gauge	1
15	8945-5	Wire Harness, Instrument Panel	1
16	5975-1	Cable Tie (18# x 3-3/4")	2
17	8960-3	Key Set W/Umbrella	*
18	7854	Plastic Tip, Red	1
19	7307-1	Shock Mount (1.0 x .25)	3


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
20	7391	Panel Box Mount Plate	2
21	8385	Panel Box W/Graphic	1
22	7977-1	Grommet (1/8 x 1-1/16)	1
23	7307-16	Lining, Panel Box (1/8)	1
24	8536	Warning Horn	1
25	6942	Relay Switch 20/40 Amp (NC)	3
Fasteners			
	F002	10-24 Keps Nut	3
	F004	1/4-20 Keps Nut	6
	F129	10-24 x 1/2 PTHMS	1
	F228	#6 x 5/8 PPHSMS, SS	8
	F238	J Clip, Instrument Panel	8
	F250	6-32 x 1/2 PPHMS	2
	F251	6-32 Keps Nut	2
	F349	Washer .835 ID, 1.122 OD, SS	1

* Service Part Only

** May be ordered as an option. Contact your Walker dealer.

NOTE: Refer to **ELECTRICAL CONNECTORS**, Page 38 for identification of all Electrical Wiring Service Parts.

INSTRUMENT PANEL ASSEMBLY



Beginning S/N 147169
Use only genuine **Walker®** replacement parts.

ELECTRICAL ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
-------------	-------------	-------------	--------------

Harness Assembly

1	5975-3	Cable Tie (50# x 7")	6
2	5942-4	Safety Switch (NO)	1
3	5833	Cable Clamp (1/4)	1
4	8940-9	Wire Harness	1
5	5832	Cable Clamp (1/2)	5
6	7833-2	Cable Clamp (1 x 1/4)	2
7	6942	Relay Switch 20/40 Amp (NC)	1
8	7948-6	Time Delay Module	1
9	7948-5	Time Delay Harness	1
10	8941	Circuit Breaker (30 Amp) Auto Reset / Sealed	1
11	8943	Positive Battery Lead Wire (Red)	1
12	5975-1	Cable Tie (18# x 3-3/4")	3
13	5942-16	Safety Switch (NO), Delta WP	1
14	6103-19	Adapter Harness	1

Battery Assembly

15	6923	Negative Battery Cable	1
16	5933	Battery Terminal Insul., Red (+)	1
17	5844-3	Battery Hold-Down Bar	1
18	5839	Hook Bolt	2
19	6390-2	Battery Pan	1
20	NS	Battery (12V/340CCA/Wet)	1
21	5932	Battery Terminal Insul., Black (-)	1
22	7834-2	Wire Saddle (2 Wires)	1

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
-------------	-------------	-------------	--------------

Fasteners

F002	10-24 Keps Nut	8
F004	1/4-20 Keps Nut	3
F009	5/16-18 Whiz Locknut	1
F019	1/4-20 ESNA Wing Nut	2
F025	10-24 x 3/8 PPHMS	3
F026	10-24 x 1/2 PPHMS	2
F031	1/4-20 x 5/8 Hex Bolt	2
F032	1/4-20 x 3/4 Hex Bolt	1
F050	1/4 SAE Washer	2
F061	1/4 Star Lock Washer	1
F079	A/A66D Aluminum Pop Rivet	4
F085	3/16 Rivet Backup Washer	1
F093	5/16-18 x 1 Hex Bolt	1
F124	10-32 x 3/8 Tapitite Machine Screw	2
F129	10-24 x 1/2 PTHMS	1
F182	1/4 x 5/8 x 1/8 Washer	2
F232	10-32 Keps Nut	2
F284	M6 x 1.0 x 8 SCH Screw	1
F505	6-32 x 7/8 Hex Trim MS, SS	2
F506	6-32 Nylock Nut	2

NOTE: Refer to **ELECTRICAL CONNECTORS**, Page 38 for identification of all Electrical Wiring Service Parts.


[illegible]

33

ELECTRICAL ASSEMBLY (EFI COMPONENTS)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Electrical Assembly				Fasteners			
1	7306-11	Switch (205 Deg., 3/8-18 NPT)	1	F002	10-24 Keps Nut		8
2	5975-1	Cable Tie (18# x 3-3/4")	4	F025	10-24 x 3/8 PPHMS		3
3	NS	Fuse Holder (Kohler)	3	F026	10-24 x 1/2 PPHMS		2
4	6941-4	30 Amp Fuse	1	F028	10-24 x 3/4 PPHMS		3
5	NS	ECU Harness Clip	1	F063	3/8 Internal Star Lock Washer		1
6	NS	Relay (Kohler)	1	F102	10-24 x 1-1/2 PTHMS		2
7	6941-1	20 Amp Fuse	1	F106	3/8-16 x 5/8 Hex Bolt		1
8	6941-3	10 Amp Fuse	1	F145	4-40 Keps Nut		2
9	8940-7	ECU Mount Plate	1	F232	10-32 Keps Nut		2
10	NS	ECU (Kohler)	1	F284	M6 x 1.0 x 8 SHC Screw		1
11	7943	Battery Cable (+)	1	F491	4-40 x 3/8 PPHMS		2
12	7433-2	Resistor, 50 Watt / .4 OHM 1%	1				
13	7428-2	Fan Control Module W/P Plug	1	NOTE: Refer to ELECTRICAL CONNECTORS , Page 38 for identification of all Electrical Wiring Service Parts.			
14	5975-7	Cable Tie (50# x 11")	1				
15	8531-3	Reversing Module Mount	1				
16	7941	Circuit Breaker (40 Amp) (Auto Reset / Sealed)	1				
17	6942	Relay Switch 20/40 Amp (NC)	1				

ELECTRICAL ASSEMBLY (EFI COMPONENTS)



Beginning S/N 147169
Use only genuine **Walker®** replacement parts.

ELECTRICAL ASSEMBLIES (GHS 10.0 BUSHEL COMPONENTS)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
----------	----------	-------------	-----------

Horn & Harness Channel Assemblies

1	5977-2	Grommet, Cut (1/8 x 3/8)	2
2	5975-1	Cable Tie (18# x 3-3/4")	1
3	5975-3	Cable Tie (50# x 7")	1
4	5536-2	Horn, Full Signal	*

Harness & Grass-Pak® Switch Assemblies

5	8950-4	Powerfil® Wire Harness (7.0 / 10.0)	1
6	5594-6	Aluminum Shaft & Vane Assembly	1
7	5592-20	Grass-Pak® Switch Assembly	1
8	5833	Cable Clamp (1/4)	2

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
----------	----------	-------------	-----------


Fasteners

F002	10-24 Keps Nut	4
F025	10-24 x 3/8 PPHMS	1
F037	10-24 x 5/8 PTH Screw	1
F129	10-24 x 1/2 PTHMS	2
F508	4-40 Keps Nut, SS	2
F509	4-40 x 1/2 Hex Head, SS	2

* Service Part Only

NOTE: Refer to **ELECTRICAL CONNECTORS**, Page 38 for identification of all Electrical Wiring Service Parts.


ELECTRICAL ASSEMBLIES (GHS 10.0 BUSHEL COMPONENTS)



ELECTRICAL CONNECTORS

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Electrical Wiring Service Parts				29	7942-1	2-Way Locking Connector, Female	*
1	5996-1	16-14 GA Butt Connector	*	30	7942-2	2-Way Connector, Male	*
2	5996-11	12-10 GA Butt Connector	*	31	7942-3	2-Way Connector, Female	*
3	7942-14	16-14 GA Shrink Connector	*	32	7942-10	2-Way Locking Connector, Male	*
4	7942-13	12-10 GA Shrink Connector	*	33	5940-8	3-Way Connector, Male	*
5	5995-1	Wire Terminal Adapter	*	34	7942-9	3-Way Connector, Male	*
6	5996-4	16-14 GA Bullet Conn., Male	*	35	8944	3-Way Locking Connector, Male	*
7	5996-5	16-14 GA Bullet Conn., Female	*	36	8944-1	3-Way Locking Connector, Female	*
8	5940-4	16-14 GA Spg. Loaded Term., Female	*	37	7942-11	4-Way Connector, Male	*
9	5940-7	Wire Clip, Female	*	38	7942-12	4-Way Connector, Female	*
10	5996	1/4 x 16-14 GA QKS Term., Female	*	39	7942-5	5-Way Connector, Male	*
11	5996-2	3/16 x 22-18 GA QKS Term., Female	*	40	5940-2	5-Way Connector, Male	*
12	7996	16-14 GA QKS Term., Female	*	41	8942-1	5-Way Connector, Female	*
13	5940-5	16-14 GA Spg. Loaded Term., Male	*	42	7942-6	6-Way Connector, Male	*
14	5996-0	1/4 x 22-18 GA QKS Term., Male	*	43	7942-7	6-Way Connector, Male	*
15	5996-18	16-14 GA Ring Term. (#8) Nylon Insulated	*	44	7942-8	8-Way Connector, Male	*
16	7996-1	1/4 x 16-14 GA QKS Term., Male	*	45	8942-2	8-Way Connector, Female	*
17	5996-8	6 GA Ring Lug (5/16) Insulated	*	46	8942-3	5-Way Connector, Male	*
18	5996-9	22-18 GA Ring Term. (#10)	*	47	5940-9	3-Way Connector (M)	*
19	5996-10	16-14 GA Ring Term. (5/16) Insulated	*	48	7942-15	6-Way Connector (Female)	*
20	5996-12	12-10 GA Ring Term. (5/16)	*	49	7940-3	Packard Plug (Male)	*
21	5996-13	16-14 GA Ring Term. (# 10) Insulated	*	50	7940-4	Packard Plug (Female)	*
22	5996-15	12-10 GA Ring Term. (1/2)	*	* Service Part Only			
23	5996-16	6 GA Ring Terminal (1/4)	*	NOTE: Not all Electrical Connectors are used with all assemblies.			
24	5996-17	16-14 GA Ring Term. (1/4)	*	NOTE: Refer to ELECTRICAL ASSEMBLY , Page 32 for locations of Wiring Harness and of all Electrical Wiring Service Parts.			
25	5996-20	12-10 GA Ring Term. (1/4) Insulated	*				
26	5996-21	12-10 GA Ring Term. (#10) Insulated	*				
27	7942-4	Single Connector, Male	*				
28	8942	2-Way Connector, Male	*				

ELECTRICAL CONNECTORS



LUBRICATION POINTS

ITEM NO.	LOCATION	LUBRICATION TYPE	NO. PLACES
----------	----------	------------------	------------

Lubrication Points

1	Steering Lever Pivot	Grease	4
2	Body Hinge Point	Oil	2
3	Deck-to-PTO Coupling (Grease Spline Slide Area)	Grease	1
4	FSC Actuator Rod Pivots	Oil	2
5	(FSC) Friction Body Pivot	Grease	1
6	FSC Lever Pivot	Grease	1
7	Deck Support Arm Pivot	Grease	2
8	Universal Joint Tube Assembly	Grease*	1
9	Parking Brake Lever	Grease	1
10	Universal Joint Quick Connect Spline (Grease Slide Area)	Grease	1
11	Gear Axle	Oil**	2
12	Belt Tightener Pivot, Jackshaft Drive	Grease	1
13	PTO Clutch Lever Pivot	Grease	1
14	Clutch Actuator Spring Assembly	Grease	2
15	Belt Tightener Pivot, PTO Clutch	Grease	1
16	Brake Actuator Rod and Brake Band Pivot Pins (Clevis)	Oil	3

ITEM NO.	LOCATION	LUBRICATION TYPE	NO. PLACES
----------	----------	------------------	------------


17	Brake Actuator Pivot	Grease	1
18	Throttle Control Cable Ends	Oil	2
19	Catcher Hinge Point	Oil	2
20	Rear Wheel Bearing	Grease	2
21	Engine Oil	Oil**	1
22	Belt Tightener Pivot, Blower Drive (GHS Model Only)	Grease	1
23	Belt Tightener Pivot, Ground Drive	Grease	1
24	PTO Gearbox Dipstick	Oil**	1
25	Hydrostatic Drive	Oil**	2
26	Throttle Control Pivot	Oil	1

* Grease every 25 hours.

** Refer to T30i **Operator's Manual** for procedure for checking and changing oil in Engine Crankcase, Hydrostatic Transmissions and Gear Axles.

NOTE: See Model T30i **Operator's Manual** (8000-28) for proper lubrication intervals.

LUBRICATION POINTS



WIRING SCHEMATIC

WALKER MODEL T30i Beginning S/N 124884

S1 = START CIRCUIT
 S2 = START / ACCESSORY CIRCUIT
 M = MAGNETO GROUND CIRCUIT
 B = BATTERY CIRCUIT
 A = ACCESSORY CIRCUIT
 G = GROUND CIRCUIT
 J1 = #1 FUEL INJECTOR
 J2 = #2 FUEL INJECTOR
 J3 = THROTTLE POSITION SENSOR
 J4 = OIL TEMP SENSOR
 J5 = OXYGEN SENSOR
 J6 = REGULATOR / RECTIFIER
 J8 = ENGINE GROUND
 J10 = #1 IGNITION COIL
 J11 = #2 IGNITION COIL
 J12 = #1 IGNITION COIL
 J13 = #2 IGNITION COIL
 J14 = IGNITION COIL GROUND
 J20 = SPEED PICK-UP SENSOR

RELAY - A	
PTO RELAY	
OFF	30 + 87A
START	30 + 87A
PTO ON	OPEN

RELAY - B	
START RELAY	
OFF	OPEN
START	30 + 87
RUN	OPEN


RELAY - C	
FAN INTERRUPT RELAY	
OFF	30 + 87A
START	OPEN
PTO ON	30 + 87A

RELAY - D	
FAN SPEED CONTROL	
OFF	30 + 87A
START	30 + 87A
PTO ON	30 + 87


RELAY - E	
DELAY RELAY	
OFF	30 + 87A
START	OPEN
PTO ON	OPEN

RELAY - F	
IGNITION / FUEL RELAY	
OFF	OPEN
START	OPEN
PTO ON	30 + 87

IGNITION SWITCH CIRCUITS	
OFF	G + M
START	B + A / S1 + S2
RUN	B + A



WIRING SCHEMATIC



MAINTENANCE AND SERVICE RECORD SHEET

[illegible]

LIMITED WARRANTY FOR WALKER COMMERCIAL RIDER MOWER

1. WHAT THIS WARRANTY COVERS, AND FOR HOW LONG:

Walker Manufacturing company will, at its option, repair or replace, without charge, any part covered by this warranty which is found to be defective in material and/or workmanship within one (1) year* after date of sale to the original retail purchaser unless the product is used for rental purposes, in which case this warranty is limited to ninety (90) days. At Walker's request, customer will make the defective part available for inspection by Walker and/or return the defective part to Walker, transportation charges prepaid. All parts and components of the Walker Mower are covered by this warranty **except** the following components which are warranted separately by their respective manufacturers:

Kohler Engine
Battery

The available warranties covering these items are furnished with each mower. Walker does not assume any warranty obligation, liability or modification for these items, which are covered exclusively by the stated warranty of the respective manufacturers noted above.

* Extended warranties are offered for the following powertrain components:

- A three (3) year unlimited hour warranty is offered for the Walker P/N 6200-9 Gear Axle Assembly.
- A three (3) year or 3000 hour (whichever comes first) warranty is offered for Eaton Model 7 Hydrostatic transmissions; covers full cost of replacement up to 1000 hours of use, and after 1000 hours warranty coverage is prorated against 3000 hours.

2. WHAT THIS WARRANTY DOES NOT COVER:


- A. This warranty does not cover defects caused by depreciation or damage caused by normal wear, accidents, improper maintenance, improper use or abuse of the product, alterations, or failure to follow the instructions contained in the Operator's Manual for operation and maintenance.
- B. The customer shall pay any charges for making service calls and/or for transporting the mower to and from the place where the inspection and/or warranty work is performed.

3. HOW TO OBTAIN SERVICE UNDER THIS WARRANTY:

Warranty service can be arranged by contacting the dealer where you purchased the mower or by contacting Walker Manufacturing Company, 5925 East Harmony Road, Ft. Collins, CO 80528. Proof of the date of purchase may be required to verify warranty coverage.

4. WARRANTY LIMITATION:

- A. **THERE IS NO OTHER EXPRESS WARRANTY. ANY WARRANTY THAT MAY BE IMPLIED FROM THIS PURCHASE INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE IS HEREBY LIMITED TO THE DURATION OF THIS WARRANTY AND TO THE EXTENT PERMITTED BY LAW ANY AND ALL IMPLIED WARRANTIES ARE EXCLUDED.** Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.
- B. **WALKER WILL NOT BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES AND/OR EXPENSES IN CONNECTION WITH THE PURCHASE OR USE OF THE MOWER.** Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation(s) or exclusion(s) may not apply to you.
- C. Only the warranty expressed in this limited warranty shall apply and no dealer, distributor, or individual is authorized to amend, modify, or extend this warranty in any way. Accordingly, additional statements such as dealer advertising or presentations, whether oral or written, do not constitute warranties by Walker, and should not be relied upon.
- D. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.



WALKER

WALKER MFG. CO. • 5925 E. HARMONY ROAD, FORT COLLINS, CO 80528 • (970) 221-5614
FORM NO. 022718 PRINTED IN USA www.walkermowers.com ©2018 WALKER MFG. CO