




WALKER

Illustrated Parts Manual

T₂₃



Beginning S/N: 170586
P/N 8000-49

KEY TO ABBREVIATIONS USED IN THIS MANUAL

<i>Abbreviation</i>	<i>What it Represents</i>
° (Dimension)	Degrees (Angle)
" (Dimension)	inches
(-)	Negative (Polarity)
(+)	Positive (Polarity)
-1 (as deck style designation)	Standard (Aluminum) Gear Drive Deck
-2 (as deck style designation)	Heavy Duty (Cast Iron) Gear Drive Deck
-3 (as deck style designation)	Belt Drive Deck
AT	All-Terrain
CCW	Counter-clockwise
CW	Clockwise
D	Diameter
DC	Deck, Collection (number refers to size in inches)
DM	Deck, Mulching (number refers to size in inches)
DR	Deck, Rear Discharge (number refers to size in inches)
DS	Deck, Side Discharge (number refers to size in inches)
DU	Garlock (Bearing)
ESNA (Fastener)	Nylon Insert Locknut
FSC	Forward Speed Control
GA	Gauge
gal	gallon
GHS	Grass Handling System
GR (Fastener)	Grade
HD	Heavy Duty
HP	Horse Power
ID	Identification or Inside Diameter
L	Length
LH	Left Hand (orientated with operator on seat)
LP	Low Profile
mm (Dimension)	millimeters
MS (Fastener)	Machine Screw
NS (as part number)	Item is not sold by Walker Manufacturing
OD	Outside Diameter
oz	ounce
PFH (Fastener)	Phillips Flat Head
P/N	Part Number
PPH (Fastener)	Phillips Pan Head
PTH (Fastener)	Phillips Truss Head
PTO	Power Take-Off
QKS	Quick Slide
qt	quart
RH	Right Hand (orientated with operator on seat)
SAE (Fastener)	Society of Automotive Engineers
SBH (Fastener)	Socket Button Head (Bolt)
SFH (Fastener)	Slotted Flat Head
SHC (Fastener)	Socket Head Cap
SHL (Fastener)	Shoulder (Bolt)
SM (Fastener)	Sheet Metal (Screw)
S/N	Serial Number
SQH (Fastener)	Square Head
SS (Fastener)	Stainless Steel
ST (Fastener)	Self-Tapping (Screw)
TOPS™	Transmission Oil Performance System
V	Volts

NOTE: In some instances, combinations of abbreviations may be used (e.g. PPHMS - Phillips Pan Head Machine Screw).

ILLUSTRATED PARTS LIST

<i>Section of Tractor Covered</i>	<i>Page</i>
Decals	
Tractor Decals	2
Body / Chassis Assemblies	
Body / Chassis Assembly (GHS Models)	4
Rear Body Assembly (GHS Models)	6
Body Assembly (Non-Collection Models)	8
Tractor Components	
Main Component Power Transmission (GHS Models)	10
(Non-Collection Models)	12
Engine Group	14
Hydrostatic Ground Drive Assemblies	16
Steering Control Assemblies	18
Throttle & Choke Control Assemblies	20
Parking Brake Assembly	22
GHS Group	24
GHS Powerfil® Assembly (10.0)	26
GHS 10.0 Bushel Catcher Assembly	28
Instrument Panel Assembly	30

<i>Section of Tractor Covered</i>	<i>Page</i>
Electrical Components	
Electrical Assembly	32
Electrical Assemblies (GHS 10.0 Bushel Components)	34
Maintenance	
Lubrication Points	36
Wiring Schematic	38
Maintenance And Service Record Sheet	39
Warranty	
Limited Warranty	41


TRACTOR DECALS

ITEM NO.	PART NO.	DESCRIPTION	LOCATION	NO. REQ'D. GHS	NO. REQ'D NON-COLLECTION
Walker Product and Operation Decals					
1	8600-33	RH Fender	Body, RH Side Near Seat	1	1
2	5800	Walker Mower (4" Round)	Utility Bed (one on each side)	0	2
3	5800-22	Walker (8" Round)	10.0 Bushel Catcher (one on each side)	2	0
4	8821-10	Decal, T23	Body	1	1
5	5856-1	Made in USA	Body	1	1
6	5813-2	Decal, 4" Grass-Pak Powerfil®	Powerfil® Cover Plate	1	0
Danger Decals Warning Decals Caution Decals					
7	8600-34	Warning, Read Manual	Body	1	1
8	5810-3	Decal, Hydro Warning	LH Gear Axle Drive Assembly	1	1
9	8600-12	Danger, Engine Exhaust	Front Body, LH Side	1	1
10	8600-10	Danger, Pinch Point	10.0 Bushel Catcher Mounting Frame Assembly (one on each side)	2	0
11	8600-4	Danger, Rotating Blower Blades	Body, Near Body Chute	1	0
Maintenance Decals					
12	8600-30	Parking Brake	Body, RH Side below Seat	1	1
13	5855	Important, Engine Cooling	Engine	1	1
14	6895-103	Kohler 300 Hour Oil	Engine	1	1
15	5869	Removable Screen	10.0 Bushel Catcher Removable Screen	1	0
16	8600-16	Front Body Closure	Rear Cross Member, Body	1	1
17	7827	Oil Level	Jackshaft Support	1	1
18	5024-24	Decal, TOPS™	Oil Reservoir Tank	1	1
19	5810-1	Axle Oil Level	Gear Axle Drive Assemblies (one on each)	2	2
20	8600-32	Choke	Body, LH Side	1	1
21	8600-31	Throttle	Body, LH Side	1	1
22	6875	PTO Alignment Arrow	Universal Joint Tube Assembly	1	1


NOTE: All parts requiring decals are shipped with decals applied.

TRACTOR DECALS

Non-Collection Model




GHS Model



BODY / CHASSIS ASSEMBLY (GHS MODELS)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Seat Assembly				44	8035-1	Tail Wheel & Tire Assembly (13 x 4.5-6) (With Bearing Race)	2
1	6104-31	Comfort Seat	1		8035-3	Tail Wheel Tire (13 x 4.5-6 Ply)	**
2	2845-3	Aluminum Washer (5/16 x 1 x 1/4)	4		8036	Wheel & Hub (6 x 3.25) (Includes Items # 38 & Bearing Race)	**
Rear Bumper Assembly (GHS Models Only)*					8037-2	Bearing Race	**
3	7516	GHS Rear Bumper	1		7420-20	Dual Tail Wheel & Tire Assembly (Includes Items # 39-44)	**
4	7516-5	Catcher Pivot Bushing	2	45	7070-2	Wheel & Tire Assembly (18 x 9.50-8)	2
5	5162	Roller Wheel (5" Rubber)	2		7070-3	Drive Tire (18 x 9.50-8)	**
6	7517-3	Catcher Pivot Plate	2		5070-4	Wide Wheel (8 x 7)	**
Body Assembly				46	8300-18	Chassis Frame (T / 5.0 gal.)	1
7	7383-6	Body Latch Bracket, RH	1	Fasteners			
8	7383-5	Body Latch Lever	1		F002	10-24 Keps Nut	2
9	7383-7	Body Latch Bracket, LH	1		F004	1/4-20 Keps Nut	8
10	7222	Extension Spring (1/4 x 3)	1		F009	5/16-18 Whiz Locknut	11
11	5845	Rubber Bumper (1.50 OD x 1.25)	4		F012	3/8-16 Keps Nut	4
12	5989-12	Dome Plug (3/16)	1		F014	3/8-16 ESNA Nut	4
13	5989-10	Dome Plug (9/16)	1		F020	5/16-18 ESNA Nut	1
14	8101-8	Front Body Engine Guard	1		F025	10-24 x 3/8 PPHMS	2
15	NS	Body ID Plate	1		F029	1/4-20 x 1/2 Hex Bolt	6
16	8118	Heat Deflector	1		F031	1/4-20 x 5/8 Hex Bolt	2
17	7422	Panel Guard	1		F034	5/16-18 x 3/4 Hex Bolt	2
18	5989-4	Dome Plug (3/8)	4		F035	5/16-18 x 1-1/4 Hex Bolt	4
19	5989-3	Dome Plug (5/16)	2		F038	3/8-16 x 1 Hex Bolt	6
20	5146	10mm Ball Stud	2		F040	3/8-16 x 1-1/2 Hex Bolt	2
21	2145	Gas Spring Assembly (Includes Item # 20)	1		F041	3/8-16 x 1-3/4 Hex Bolt	2
22	7844	Rubber Bumper (1.25 OD x .250)	1		F042	3/8-16 x 2-1/4 Hex Bolt	2
23	5989-9	Dome Plug (1/4)	4		F049	5/16 SAE Washer	2
24	8100-15	Front Body	1		F050	1/4 SAE Washer	2
25	5180	Edge Molding, Lever Opening	2		F051	3/8 SAE Washer	2
26	5989-55	Dome Plug (1/2)	1		F059	3/8 Wave Spring Washer	2
27	5989-5	Dome Plug (7/16)	1		F093	5/16-18 x 1 Hex Bolt	1
Tilt-Up Latch Assembly***					F157	1/2-20 x 1-1/4 Wheel Lug Bolt	8
28	5847	Plastic Tip	1		F205	5/16-18 x 1/4 Set Screw, Knurl Point	2
29	5744-20	Spring Arm, Tilt-Up Latch	1		F206	#2 x 3/16 Drive Pin	2
30	5744-10	Spring Pivot Bushing	1		F218	7/16 Split Lock Washer	2
31	5744-15	Compression Spring (3/8 x 5/8)	1		F219	7/16-14 x 1-1/4 Hex Bolt	2
32	5744-13	Mount Angle, LH	1		F241	.375 x .875 x .10 Washer	4
33	5744-12	Hook, Tilt-Up Latch	1		F256	7/16 SAE Washer	2
34	5744-14	Mount Angle, RH	1		F341	Coil Roll Pin (7/64 x 9/16)	1
Chassis Assembly					F342	5/16 Conical Washer	2
35	5267-1	Retainer Collar (1") (Includes Item # F413)	1		F413	5/16-24 x 5/16 Set Screw	2
36	5270-1	Ball Bearing	2		F570	3/8-16 Flange Top Lock Nut	4
37	7420	Tail Wheel Fork	1		F591	7/16-14 Flange Top Lock Nut	2
38	5830-3	Grease Fitting (45 Degree)	2		F592	7/16-14 x 1-1/8 Hex Bolt GR 5	2
39	8039	Nut, Tail Wheel Axle	2	* Rear Bumper Assembly for SD Models is not shown here. Refer to BODY ASSEMBLY (SD MODELS) , Page 8.			
40	8768-2	Seal, Reverse Lip	4	** Service Part Only			
41	8038-1	Spacer, Tail Wheel Axle (.750 ID x 1.125 OD)	2	*** Complete Tilt-Up Latch Assembly Kit available by ordering kit # 5747.			
42	8037	Bearing Cone (3/4 ID)	4				
43	8038	Tail Wheel Axle (3/4 x 10-3/8)	1				

BODY / CHASSIS ASSEMBLY (GHS MODELS)




Model T23 Beginning S/N 170586
Use only genuine **Walker®** replacement parts.

REAR BODY ASSEMBLY (GHS MODELS)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Rear Body Assembly (GHS Models)				Fasteners			
1	7190-3	Insulation Foam Pad (5 x 20)	1	F002	10-24 Keps Nut		4
2	8082	Heat Shield	1	F009	5/16-18 Whiz Locknut		2
3	8515-14	Catcher Handle Plate, RH	1	F023	10-24 ESNA Nut		7
4	8515-13	Catcher Handle Plate, LH	1	F026	10-24 x 1/2 PPHMS		3
5	8615-4	Catcher Support Frame, 10.0	1	F027	10-24 x 5/8 PPHMS		1
6	7190-2	Insulation Foam Pad, RH	1	F032	1/4-20 x 3/4 Hex Bolt		3
7	7190-1	Insulation Foam Pad, LH	1	F085	3/16 Rivet Backup Washer		2
8	5832	Cable Clamp (1/2)	1	F390	1/4-20 x 7/8 Carriage Bolt		2
9	7145	Gas Spring Assembly (Includes Items # 11 & 12)	1	F568	10-24 Flange Top Lock Nut		2
10	8389-5	Splash Guard	1	F569	1/4-20 Flange Top Lock Nut		5
11	7147	Spring Clip	2	F613	10-24 x 1/2 Truss Head Torx		9
12	7146	13mm Ball Stud	2	F615	1.0 x .255 x .125 Washer		1
13	8105-10	Rear Body Panel	1	NOTE: Rear Bumper Assembly for GHS Models is not shown here. Refer to BODY / CHASSIS ASSEMBLY (GHS MODELS) , Page 4.			

REAR BODY ASSEMBLY (GHS MODELS)




BODY ASSEMBLY (NON-COLLECTION MODELS)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Utility Bed Assembly				Fasteners			
1	8650-10	Bed Liner (21.5 x 27.5)	1	F002	10-24 Keps Nut		8
2	8650-2	Utility Bed (Includes Item # 1)	1	F009	5/16-18 Whiz Locknut		2
3	7190-2	Insulation Foam Pad, RH	1	F012	3/8-16 Keps Nut		6
4	7190-1	Insulation Foam Pad, LH	1	F013	3/8-16 Whiz Locknut		2
Rear Bumper Assembly (SD Models)				F014	3/8-16 ESNA Nut		2
5	7153-3	Cover Plate	1	F023	10-24 ESNA Nut		7
6	7145	Gas Spring Assembly (Includes Items # 7 & 8)	1	F026	10-24 x 1/2 PPHMS		3
7	7147	Spring Clip	2	F027	10-24 x 5/8 PPHMS		1
8	7146	13mm Ball Stud	2	F038	3/8-16 x 1 Hex Bolt		6
9	7521	Rear Bumper	1	F040	3/8-16 x 1-1/2 Hex Bolt		2
10	5162	Roller Wheel (5" Rubber)	2	F042	3/8-16 x 2-1/4 Hex Bolt		2
11	8105-10	Rear Body Panel	1	F051	3/8 SAE Washer		2
12	8389-5	Splash Guard	1	F059	3/8 Wave Spring Washer		2
				F128	10-24 x 3/8 PTHMS		4
				F613	10-24 x 1/2 Truss Head Torx		7

NOTE: Refer to **BODY / CHASSIS ASSEMBLY (GHS MODELS)**,
Page 4 for all common parts used on both models.


BODY ASSEMBLY (NON-COLLECTION MODELS)



MAIN COMPONENT POWER TRANSMISSION (GHS MODELS)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Clutch Lever Assembly				40	8349-4	Idler Arm	1
1	8358-3	Clutch Lever (Includes Items # 2 & 3)	1	41	7201-4	Inner Race (1-1/2)	2
2	5830	Grease Fitting	8	42	5221-1	Extension Spring (3/4 x 5)	2
3	4850	Handle Grip, Black	1	43	8539	Starter Relay Mount	1
4	7303-10	Clutch Actuator Bolt (3/8)	1	44	5268	Bearing W/Collar (3/4)	2
5	7380-5	Knuckle Joint (3/8 ID)	1	45	7241-2	Transmission Drive Pulley (3-1/4MV) (Includes Items # F067 & F171)	1
6	7226-10	Compression Spring (3/4 x 2-1/2)	1	46	7833	Cable Clamp (7/8 x 1/4)	1
7	8130-5	Pushrod, Clutch Actuator (Threaded Tube) (Includes Item # 2)	1	47	8349	Transmission Belt Tightener Arm	1
8	8130-10	Clutch Actuator Rod Assembly (Includes Items # 2, 4-7, F054, F336 & F353)	1	48	5245	Idler Pulley (3")	1
9	7201-3	Fiberglide Bearing	6	49	8394-6	Hydro Jackshaft Mount Assembly (Includes Items # 2, 9, 12, 41, 44, 50, F012, F042, F067 & F171)	1
10	7201-5	Inner Race (2-1/4)	1	50	8273-1	Jackshaft (3/4 x 8-1/8)	1**
11	8368	PTO Belt Tightener	1	51	7240-4	Jackshaft Drive Pulley (3.3/3V) (Includes Items # F067 & F171)	1
12	5841	Retainer Washer (3/8 x 1-1/4)	4	Fasteners			
13	8243-1	Clutch Idler Pulley	1		F003	1/4-28 Hex Nut	2
	8243	Clutch Idler Pulley Assembly (Includes Items # 13-15 & F070)	*		F004	1/4-20 Keps Nut	3
14	5265	Bearing (3/4)	1		F005	1/4-20 ESNA Nut	1
15	8243-3	Hub, Idler Pulley	1		F009	5/16-18 Whiz Locknut	3
16	8375	PTO Belt Tightener Stop	1		F012	3/8-16 Keps Nut	6
17	7377	Plastic Washer (1 x .438 x .025)	2		F029	1/4-20 x 1/2 Hex Bolt	1
18	7378	Pivot Bearing (7/16 x 9/16)	1		F041	3/8-16 x 1-3/4 Hex Bolt	2
19	5281-5	Clevis Pin (1/4 x 0.80)	2		F042	3/8-16 x 2-1/4 Hex Bolt	3
20	5280	Clevis (1/4)	2		F043	3/8-16 x 3 Hex Bolt	1
21	8305	Brake Actuator Rod	1		F047	3/8-16 x 4-1/2 Hex Bolt	1
22	8370	Bearing, Brake Actuator	1		F054	AN960616 Washer	3
23	8250	Brake Spring (1/2 x 2-1/2)	1		F061	1/4 Internal Star Lock Washer	1
24	8369	Brake Actuator (Includes Items # 2 & 22)	1		F067	3/16 x 3/16 x 1 Key	2
PTO Drive Shaft Assembly					F069	3/32 x 1/2 Cotter Pin	3
25	7050-1	Dipstick, Gearbox	1		F070	1-3/4 Internal Snap Ring	1
26	8371-1	Mount Bracket, Brake Band	1		F090	1/4-20 x 2-1/2 Hex Bolt	1
27	8377	Brake Band Guide	1		F116	1/4-20 x 1-1/4 Hex Bolt	1
28	8050-11	PTO Gearbox / Flange Pulley	1		F121	5/16-18 x 3/8 x 1 SHL Bolt	1
29	7248	Ground Drive Belt, Micro-V	1		F131	5/16-18 x 1/2 Hex Bolt	2
30	7275-16	Universal Joint Tube Assembly / Spline	1		F132	1/4-20 x 2-3/4 Hex Bolt	1
31	7275-9	Quick Coupler Installation Tool	1		F168	5/16 Split Lock Washer	10
32	7523-2	Clevis Pin W/Hole (1/4 x 5/8)	1		F171	5/16-18 x 3/8 Set Screw	4
33	8304	Brake Band (14-1/2)	1		F178	1/4 x 1 Fender Washer	1
34	6250-1	Drive Belt (3VX370)	1		F182	1/4 x 5/8 x 1/8 Washer	2
35	7236-1	PTO Drive Pulley (4-1/2/3V) (Includes Items # F168 & F226)	1		F226	5/16-18 x 7/8 Hex Bolt	14
36	8237-2	Engine Pulley, Bolt On (4/3.8/3V) (Includes Item # F226)	1		F241	.375 x .875 x .10 Washer	1
37	8230	Engine PTO Belt	1		F255	5/16-18 x 1-1/2 Hex Bolt	2
Jackshaft Assembly					F261	AN960616L Washer	1
38	7245-1	Idler Pulley (3/8 Groove)	1		F336	3/8-16 Jam Nut	1
39	6325-2	Spacer Bushing (5/16)	2		F353	3/8-16 ESNA LP Nut	1
				*	Service Part Only		
				**	Prior to S/N 175934 use P/N 8273. See Advisory Bulletin #22288.		


MAIN COMPONENT POWER TRANSMISSION (GHS MODELS)



MAIN COMPONENT POWER TRANSMISSION (NON-COLLECTION MODELS)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Clutch Lever Assembly				40	8349-4	Idler Arm	1
1	8358-3	Clutch Lever (Includes Items # 2 & 3)	1	41	7201-4	Inner Race (1-1/2)	2
2	5830	Grease Fitting	8	42	5221-1	Extension Spring (3/4 x 5)	2
3	4850	Handle Grip, Black	1	43	8539	Starter Relay Mount	1
4	7303-10	Clutch Actuator Bolt (3/8)	1	44	5268	Bearing W/Collar (3/4)	2
5	7380-5	Knuckle Joint (3/8 ID)	1	45	7241-2	Transmission Drive Pulley (3-1/4MV) (Includes Items # F067 & F171)	1
6	7226-10	Compression Spring (3/4 x 2-1/2)	1	46	7833	Cable Clamp (7/8 x 1/4)	1
7	8130-5	Pushrod, Clutch Actuator (Threaded Tube) (Includes Item # 2)	1	47	7394-6	Idler Pulley Spring Mount	1
8	8130-10	Clutch Actuator Rod Assembly (Includes Items # 2, 4-7, F054, F336 & F353)	1	48	8349	Transmission Belt Tightener Arm	1
9	7201-3	Fiberglide Bearing	6	49	5245	Idler Pulley (3")	1
10	7201-5	Inner Race (2-1/4)	1	50	8394-6	Hydro Jackshaft Mount Assembly (Includes Items # 2, 9, 12, 41, 44, 51, F012, F042, F067 & F171)	1
11	8368	PTO Belt Tightener	1	51	8273-1	Jackshaft (3/4 x 8-1/8)	1**
12	5841	Retainer Washer (3/8 x 1-1/4)	4	52	7240-4	Jackshaft Drive Pulley (3.3/3V) (Includes Items # F067 & F171)	1
13	8243-1	Clutch Idler Pulley	1	Fasteners			
	8243	Clutch Idler Pulley Assembly (Includes Items # 13-15 & F070)	*		F003	1/4-28 Hex Nut	2
14	5265	Bearing (3/4)	1		F004	1/4-20 Keps Nut	3
15	8243-3	Hub, Idler Pulley	1		F005	1/4-20 ESNA Nut	1
16	8375	PTO Belt Tightener Stop	1		F009	5/16-18 Whiz Locknut	3
17	7377	Plastic Washer (1 x .438 x .025)	2		F012	3/8-16 Keps Nut	6
18	7378	Pivot Bearing (7/16 x 9/16)	1		F029	1/4-20 x 1/2 Hex Bolt	1
19	5281-5	Clevis Pin (1/4 x 0.80)	2		F041	3/8-16 x 1-3/4 Hex Bolt	2
20	5280	Clevis (1/4)	2		F042	3/8-16 x 2-1/4 Hex Bolt	3
21	8305	Brake Actuator Rod	1		F043	3/8-16 x 3 Hex Bolt	1
22	8370	Bearing, Brake Actuator	1		F047	3/8-16 x 4-1/2 Hex Bolt	1
23	8250	Brake Spring (1/2 x 2-1/2)	1		F054	AN960616 Washer	3
24	8369	Brake Actuator (Includes Items # 2 & 22)	1		F061	1/4 Internal Star Lock Washer	1
PTO Drive Shaft Assembly					F067	3/16 x 3/16 x 1 Key	2
25	7050-1	Dipstick, Gearbox	1		F069	3/32 x 1/2 Cotter Pin	3
26	8371-1	Mount Bracket, Brake Band	1		F070	1-3/4 Internal Snap Ring	1
27	8377	Brake Band Guide	1		F090	1/4-20 x 2-1/2 Hex Bolt	2
28	8050-11	PTO Gearbox / Flange Pulley	1		F116	1/4-20 x 1-1/4 Hex Bolt	1
29	7248	Ground Drive Belt, Micro-V	1		F121	5/16-18 x 3/8 x 1 SHL Bolt	1
30	7275-16	Universal Joint Tube Assembly / Spine	1		F131	5/16-18 x 1/2 Hex Bolt	2
31	7275-9	Quick Coupler Installation Tool	1		F168	5/16 Split Lock Washer	10
32	7523-2	Clevis Pin W/Hole (1/4 x 5/8)	1		F171	5/16-18 x 3/8 Set Screw	4
33	8304	Brake Band (14-1/2)	1		F178	1/4 x 1 Fender Washer	1
34	6250-1	Drive Belt (3VX370)	1		F182	1/4 x 5/8 x 1/8 Washer	2
35	7236-1	PTO Drive Pulley (4-1/2/3V) (Includes Items # F168 & F226)	1		F226	5/16-18 x 7/8 Hex Bolt	14
36	8237-2	Engine Pulley, Bolt On (4/3.8/3V) (Includes Item # F226)	1		F241	.375 x .875 x .10 Washer	1
37	8230	Engine PTO Belt	1		F255	5/16-18 x 1-1/2 Hex Bolt	2
Jackshaft Assembly					F261	AN960616L Washer	1
38	7245-1	Idler Pulley (3/8 Groove)	1		F336	3/8-16 Jam Nut	1
39	6325-2	Spacer Bushing (5/16)	2		F353	3/8-16 ESNA LP Nut	1
				* Service Part Only			
				** Prior to S/N 175934 use P/N 8273. See Advisory Bulletin #22288.			

MAIN COMPONENT POWER TRANSMISSION (NON-COLLECTION MODELS)



ENGINE GROUP

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Precleaner Assembly				46	NS	10-24 x 1/2" Button Head Hex Screw	3
1	7026-3	Remote Precleaner (Includes Item # 5)	1	47	8013-44	Upright Support	1
2	7440	Shock Mount (1 x 3/4)	3	48	8013-45	Heat Shield, Muffler	1
3	7028-20	Rear Precleaner Mount	1	49	NS	1/4-20 x 5/8" Button Head Hex Screw	4
4	7032	Elbow, Precleaner	1	50	8013-43	Muffler Heat Shield Endcap	1
5	7840-5	Hose Clamp (1.56 - 2.50)	5	51	NS	10-24 x 3/8" Button Head Hex Screw	1
6	5091-18	Air Flow Indicator (Vacuum 15" H2O)	1	52	8013-18	Muffler Brace	1
7	5088-12	Air Cleaner Assembly (Includes Items # 6, 9-13 & 17)	*	53	8021-2	Engine Brace, Chassis	1
8	5088-3	Air Cleaner Band	1	54	8021-1	Engine Brace	1
9	5090-3	Safety Filter Insert	1	Fasteners			
10	5090-1	Air Cleaner Cartridge	1	F002	10-24 Keps Nut		7
11	5088-5	Air Cleaner Draw Latch	2	F004	1/4-20 Keps Nut		6
12	5088-11	Air Cleaner Cap (Includes Item # 11)	1	F009	5/16-18 Whiz Locknut		13
13	5090-2	Vacuator Valve	1	F012	3/8-16 Keps Nut		2
14	8026-10	Air Hose, Cleaner	1	F029	1/4-20 x 1/2 Hex Bolt		4
15	7031-3	Tube Support Arm	1	F031	1/4-20 x 5/8 Hex Bolt		2
16	7028-6	Precleaner Tube (1-3/4)	1	F034	5/16-18 x 3/4 Hex Bolt		2
17	5091-4	Indicator Nipple	1	F038	3/8-16 x 1 Hex Bolt		3
Engine Assembly				F049	5/16 SAE Washer		3
18	NS	Fuel Pump (Kohler)	1	F050	1/4 SAE Washer		2
19	5879-3	Hose Clamp (1/2)	4	F053	7/16 Int. Star Lock Washer		2
20	NS	Fuel Line, Engine (Kohler)	*	F061	1/4 Internal Star Lock Washer		4
21	5020	Fuel Filter	*	F079	A/A66D Aluminum Pop Rivet		2
22	NS	Rectifier	*	F091	5/16-18 x 5/8 Hex Bolt		2
23	8016-4	Regulator Mount	1	F128	10-24 x 3/8 PTHMS		3
24	NS	Oil Filter	1***	F140	7/16-14 x 1 Hex Bolt		2
25	NS	23 HP Kohler Engine	1	F175	1/2 Split Lock Washer		4
26	5845	Rubber Bumper (1.50 x 1.25)	1	F198	.250 x .625 x .040 Washer, SS		2
27	8010-2	Engine Bumper Mount	1	F235	5/16-18 x 2-1/2 Hex Bolt		1
28	5832	Cable Clamp (1/2)	3	F255	5/16-18 x 1-1/2 Hex Bolt		2
Fuel Tank Assembly				F256	7/16 SAE Washer		2
29	M246	Fuel Line, Tank (1/4 x 20-1/2")	1**	F273	M6 x 1.0 Nut		4
30	5083-1	Bushing, Rubber	1	F285	1/2-13 x 1-1/2 Hex Bolt		4
31	M113	Fuel Line (3/16 x 28")	1**	F438	5/16-18 x 2-3/4 Hex Bolt		1
32	5086-7	Hose (1/4 x 6)	1	F547	M6 x 1.0 x 45 Stud		2
33	8023	Fuel Tank Support	1	F551	5/16-18 Flange Top Lock Nut		2
34	5020-2	Fuel Filter, In Tank	1	F570	3/8-16 Flange Top Lock Nut		1
35	8055-1	Fuel Tank, 4.7 Gallon, Gas (Black) (Includes Items # 30, 32, 34 & 37-40)	1	F646	3/8-16 x 3/4 Serrated Hex Bolt		2
36	5082-4	2-1/4 Ratchet Fuel Cap	*	* Service Part Only			
37	8055-2	Fuel Tank Gauge	1	** Required hose specifications:			
38	5977-7	Roll Over Grommet (.900 x 1-1/2)	1	M113 - 3/16" ID fuel/oil/vapor hose (Gates 4219-0093 or equivalent)			
39	8043-8	Roll Over Valve	1	M246 - 1/4" ID low permeation (<15g/m^2/day) fuel hose (Parker 38904 or equivalent)			
40	5083-8	Tank Tube (13")	1	*** Refer to the Operator's Manual for recommended part number.			
Exhaust Assembly				*** Refer to the Operator's Manual for recommended part number.			
41	8530-21	Grass Shield	1	Δ Use the engine model and spec number from Kohler to order this item.			
42	7307-9	Pull Through Bumper	2	NOTE: Refer to Kohler Engine Decal (NS) for Engine Identification Number.			
43	NS	Gasket (Kohler)	2Δ				
44	NS	Nut (Kohler)	4Δ				
45	8013-9	Muffler	1				


[illegible]

15

HYDROSTATIC GROUND DRIVE ASSEMBLIES

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
TOPS™ Components				Deck Support Arm Assemblies			
1	5024-22	3/8 Hose Barb x #6/ORB 90 Degree	2	41	6430-10	Outboard Mount, LH	1
2	5879-11	Hose Clamp (16mm)	6	42	6431-1	Deck Support Arm, LH (Includes Item # 46)	1
3	M358	High Temp Hose (3/8" x 8-1/4")	1	43	5775-2	Hitch Pin (# 6)	2
4	5024-30	Pulley	1	44	6431-2	Deck Support Arm, RH (Includes Item # 46)	1
5	5025-51	Hydro Pump Assembly (Includes Items # 7 & 19)	1	45	6430-9	Outboard Mount, RH	1
6	M358	High Temp Hose (3/8" x 8-3/4")	1	46	5830	Grease Fitting	2
7	5024-15	1/4-18 Pipe Thread, 3/8 Barb Fitting	2	47	6840-1	Support Arm Bushing (2-1/16)	2
8	5024-13	Transmission Oil Filter	1	Transmission Repair Parts			
9	5975-3	Cable Tie (50# x 7")	1	48	5025-16	Control Shaft Repair Kit	*
10	6206-1	Air Vent Valve	3	49	5025-13	Hydro Input Shaft / Repair Kit (Includes Items # 50-52)	*
11	5024-27	1-1/16"-12 Socket Plug Reservoir Cap	1	50	5025-8	Bearing, Input Shaft	*
12	5024-25	Oil Reservoir Sight Gauge	1	51	5025-7	Snap Ring	*
13	5024-9	90 Degree Fitting W/Filter	1	52	NS	Seal, Input Shaft	*
14	5024-29	Oil Reservoir Tank	1	53	5025-53	O-Ring & Plug	*
15	7427-12	Brass Pipe Plug (1/4 NPTF)	1	Fasteners			
16	5024-23	90 Degree Male Fitting, 3/8 Barb 1/4 Thread	1	F004	1/4-20 Keps Nut	2	
17	M358	High Temp Hose (3/8" x 6-1/2")	1	F012	3/8-16 Keps Nut	2	
18	5024-11	Left Hand Hose (7-3/8")	1	F023	10-24 ESNA Nut	2	
19	5024-10	Elbow, 90 Degree (1/2-20 x 9/16-18)	4	F027	10-24 x 5/8 PPHMS	2	
20	5022	Reservoir/Casting Gasket	2	F032	1/4-20 x 3/4 Hex Bolt	1	
21	5024-7	Transmission Reservoir Adapter Fitting	2	F036	1/4-20 x 1/2 SBH Screw	2	
22	5024-12	Right Hand Hose (9-3/8")	1	F040	3/8-16 x 1-1/2 Hex Bolt	4	
Ground Drive Assemblies				F043	3/8-16 x 3 Hex Bolt	6	
23	6243-3	Fan Guard	1	F053	7/16 Internal Star Lock Washer	4	
24	6209-6	Bridge Assembly	1	F063	3/8 Internal Star Lock Washer	17	
25	6243-1	Hydro Fan, CW	1	F064	1/8 x 1/2 Woodruff Key (#3)	4	
26	7244	Hydro Pulley (3-7/8/MV) (Includes Items # F064 & F359)	2	F081	A/A45D Aluminum Pop Rivet	2	
27	5026-34	Hydrostatic Drive, CW	1	F160	External Snap Ring (.669 Shaft)	2	
28	6200-9	Gear Axle Drive Assembly (Includes Items # 10 & 29)	2	F178	1/4 x 1 Fender Washer	2	
29	6207-12	Pipe Plug (1/4 NPTF)	4	F182	1/4 x 5/8 x 1/8 Washer	1	
30	5126	Cable Retainer (Uses existing bolt on Gear Axle Drive Assembly)	1	F194	7/16 x 1-1/4 x 1/8 Washer	2	
31	6233-1	Pinion Gear	2	F200	7/16-20 x 3 Grade 8 Bolt	2	
32	6234	Spacer, Pinion Gear	2	F211	1/4-20 x 7/8 Hex Bolt	2	
33	6201	O-Ring Seal	2	F244	7/16-20 x 3/4 Hex Bolt	2	
34	5025-34	Hydrostatic Drive, CCW	1	F262	3/8-16 x 4 Hex Bolt All Thread	2	
35	6243-2	Hydro Fan, CCW	1	F359	5/16-18 x 5/16 Set Screw (Knurl Point)	4	
Transmission Lockout Assembly				F398	1/4-20 x 2 Hex Bolt	2	
36	5028-3	Transmission Lockout Assembly (Includes Items # 37-40, F023, F027 & F081)	*	F569	1/4-20 Flange Top Lock Nut	3	
37	5847	Plastic Tip	2	F579	3/8-16 x 1 Hex Bolt Grade 8	4	
38	5057	Lockout Cam (Includes Item # F081)	2	F659	1/8 x 1/8 x 3/4 Key	1	
39	5028-5	Lockout Lever	2	F669	1/4-20 x 5/8 Hex Bolt W/Loctite	1	
40	5027-5	Lockout Mount	1**	* Service Part Only			
				** Part not used on Jackshaft side of tractor.			

HYDROSTATIC GROUND DRIVE ASSEMBLIES




STEERING CONTROL ASSEMBLIES

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Transmission Spring Assemblies				Steering Lever Assemblies			
1	6201-4	Shock Mount Gear Drive, RH	1	32	5223	Extension Spring (1/4 x 5-1/2)	2
2	5146	10mm Ball Stud	4	33	5450	D-Clip	2
3	5199-4	Steering Lever Dampener Assembly	2	34	5451-11	Steering Lever Assembly, LH / Adjustable (Includes Items # 9-11, 16, F034 & F582)	1
4	6201-3	Shock Mount Gear Drive, LH	1	35	5391-3	Steering Lever Support	1
5	5214-2	Ball Joint (5/16-24) Nylon Lined	2	36	5217	Pivot Pin, Steering Lever	1
6	6212-7	Transmission Control Arm, LH	1	37	5453-10	Steering Lever Handle, Adjustable (Includes Items # 14 & F345)	2
7	5213-3	Control Rod (6")	1	38	5450-11	Steering Lever Assembly, RH / Adjustable (Includes Items # 9-11, 16, F034 & F582)	1
8	5665-1	Compression Spring (2-1/2)	2	Fasteners			
9	7201-2	Fiberglide Bearing 1/2"	2		F004	1/4-20 Keps Nut	4
10	5463-5	Steering Arm Pivot Bushing (SS)	2		F007	5/16-18 Jam Nut	2
11	5463-4	Steering Lever Actuator	2		F009	5/16-18 Whiz Locknut	7
12	5213-4	Control Rod (14-3/4")	1		F010	5/16-24 ESNA Nut	4
13	5212-7	Transmission Control Arm, RH	1		F012	3/8-16 Keps Nut	2
Forward Speed Control Assemblies					F024	5/16-24 Jam Nut	4
14	5850-2	Handle Grip, Foam (5-1/2)	3		F029	1/4-20 x 1/2 Hex Bolt	2
15	7170-2	FSC Lever Assembly (Includes Item # 16)	1		F032	1/4-20 x 3/4 Hex Bolt	2
16	5830	Grease Fitting	6		F034	5/16-18 x 3/4 Hex Bolt	4
17	5975-3	Cable Tie (50# x 7")	1		F038	3/8-16 x 1 Hex Bolt	2
18	5214-4	Ball Joint (5/16-24) W/O Stud	2		F050	1/4 SAE Washer	1
19	5219	Extension Spring (3/4 x 6-3/4)	1		F051	3/8 SAE Washer	2
20	5172	Bearing, Delrin (.250 x .375 x .250)	2		F064	1/8 x 1/2 Woodruff Key (#3)	2
21	5141-1	FSC Actuator Block	1		F068	1/8 x 1 Cotter Pin	1
22	5140-9	FSC Brace	1		F069	3/32 x 1/2 Cotter Pin	1
23	5141	FSC Friction Washer (1-1/2 x 3/8 x 1/16)	2		F093	5/16-18 x 1 Hex Bolt	1
24	5142-8	FSC Key	1		F146	1/4-20 Jam Nut	1
	5140-12	FSC Control Assembly (Includes Items # 16, 23-25, 28, F182, F192 & F193)	*		F182	1/4 x 5/8 x 1/8 Washer	1
25	5140-30	FSC Friction Body (Includes Item # 16)	1		F183	.312 x .700 x .074 Washer	3
26	5141-2	FSC Actuator Rod	1		F186	5/64 x 1/2 Cotter Pin	1
27	5281-5	Clevis Pin (1/4 x 0.80)	1		F188	1/4-20 Self-Locking Nut	4
28	5142-9	FSC Actuator Cam	1		F192	3/8-24 Self-Locking Nut	1
29	5141-3	Spacer	1		F193	3/8 Belleville Spring Washer	3
30	5141-4	FSC Rod	1		F198	.250 x .625 x .040 Washer, SS	2
31	5470-2	Speed Control Stop	1		F226	5/16-18 x 7/8 Hex Bolt	1
					F316	5/16-18 x 1-3/4 Hex Bolt	1
					F345	1/4-20 x .770 Knurled Bolt	4
					F350	1/4-20 LP Nylock	1
					F353	3/8-16 ESNA LP Nut	2
					F401	.504 x .751 x .030 Washer	1
					F562	5/16-18 x 1 Set Screw	1
					F582	Washer 5/16 x 7/8 x .125	2

* Service Part Only

STEERING CONTROL ASSEMBLIES




Model T23 Beginning S/N 170586
Use only genuine **Walker®** replacement parts.

THROTTLE & CHOKE CONTROL ASSEMBLIES

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Throttle & Choke Control Assemblies				Fasteners			
1	5108-6	Choke Control Knob, Black	1	F002	10-24 Keps Nut		2
2	5108-31	Control Lever	2	F085	3/16 Rivet Backup Washer		2
3	5108-10	Friction Washer (.125)	4	F202	10-24 x 5/8 SHC Screw GR 5		4
4	8123	Insulating Sleeve (3/8 x 6)	1	F350	1/4-20 LP Nylock		2
5	5975-1	Cable Tie (18# x 3-3/4")	2	F638	1/4-20 x 1 Carriage Bolt		2
6	8122-1	Choke Cable	1	F642	1/4 x .042 Belleville Washer		2
7	8121-1	Throttle Cable	1				
8	5172-6	Bushing, SS (.375 x .188 x .290)	2				
9	5108-29	Control Bracket	2				
10	5108-5	Throttle Control Knob, Red	1				


THROTTLE & CHOKE CONTROL ASSEMBLIES



PARKING BRAKE ASSEMBLY


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Parking Brake Assembly				Fasteners			
1	7406-1	Handle Grip, Red	1	F002	10-24 Keps Nut		2
2	7406-9	Parking Brake Lever	1	F003	1/4-28 Hex Nut		1
3	7406-10	Lever Mount	1	F004	1/4-20 Keps Nut		4
4	5830	Grease Fitting	1	F025	10-24 x 3/8 PPHMS		2
5	7407	Clevis Pin (3/16 x 1/2)	2	F029	1/4-20 x 1/2 Hex Bolt		3
6	7404-6	Brake Actuator Arm	2	F032	1/4-20 x 3/4 Hex Bolt		1
7	7405	Pin, Transmission Lock	2	F054	AN960616 Washer		2
8	7402	Clevis	2	F072	1/4 "E" Retainer Ring		2
9	7408	Compression Spring (1/2 x 3/4)	2	F086	#10 SAE Washer		4
10	7415	Rubber Dust Shield (5/8 x 3/8 x 1/32)	2	F109	1/8 x 5/8 Roll Pin		2
11	5567-3	O-Ring Seal (1/4 x 3/8)	4	F111	1/8 x 3/4 Cotter Pin		1
12	7403	Plunger Bushing, Gear Axle	2	F112	5/8 x 1-1/4 x .03 Washer		2
13	7404-7	Brake Actuator Mount	2	F127	1/16 x 1/2 Cotter Pin		4
14	7412	Clevis Pin (3/16 x 5/8)	2	F261	AN960616L Washer		5
15	5833	Cable Clamp (1/4)	2	F287	1/4-28 Keps Nut		1
16	7410	Brake Control Cable, LH (25.5")	1				
17	7409	Brake Control Cable, RH (20.5")	1				
18	7401-3	Cable Mount Bracket	1				
19	7401-1	Cable Pull Rod	1				
20	5552	Ball Joint (1/4-28)	1				

PARKING BRAKE ASSEMBLY



GHS GROUP


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Delivery Chute Assembly				Fasteners			
1	5515-4	Elbow Delivery Spout	1	F002	10-24 Keps Nut		4
2	5592-24	Backing Plate, Grass-Pak® Switch	1	F004	1/4-20 Keps Nut		3
3	5592-23	Grass-Pak® Housing Spacer	1	F009	5/16-18 Whiz Locknut		7
4	5578	Rear Clip, Chute Mount	1	F012	3/8-16 Keps Nut		3
5	5577	Side Clip, Chute Mount	2	F023	10-24 ESNA Nut		2
6	8511-1	Delivery Chute W/Clips / 10.0 (Includes Items # 4, 5, 7, F362 & F411)	1	F029	1/4-20 x 1/2 Hex Bolt		3
7	5578-10	Front Clip, Chute Mount	1	F034	5/16-18 x 3/4 Hex Bolt		1
8	7530-4	Body Chute (10.5 Blower)	1	F039	3/8-16 x 1-1/4 Hex Bolt		1
Blower Belt Tightener Assembly				F040	3/8-16 x 1-1/2 Hex Bolt		1
				F042	3/8-16 x 2-1/4 Hex Bolt		1
				F050	1/4 SAE Washer		1
				F051	3/8 SAE Washer		1
9	7238-6	Blower Drive Pulley (Includes Items # F075, F114 & F231)	1	F054	AN960616 Washer		1
10	7234-2	Blower Belt (Micro-V)	1	F067	3/16 x 3/16 x 1 Key		1
11	7239-1	Blower Pulley (Micro-V) (Includes Items # F067, F075 & F114)	1	F075	5/16-18 x 1/2 SQH Set Screw		2
12	7364-2	Torsion Spring	1	F079	A/A66D Aluminum Pop Rivet		6
13	7201-3	Fiberglide Bearing	2	F090	1/4-20 x 2-1/2 Hex Bolt		1
14	5830-3	Grease Fitting (45 Deg.)	1	F114	5/16-18 x 5/8 SQH Set Screw		2
15	7364-1	Blower Belt Tightener Arm	1	F128	10-24 x 3/8 PTHMS		4
16	7201-4	Inner Race (1-1/2)	1	F131	5/16-18 x 1/2 Hex Bolt		3
17	5841	Retainer Washer (3/8 x 1-1/4)	1	F132	1/4-20 x 2-3/4 Hex Bolt		1
18	5245	Idler Pulley (3")	1	F168	5/16 Split Lock Washer		3
Blower Assembly				F217	7/16-14 Hex Nut		1
				F218	7/16 Split Lock Washer		1
				F231	1/4 x 3/4 Woodruff Key (# 806)		1
				F281	7/16-14 x 1-3/4 Hex Bolt		1
19	7544	Blower Assembly (10.5") (Includes Items # 20-24, F004, F009, F029, F050, F131, F168 & F426)	1	F362	A/A62D Alum. Pop Rivet (3/16D x 13/32L)		2
20	5268	Bearing W/Collar (3/4)	2	F411	3/16 Bulbex Rivet		6
21	7544-3	Blower Housing (10.5)	1	F426	1/4-20 x 1/2 Carriage Bolt		1
22	7545-2	Blower Output Shaft (10.5)	1	F577	10-24 x 5/8 Carriage Bolt		2
23	7545	Blower Wheel (10.5")	1				
24	7543-1	Blower Faceplate (10.5)	1				
25	7526	Intake Tube (10.5 Blower)	1				
26	5595-2	Intake Cover / GHS	1				
27	7528-5	Skid Bar	1				



GHS POWERFIL® ASSEMBLY (10.0)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
10.0 GHS Powerfil® Assembly				Fasteners			
1	5551-3	Bearing Cap, Powerfil®	1		F003	1/4-28 Hex Nut	2
2	5551-1	Pivot Bearing (#S3PP)	2		F023	10-24 ESNA Nut	10
3	5518-2	Pivot, Delivery Spout	1		F054	AN960616 Washer	1
4	5517-2	Pivot Mount	1		F085	3/16 Rivet Backup Washer	1
5	5552	Ball Joint (1/4-28)	2		F101	10-24 x 1-1/4 SHC Screw	1
6	5558-1	Powerfil® Push Rod	1		F109	1/8 x 5/8 Roll Pin	1
7	5553-3	Bushing, Powerfil® Actuator	4		F261	AN960616L Washer	1
8	5553-1	Compression Spring (1/2 x 2)	2		F287	1/4-28 Keps Nut	2
9	5558-2	Powerfil® Actuator Rod	1		F612	10-24 x 5/8 Truss Head Torx	7
	5549	Actuator Rod Assembly (Includes Items # 5-9 & F003)	*		F613	10-24 x 1/2 Truss Head Torx	2
10	5554	Actuator Arm	1	* Service Part Only			
11	5519-3	Motor Mount Nut (5/8-24)	*				
12	5519-2	Motor Mount Washer	*				
13	5976-2	Grommet (3/16 x 3/4)	1				
14	5519-5	Actuator Motor (12V) (Includes Items # 11 & 12)	1				


GHS POWERFIL® ASSEMBLY (10.0)



GHS 10.0 BUSHEL CATCHER ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Upper Baffle Screen Assembly (Removable)				46	5977-3	Grommet (9/16)	1
1	7512-8	Removable Screen (3/16 Hole) (Includes Items # 2, 5, F190 & F617)	1**	47	5976-2	Grommet (3/16 x 3/4)	1
2	7506	Knob / Threaded Insert (10-24)	2	48	8117	Wire Harness Channel	1
3	8606-3	Channel Top, LH	1	49	8602-3	10.0 Catcher W/O Powerfil®, Gray (Includes Door)	*
4	8606-2	Channel Bottom	2		8602-4	10.0 Catcher W/Powerfil®, Gray (Includes Door)	*
5	7856-1	Edge Molding (26")	1		8610-5	10.0 Bushel Catcher Box, Gray	*
6	7507	Screen Seal (27-1/2)	1	50	8607-9	Powerfil® Cover Plate	1
7	7505	Mustache Spring	2	51	8155-2	Gas Spring Cover, RH	1
8	8606	C-Channel (10.0)	1	52	8608-8	Hinge Plate, RH	1
	8606-20	C-Channel With Spring (10.0) (Includes Items # 7, 8 & F340)	*	53	8608-9	Torsion Bar	1
9	8606-4	Channel Top, RH	1	5598-2 Optional Dump Bag (Not Shown)			
10.0 Exhaust Deflector Door Assembly				May be ordered as an option. Contact your Walker dealer.			
10	8607-16	Upper Seal Support	1	Fasteners			
11	8607-17	Upper Door Seal	1		F020	5/16-18 ESNA Nut	2
12	8607-18	Backup Plate	1		F023	10-24 ESNA Nut	29
13	8512-4	10.0 Catcher Box Door, Gray (Includes Items # 10-14, 16, 17, F085, F411, F649 & F654)	1		F024	5/16-24 Jam Nut	4
14	5583	Handle	1		F029	1/4-20 x 1/2 Hex Bolt	8
15	8607-1	Door Mount, LH	1		F032	1/4-20 x 3/4 Hex Bolt	2
16	8607-12	Upper Door Stiffener	1		F049	5/16 SAE Washer	6
17	8607-7	Lower Door Stiffener	1		F050	1/4 SAE Washer	2
18	8607-8	Door Guide	1		F068	1/8 x 1 Cotter Pin	2
19	8607-2	Door Mount, RH	1		F079	A/A66D Aluminum Pop Rivet	5
GHS 10.0 Bushel Catcher Assembly					F085	3/16 Rivet Backup Washer	6
20	8608-13	Center Strap	1		F094	8-32 x 1/2 PTHMS	6
21	8608-3	Upper Frame Doubler	2		F190	#10 Internal Star Lock Washer	2
22	8608-1	Outside Box Strap	2		F195	1/4-20 x 3/4 PPHMS, SS	4
23	8608-2	Lower Frame Doubler	2		F196	1/4-20 x 1 PPHMS, SS	4
24	8608-4	Center Frame Doubler	1		F208	5/16-18 x 2-1/4 Hex Bolt	2
25	8608-11	Catcher Door Finger	1		F230	1/4-20 x 1-1/4 PPHMS, SS	4
26	8608-6	Catcher Mount	1		F242	1/4-20 x 7/8 PPHMS, SS	8
27	8610-8	Catcher Dump Flap	1		F340	Rivet, Aluminum	4
28	8610-3	Backing Plate, Dump Flap	1		F351	Aluminum Pop Rivet	6
29	7584	Reinforcing Strap	1		F360	1/4-20 x 3/8 Hex Bolt	2
30	5103-5	Pivot Bushing Inner	2		F390	1/4-20 x 7/8 Carriage Bolt	4
31	5801-4	Decal Plate, Round	2		F411	3/16 Bulbex Rivet	21
32	7620-3	Pivot Bushing (1/2 x 9/16)	2		F456	5/16-18 x 3/4 SBH Cap Screw, SS	4
33	8608-7	Hinge Plate, LH	1		F524	3/16 x 3/8 Aluminum Rivet, Black	8
34	5103-7	Outside Torsion Bushing	2		F540	1/4-20 x 1-3/4 PPHMS, SS	1
35	8607-4	Upper Arm	2		F551	5/16-18 Flange Top Lock Nut	4
36	5214-12	Ball Joint (5/16-24)	4		F568	10-24 Flange Top Lock Nut	1
37	5155-12	5/16 Ball Stud	2		F569	1/4-20 Flange Top Lock Nut	27
38	5155-4	Gas Spring	2		F612	10-24 x 5/8 Truss Head Torx	8
39	8155-1	Gas Spring Cover, LH	1		F613	10-24 x 1/2 Truss Head Torx	11
40	8607-3	Lower Arm	2		F617	10-24 x 3/8 Truss Head Torx	4
41	5103-6	Pivot Bushing Outer	2		F618	10-24 x 3/4 Truss Head Torx	6
42	5155-13	3/4 Ball Stud	2		F649	3/16 x .510/.625 Grip Range Rivet, SS	4
43	5523-6	Gas Spring Plate	2		F654	3/16 x .510/.625 Grip Range Rivet	7
44	8608-10	Box Support, Gas Spring	2	*	Service Part Only		
45	7532-1	Handle, Catcher Lift	2	**	This screen can be replaced by P/N 7512-11 Removable Screen (3/4" holes) for improved air flow performance in wet conditions.		


GHS 10.0 BUSHEL CATCHER ASSEMBLY



INSTRUMENT PANEL ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Instrument Panel Assembly				19	8536	Warning Horn	1
1	7307-2	Instrument Panel Cover (Optional)	**	20	8960-15	Ignition Switch (With Keys) (Includes Items # 22, 23 & F349)	1
	8306-4	Instrument Panel Assembly (Includes Items # 2-11, 13, 19-21, F228, F250, F251 & F349)	1	21	8996-9	Red Indicator Light Assembly	2
2	7307-7	Panel Frame	1	22	7854	Plastic Tip, Red	1
3	8820-5	Panel Faceplate W/Decal	1	23	8960-3	Key Set W/Umbrella	*
4	7386	Panel Gasket	1	Fasteners			
5	6941-9	Relay Switch 30/40 Amp	2		F004	1/4-20 Keps Nut	6
6	7941-3	Boot, Circuit Breaker	1		F228	#6 x 5/8 PPHSMS, SS	8
7	7941-5	Circuit Breaker (7 Amp)	1		F238	J Clip, Instrument Panel	8
8	5995-2	Switch Boot	1		F250	6-32 x 1/2 PPHMS	2
9	5995	Toggle Switch (Off-On)	1		F251	6-32 Keps Nut	2
10	8997	Voltmeter Gauge	1		F349	Washer .835 ID 1.122 OD, SS	1
11	8990-1	Hourmeter (Global)	1	* Service Part Only			
12	5975-1	Cable Tie (18# x 3-3/4")	2	** May be ordered as an option. Contact your Walker dealer.			
13	8945-3	Wire Harness, Instrument Panel	1				
14	7307-16	Lining, Panel Box (1/8)	1				
15	7391	Panel Box Mount Plate	2				
16	7977-3	Grommet (1/8 x 1-1/8)	1				
17	7307-1	Shock Mount (1.0 x .25)	3				
18	8385	Panel Box W/Graphic	1				


INSTRUMENT PANEL ASSEMBLY



ELECTRICAL ASSEMBLY

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D	ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
Harness Assembly				Fasteners			
1	5975-3	Cable Tie (50# x 7")	7	F002	10-24 Keps Nut		6
2	5942-4	Safety Switch (NO)	1	F004	1/4-20 Keps Nut		3
3	5833	Cable Clamp (1/4)	1	F009	5/16-18 Whiz Locknut		1
4	8940-26	Wire Harness	1	F019	1/4-20 ESNA Wing Nut		2
5	5832	Cable Clamp (1/2)	5	F025	10-24 x 3/8 PPHMS		3
6	8012-6	Regulator Adapter Harness	1	F026	10-24 x 1/2 PPHMS		2
7	7833-2	Cable Clamp (1 x 1/4)	2	F031	1/4-20 x 5/8 Hex Bolt		2
8	6941-9	Relay Switch 30/40 Amp	1	F032	1/4-20 x 3/4 Hex Bolt		1
9	7948-6	Time Delay Module (.5 Second Delay)	1	F050	1/4 SAE Washer		2
10	7948-5	Time Delay Harness	1	F061	1/4 Star Lock Washer		1
11	8404-8	Plastic Cover, Red	2	F079	A/A66D Aluminum Pop Rivet		4
12	8941	Circuit Breaker (30 Amp) Auto Reset / Sealed	1	F085	3/16 Rivet Backup Washer		1
13	8943	Positive Battery Lead Wire (Red)	1	F093	5/16-18 x 1 Hex Bolt		1
14	5975-1	Cable Tie (18# x 3-3/4")	3	F124	10-32 x 3/8 Taptite Machine Screw		2
15	5942-16	Safety Switch (NO), Delta WP	2	F129	10-24 x 1/2 PTHMS		1
16	6104-13	Adapter Harness	1	F182	1/4 x 5/8 x 1/8 Washer		2
17	5977-6	Grommet (1 x 1-1/4)	1	F232	10-32 Keps Nut		2
18	6105-3	Harness Clip	1	F284	M6 x 1.0 x 8 SCH Screw		1
19	6104-11	Seat Switch (NO)	1	F505	6-32 x 7/8 Hex Trim MS, SS		4
				F506	6-32 Nylock Nut		4
Battery Assembly							
20	6923	Negative Battery Cable	1				
21	5933	Battery Terminal Insul., Red (+)	1				
22	5844-3	Battery Hold-Down Bar	1				
23	5839	Hook Bolt	2				
24	6390-2	Battery Pan	1				
25	NS	Battery (12V/300 CCA/Dry/SP-35)	1				
26	5932	Battery Terminal Insul., Black (-)	1				
27	7834-2	Wire Saddle (2 Wires)	1				

ELECTRICAL ASSEMBLY



Model T23 Beginning S/N 170586
Use only genuine **Walker®** replacement parts.

ELECTRICAL ASSEMBLIES (GHS 10.0 BUSHEL COMPONENTS)

ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
----------	----------	-------------	-----------

Horn & Harness Channel Assemblies

1	5977-2	Grommet, Cut (1/8 x 3/8)	2
2	5975-1	Cable Tie (18# x 3-3/4")	1
3	5975-3	Cable Tie (50# x 7")	1
4	5536-2	Horn, Full Signal	*

Harness & Grass-Pak® Switch Assemblies

5	8950-4	Powerfil® Wire Harness (7.0 / 10.0)	1
6	5594-6	Aluminum Shaft & Vane Assembly	1
7	5592-20	Grass-Pak® Switch Assembly	1
8	5833	Cable Clamp (1/4)	2


ITEM NO.	PART NO.	DESCRIPTION	NO. REQ'D
----------	----------	-------------	-----------

Fasteners

F002	10-24 Keps Nut	1
F023	10-24 ESNA Nut	3
F025	10-24 x 3/8 PPHMS	1
F508	4-40 Keps Nut, SS	2
F509	4-40 x 1/2 Hex Head, SS	2
F612	10-24 x 5/8 Truss Head Torx	1
F613	10-24 x 1/2 Truss Head Torx	2

* Service Part Only


ELECTRICAL ASSEMBLIES (GHS 10.0 BUSHEL COMPONENTS)




LUBRICATION POINTS

ITEM NO.	LOCATION	LUBRICATION TYPE	NO. PLACES	ITEM NO.	LOCATION	LUBRICATION TYPE	NO. PLACES
Lubrication Points				18	Brake Actuator Pivot	Grease	1
1	Steering Lever Pivot	Grease	4	19	Throttle Control Cable Ends	Oil	2
2	Body Hinge Point	Oil	2	20	Catcher Hinge Point	Oil	2
3	Deck-to-PTO Coupling (Grease Spline Slide Area)	Grease	1	21	Rear Wheel Bearing	Grease	2
4	FSC Actuator Rod Pivot Pins	Oil	2	22	Choke Control Cable Ends	Oil	2
5	(FSC) Friction Body Pivot	Grease	1	23	Engine Dipstick / Oil Fill	Oil**	1
6	FSC Lever Pivot	Grease	1	24	Belt Tightener Pivot, Blower Drive (GHS Model Only)	Grease	1
7	Deck Support Arm Pivot	Grease	2	25	Belt Tightener Pivot, Ground Drive	Grease	1
8	Gear Axle	Oil**	2	26	PTO Gearbox Dipstick	Oil**	1
9	Universal Joint Tube Assembly	Grease*	1	27	Choke Control Pivot	Oil	1
10	Parking Brake Lever Pivot	Grease	1	28	Throttle Control Pivot	Oil	1
11	Universal Joint Quick Connect Spline (Grease Slide Area)	Grease	1	* Grease every 25 hours.			
12	Hydrostatic Drive / Oil Reservoir	Oil**	3	** Refer to Model T23 Operator's Manual for procedure for checking and changing oil in Engine Crankcase, Hydro- static Transmissions and Gear Axles.			
13	Belt Tightener Pivot, Jackshaft Drive	Grease	1	NOTE: See Model T23 Operator's Manual (P/N 8000-44) for proper lubrication intervals.			
14	PTO Clutch Lever Pivot	Grease	1				
15	Clutch Actuator Spring Assembly	Grease	2				
16	Belt Tightener Pivot, PTO Clutch	Grease	1				
17	Brake Actuator Rod and Brake Band Pivot Pins (Clevis)	Oil	3				

LUBRICATION POINTS



WIRING SCHEMATIC



MAINTENANCE AND SERVICE RECORD SHEET

[illegible]

MAINTENANCE AND SERVICE RECORD SHEET

[illegible]

LIMITED WARRANTY FOR WALKER COMMERCIAL RIDER MOWER

1. WHAT THIS WARRANTY COVERS, AND FOR HOW LONG:

Walker Manufacturing company will, at its option, repair or replace, without charge, any part covered by this warranty which is found to be defective in material and/or workmanship within two (2) years* after the date of sale to the original retail purchaser unless the product is used for rental purposes, in which case this warranty is limited to ninety (90) days. At Walker's request, customer will make the defective part available for inspection by Walker and/or return the defective part to Walker, transportation charges prepaid. All parts and components of the Walker Mower are covered by this warranty **except** the following components which are warranted separately by their respective manufacturers:

Kohler Engine
Battery

The available warranties covering these items are furnished with each mower. Walker does not assume any warranty obligation, liability or modification for these items, which are covered exclusively by the stated warranty of the respective manufacturers noted above.

* Extended warranties are offered for the following powertrain components:

- A three (3) year unlimited hour warranty is offered for the Walker P/N 6200-9 Gear Axle Assembly.
- A three (3) year or 3000 hour (whichever comes first) warranty is offered for Eaton Model 7 Hydrostatic transmissions; covers full cost of replacement up to 1000 hours of use, and after 1000 hours warranty coverage is prorated against 3000 hours. If the transmissions are serviced at the recommended intervals by an authorized Walker Dealer using only Mobil SHC™ 630 oil (P/N 6450-20) and Walker filters (P/N 5024-13), the warranty will be extended to three (3) years, full replacement coverage, and unlimited hours.

2. WHAT THIS WARRANTY DOES NOT COVER:


- A. This warranty does not cover defects caused by depreciation or damage caused by normal wear, accidents, improper maintenance, improper use or abuse of the product, alterations, or failure to follow the instructions contained in the Operator's Manual for operation and maintenance.
- B. The customer shall pay any charges for making service calls and/or for transporting the mower to and from the place where the inspection and/or warranty work is performed.

3. HOW TO OBTAIN SERVICE UNDER THIS WARRANTY:

Warranty service can be arranged by contacting the dealer where you purchased the mower or by contacting Walker Manufacturing Company, 5925 East Harmony Road, Ft. Collins, CO 80528. Proof of the date of purchase may be required to verify warranty coverage.

4. WARRANTY LIMITATION:

- A. **THERE IS NO OTHER EXPRESS WARRANTY. ANY WARRANTY THAT MAY BE IMPLIED FROM THIS PURCHASE INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE IS HEREBY LIMITED TO THE DURATION OF THIS WARRANTY AND TO THE EXTENT PERMITTED BY LAW ANY AND ALL IMPLIED WARRANTIES ARE EXCLUDED.** Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.
- B. **WALKER WILL NOT BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES AND/OR EXPENSES IN CONNECTION WITH THE PURCHASE OR USE OF THE MOWER.** Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation(s) or exclusion(s) may not apply to you.
- C. Only the warranty expressed in this limited warranty shall apply and no dealer, distributor, or individual is authorized to amend, modify, or extend this warranty in any way. Accordingly, additional statements such as dealer advertising or presentations, whether oral or written, do not constitute warranties by Walker, and should not be relied upon.
- D. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.



WALKER

WALKER MFG. CO. • 5925 E. HARMONY ROAD, FORT COLLINS, CO 80528 • (970) 221-5614
FORM NO. 040824 PRINTED IN USA www.walker.com ©2024 WALKER MFG. CO